


Section 10

Internal Combustion (IC) Truck Components

Contents

(IC) Truck Components	10.2
Cross Reference by Manufacturer	
Propane Tanks	10.22
Propane Parts	10.23
Starters	10.25
Alternators	10.26
Water Pumps	10.27
Radiators and Accessories	10.28
Brake Shoes and Accessories	10.29
Brake Cylinders	10.30
Muffler	10.30
Distributors/Caps	10.31
Ignition Rotors	10.33
Spark Plugs	10.34
Spark Plug Wires	10.36
Coils	10.36
Fan Blades	10.37
Belts	10.37
Bearings	10.39
Seals	10.41
Cylinder Parts	10.41
Switches	10.41

Note: "1910.178(q)(5) All parts of any such industrial truck requiring replacement shall be replaced only by parts equivalent as to safety with those used in the original design."



(IC) Truck Components Cross Reference by Manufacturer

OE Number	Crown Part No.	Description
Allis Chalmers/Tusk (AC)		
232560	380013-012-02	Spark Plug L14-U
4506525	380010-002-02	Belt-Fan H20
4512419	380010-005-02	Belt-Fan K21-K25
4513315	380013-012-02	Spark Plug L14-U
4516333	380013-004-02	Spark Plug W14EXR-U
4516353	380013-004-02	Spark Plug W14EXR-U
4613261	380013-012-02	Spark Plug L14-U
4660976	380013-012-02	Spark Plug L14-U
4737405	380001-010-01	Connector LPG Male 7141M
4738548	064423	Female LP Tank Fitting
4789142	380011-006-02	Alternator 4G52-4G54
4810105	380013-012-02	Spark Plug L14-U
4860509	380010-010-02	Belt-Fan 4Y 5-6 Series
4870598	380001-001-01	Lockoff VFF-30-2-IMP
4901388	380008-003-02	Fan Blade H20 II
4905798	380013-001-02	Spark Plug W20ES-U
4905800	380013-012-02	Spark Plug L14-U
4907334	380013-017-02	Spark Plug W16S-U
4908597	380013-012-02	Spark Plug L14-U
4910105	380013-012-02	Spark Plug L14-U
4916015	380013-012-02	Spark Plug L14-U
4920209	380005-004-01	Starter 4G63-4G64
4920234	380012-011-02	Distrib. Cap DC-20 4G32-52-54
4920235	380015-007-02	Rotor RT-10 4G32-52-54
4920323	380013-006-02	Spark Plug W16EX-U
4921224	380012-011-02	Distributor Cap DC-20 4G32-52-54
4921400	380010-002-02	Belt-Fan H20
4933394	380013-004-02	Spark Plug W14EXR-U
4940236	380050-004	Inner Bearing
4940527	380020-007-02	Brake Shoe Kit (4)
4940532	380020-007-02	Brake Shoe Kit (4)
4940535	380020-007-02	Brake Shoe Kit (4)
4942145	380010-002-02	Belt-Fan H20
4942349	380006-001-02	Pump Water H20 New Style
4942359	380008-004-02	Fan Blade H20
4942371	380012-005-02	Distributor C H20
4942380	380015-008-02	Rotor H20
4942394	380014-008-02	Plug Wire Set H20
4942402	380011-007-02	Alternator H20
4942421	380005-006-01	Starter H20
4942507	380015-008-02	Rotor H20
4943832	794109-004	Bearing Assm
4943897	380020-005-02	Brake Pad (1)
4945286	380050-003	Outer Bearing
4947935	380011-007-02	Alternator H20
4948504	794109-004	Bearing Assm
4948522	380005-001-01	Starter H20-H20II-H25
4948821	380006-003-02	Pump Water HER2.7-1404
4948894	380013-017-02	Spark Plug W16S-U
4949021	380015-007-02	Rotor RT-10 4G32-52-54
4949023	380012-011-02	Distributor Cap DC-20 4G32-52-54
4949046	380011-004-02	Alternator H20-P40-TB42
4949214	380007-001-02	Muffler KO3EB-03-22110
4966574	380010-002-02	Belt-Fan H20
4967525	380005-001-01	Starter H20-H20II-H25
4968831	380015-006-02	Rotor RT-13 TB42 6Cyl
4969885	380006-001-02	Pump Water H20 New Style
4969894	380012-012-02	Distributor Cap H20II
74830760	380001-002-01	Converter JB2
74870598	380001-001-01	Lockoff VFF-30-2-IMP
74884393	380001-002-01	Converter JB2
8641341	380001-001-01	Lockoff VFF-30-2-IMP
8761136	380015-008-02	Rotor H20
8761212	380009-001-02	Radiator

OE Number	Crown Part No.	Description
8761527	380020-004-02	Brake Shoe (1)
8761528	380020-004-02	Brake Shoe (1)
8761529	380020-004-02	Brake Shoe (1)
8761597	380021-001-02	Brake Cylinder
8761606	380023-001-02	Brake Pedal Cover
8761949	380006-002-02	Pump Water K21-K25
8761967	380010-001-02	Belt-Fan H20II-H25
8762050	380013-007-02	Spark Plug W9EP
8762055	380011-001-01	Alternator K21-K25
8762077	380012-002-02	Distributor G H20II
8762078	380012-001-02	Distributor Cap DC-10 H20II
8762079	380015-001-02	Rotor RT-11 H20II
8762122	380012-002-02	Distributor G H20II
8762498	380008-002-02	Fan Blade 4Y 6-7 Series
8762610	380020-001-02	Brake Shoe Kit (4)
8766117	380021-001-02	Brake Cylinder
8772271A	380011-001-01	Alternator K21-K25
8779236	380008-001-02	Fan Blade K21-K25
9001652	380013-017-02	Spark Plug W16S-U
927269	380050-006	Bearing Cone
927272	380050-005	Bearing Cup
AC4830760	380001-002-01	Converter JB2
Baker (BK)		
026903137C	380010-004-02	Belt-Fan GM 3.0L
101286	380010-002-02	Belt-Fan H20
101359	380013-012-02	Spark Plug L14-U
101411	064423	Female LP Tank Fitting
101527	380013-012-02	Spark Plug L14-U
1055931	380001-005-01	Repair Kit JB2
105627	380001-001-01	Lockoff VFF-30-2-IMP
115923	380013-012-02	Spark Plug L14-U
116251	380013-012-02	Spark Plug L14-U
219990	380050-033	Seal Oil Drive Axle
241238	380050-033	Seal Oil Drive Axle
6022	380050-006	Bearing Cone
6022	380050-006	Bearing Cone
6024	380050-005	Bearing Cup
6024	380050-005	Bearing Cup
683819	380050-018	Thrust Roller
716D1	380013-012-02	Spark Plug L14-U
716G1	380013-017-02	Spark Plug W16S-U
716J1	380013-012-02	Spark Plug L14-U
9247374	794109-004	Bearing Assm
9265026	380010-010-02	Belt-Fan 4Y 5-6 Series
9491000604	380010-004-02	Belt-Fan GM 3.0L
9491000624	380010-002-02	Belt-Fan H20
9Y11863	064423	Female LP Tank Fitting
9Y11864	380001-010-01	Connector LPG Male 7141M
FM8105471	380010-004-02	Belt-Fan GM 3.0L
KMCC662145	380050-017	Roller
L0009246860	794109-004	Bearing Assm
L0009247374	794109-004	Bearing Assm
L9509000865	794109-004	Bearing Assm
LD0009246860	794109-004	Bearing Assm
LFM53100008	380050-004	Inner Bearing
Barrett (BR)		
27494-000	380050-035	Bearing Mast
B-27494	380050-035	Bearing Mast
B27494	380050-035	Bearing Mast
CK1318727	380050-005	Bearing Cup
CK1318728	380050-006	Bearing Cone
CK1817083	794109-004	Bearing Assm
CK909353	380015-007-02	Rotor RT-10 4G32-52-54
CK916006	380015-007-02	Rotor RT-10 4G32-52-54
CK923627	380015-001-02	Rotor RT-11 H20II

(IC) Truck Components Cross Reference by Manufacturer

OE Number	Crown Part No.	Description
Blue Giant (BG)		
104910PK	380050-005	Bearing Cup
104948PK	380050-006	Bearing Cone
209MZZ1	380050-035	Bearing Mast
30214JR	380050-004	Inner Bearing
83B089B	380050-019	Roller-Lift
AK30214JR	380050-004	Inner Bearing
AK83B089B	380050-019	Roller-Lift
FMMG209DD	380050-035	Bearing Mast
HVX559	380050-035	Bearing Mast
JLM104910	380050-005	Bearing Cup
JLM104948	380050-006	Bearing Cone
MG209DD	380050-035	Bearing Mast
MG5208VFFQ	380050-016	Roller
MR209MZZ1	380050-035	Bearing Mast
NT104910PK	380050-005	Bearing Cup
NT104948PK	380050-006	Bearing Cone
NTSX09A63	380050-035	Bearing Mast
SX09A63	380050-035	Bearing Mast
X559	380050-035	Bearing Mast
Boman (BO)		
242219516	380013-016-02	Spark Plug T14PR-U
986032431	380011-004-02	Alternator H20-P40-TB42
986033481	380011-004-02	Alternator H20-P40-TB42
HR9DPX	380013-014-02	Spark Plug PT16EPR-L13
HR9DPY	380013-014-02	Spark Plug PT16EPR-L13
Brad Harris (BH)		
H9BC	380013-016-02	Spark Plug T14PR-U
HR8BC	380013-008-02	Spark Plug T16PR-U
HR8BP	380013-008-02	Spark Plug T16PR-U
HR9BC	380013-008-02	Spark Plug T16PR-U
W10DC	380013-007-02	Spark Plug W9EP
Cascade (CA)		
662145	380050-017	Roller
662145A	380050-017	Roller
683819	380050-018	Thrust Roller
797469	380050-017	Roller
C662145	380050-017	Roller
C797469	380050-017	Roller
CC-662145	380050-017	Roller
CC-683819	380050-018	Thrust Roller
CC-683919	380050-018	Thrust Roller
CC662145	380050-017	Roller
CC683819	380050-018	Thrust Roller
CC683919	380050-018	Thrust Roller
Castex (CX)		
102721	380010-010-02	Belt-Fan 4Y 5-6 Series
MH38805	380010-005-02	Belt-Fan K21-K25
Caterpillar/Towmotor (CT)		
0007954	380013-012-02	Spark Plug L14-U
0036901	380010-006-02	Belt-Fan 4G52-4G63
0041663	380013-012-02	Spark Plug L14-U
0045019	064423	Female LP Tank Fitting
0047563	380010-006-02	Belt-Fan 4G52-4G63
0047653	380010-006-02	Belt-Fan 4G52-4G63
0049099	380001-010-01	Connector LPG Male 7141M
0057932	380010-002-02	Belt-Fan H20
0062923	380010-002-02	Belt-Fan H20
0099481	380010-002-02	Belt-Fan H20
0099841	380010-002-02	Belt-Fan H20
0308302	380010-002-02	Belt-Fan H20
0347191	380010-002-02	Belt-Fan H20
0347192	380010-002-02	Belt-Fan H20
0347196	380010-002-02	Belt-Fan H20
062923	380010-002-02	Belt-Fan H20
0631202	380013-012-02	Spark Plug L14-U

OE Number	Crown Part No.	Description
0676637	380013-012-02	Spark Plug L14-U
0971246	380015-008-02	Rotor H20
0971264	380006-001-02	Pump Water H20 New Style
0971270	380015-007-02	Rotor RT-10 4G32-52-54
0971276	380012-011-02	Distributor Cap DC-20 4G32-52-54
0971284	380010-002-02	Belt-Fan H20
0971315	380023-001-02	Brake Pedal Cover
0971353	380013-007-02	Spark Plug W9EP
0971472	380010-010-02	Belt-Fan 4Y 5-6 Series
0971564	380012-005-02	Distributor C H20
0971771	380012-011-02	Distributor Cap DC-20 4G32-52-54
0972385	380013-012-02	Spark Plug L14-U
0972685	380010-002-02	Belt-Fan H20
0973283	380013-012-02	Spark Plug L14-U
0973400	380010-002-02	Belt-Fan H20
0973401	380010-004-02	Belt-Fan GM 3.0L
1009115	794109-004	Bearing Assm
1015754	380010-006-02	Belt-Fan 4G52-4G63
1015776	380021-004-02	Brake Cylinder
1015777	380021-004-02	Brake Cylinder
1015874	064423	Female LP Tank Fitting
1017001	380015-007-02	Rotor RT-10 4G32-52-54
1017046	380012-011-02	Distributor Cap DC-20 4G32-52-54
1017158	380010-004-02	Belt-Fan GM 3.0L
1017268	380013-004-02	Spark Plug W14EXR-U
1032322	380050-004	Inner Bearing
1038060	380015-006-02	Rotor RT-13 TB42 6Cyl
1038083	380013-009-02	Spark Plug W16EPR-U
1039078	380010-006-02	Belt-Fan 4G52-4G63
1041457	380012-009-02	Distributor B 4G63-4G64
1041551	380015-007-02	Rotor RT-10 4G32-52-54
1041579	380006-005-02	Pump Water 4G63-4G64
1041623	380010-009-02	Belt-Fan 4G63-4G64
1041823	380010-009-02	Belt-Fan 4G63-4G64
1075032	380050-006	Bearing Cone
1075034	380050-005	Bearing Cup
1085332	380001-010-01	Connector LPG Male 7141M
1085392	380001-010-01	Connector LPG Male 7141M
141267	380013-017-02	Spark Plug W16S-U
1832A002	380016-001-02	Coil A218371 MD358504 925969
1W0404	380006-003-02	Pump Water HER2.7-1404
1W404	380006-003-02	Pump Water HER2.7-1404
2A3643	380013-012-02	Spark Plug L14-U
2I3346	380011-006-02	Alternator 4G52-4G54
2I5133	380015-002-02	Rotor RT-07 4Y
2I5154	380012-004-02	Distributor Cap DC-6 4Y
2I5416	380050-007	Oil Seal
2I5812	380050-034	Bearing Mast
2I6256	380010-006-02	Belt-Fan 4G52-4G63
2I6276	380012-012-02	Distributor Cap H20II
2I6444	380050-040	Ignition Switch
2I6460	380013-008-02	Spark Plug T16PR-U
2I8115	380015-004-02	Rotor RT-03 F2-FE
2I9273	380006-009-02	Pump Water VA
2N0159	380010-002-02	Belt-Fan H20
2W2530	380010-009-02	Belt-Fan 4G63-4G64
2W9486	380013-006-02	Spark Plug W16EX-U
308302	380010-002-02	Belt-Fan H20
347191	380010-002-02	Belt-Fan H20
347192	380010-002-02	Belt-Fan H20
347196	380010-002-02	Belt-Fan H20
353706	380013-012-02	Spark Plug L14-U
45019	064423	Female LP Tank Fitting
46371	380012-012-02	Distributor Cap H20II
4M6291	380010-006-02	Belt-Fan 4G52-4G63
4W1583	380006-003-02	Pump Water HER2.7-1404

Caterpillar/Towmotor Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Caterpillar/Towmotor Continued

OE Number	Crown Part No.	Description
57932	380010-002-02	Belt-Fan H20
617117	380010-002-02	Belt-Fan H20
62923	380010-002-02	Belt-Fan H20
683819	380050-018	Thrust Roller
6L3408	380010-005-02	Belt-Fan K21-K25
7N314	380001-001-01	Lockoff VFF-30-2-IMP
7W717	380010-004-02	Belt-Fan GM 3.0L
801985	794109-004	Bearing Assm
801985	794109-004	Bearing Assm
8N2236	380013-017-02	Spark Plug W16S-U
8N2630	380013-012-02	Spark Plug L14-U
90420-01480	380015-009-02	Rotor RT-01 GM 6Cyl
90420-01620	380013-014-02	Spark Plug PT16EPR-L13
91202-07400	380008-005-02	Fan Blade 4G63-4G64 K Series
91202-17400	380008-005-02	Fan Blade 4G63-4G64 K Series
91346-40300	380021-002-02	Brake Cylinder
9136103500	380001-010-01	Connector LPG Male 7141M
9136103501	380001-010-01	Connector LPG Male 7141M
9136113500	380001-010-01	Connector LPG Male 7141M
91401-09800	380010-006-02	Belt-Fan 4G52-4G63
91401-19700	380010-006-02	Belt-Fan 4G52-4G63
91446-17100	380020-004-02	Brake Shoe (1)
91465-0020	380001-003-01	Converter Cobra
91484-17100	380021-004-02	Brake Cylinder
91484-27100	380021-004-02	Brake Cylinder
91484-27101	380021-004-02	Brake Cylinder
91484-37100	380021-004-02	Brake Cylinder
91546-12500	380020-004-02	Brake Shoe (1)
91546-12600	380020-004-02	Brake Shoe (1)
91865-03100	380001-001-01	Lockoff VFF-30-2-IMP
91B46-10313	380020-007-02	Brake Shoe Kit (4)
91B46-10314	380020-007-02	Brake Shoe Kit (4)
91B46-10412	380020-007-02	Brake Shoe Kit (4)
91H20-02560	380010-005-02	Belt-Fan K21-K25
91H20-02570	380010-005-02	Belt-Fan K21-K25
91H20-02580	380006-002-02	Pump Water K21-K25
91H20-02860	380013-002-02	Spark Plug Q14R-U11
91H20-03270	380011-001-01	Alternator K21-K25
91H20-04710	380015-001-02	Rotor RT-11 H20II
91H2003270	380011-001-01	Alternator K21-K25
93146-02500	380021-002-02	Brake Cylinder
93146-12500	380021-002-02	Brake Cylinder
93165-03100	380001-002-01	Converter JB2
93165-03800	064423	Female LP Tank Fitting
93165-13100	380001-002-01	Converter JB2
93165-13110	380001-002-01	Converter JB2
93165-13110	380001-006-01	Repair Kit Cobra
93165-23100	380001-003-01	Converter Cobra
9316503500	380001-010-01	Connector LPG Male 7141M
9316503600	064423	Female LP Tank Fitting
93265-10060	380001-002-01	Converter JB2
93265-10080	380001-002-01	Converter JB2
93265-20800	380001-002-01	Converter JB2
93265-30800	380001-002-01	Converter JB2
9326500070	380001-001-01	Lockoff VFF-30-2-IMP
93465-10010	380001-002-01	Converter JB2
953582	380050-006	Bearing Cone
97046-21800	380020-005-02	Brake Pad (1)
971264	380006-001-02	Pump Water H20 New Style
971270	380015-007-02	Rotor RT-10 4G32-52-54
971276	380012-011-02	Distributor Cap DC-20 4G32-52-54
971284	380010-002-02	Belt-Fan H20
971302	380010-006-02	Belt-Fan 4G52-4G63
971562	380011-007-02	Alternator H20
971771	380012-011-02	Distributor Cap DC-20 4G32-52-54

OE Number	Crown Part No.	Description
972433	380050-035	Bearing Mast
972433	380050-035	Bearing Mast
972685	380010-002-02	Belt-Fan H20
973400	380010-002-02	Belt-Fan H20
973401	380010-004-02	Belt-Fan GM 3.0L
973546	380050-037	Packing Cylinder Kit
973851	380050-011	Oil Seal
973851	380050-011	Oil Seal
973960	380050-035	Bearing Mast
973960	380050-035	Bearing Mast
99476	380013-017-02	Spark Plug W16S-U
99476	380013-017-02	Spark Plug W16S-U
99481	380010-002-02	Belt-Fan H20
99841	380010-002-02	Belt-Fan H20
9I4658	380015-001-02	Rotor RT-11 H20II
9L2248	380010-005-02	Belt-Fan K21-K25
9S3581	380050-005	Bearing Cup
9S3582	380050-006	Bearing Cone
9Y5969	380006-003-02	Pump Water HER2.7-1404
A0000-00429	380006-011-02	Pump Water H20II-H25
A0000-02071	380011-004-02	Alternator H20-P40-TB42
A0000-05846	380005-005-02	Starter GM 3.0L
A0000-07882	380050-005	Bearing Cup
A0000-07892	380050-006	Bearing Cone
A0000-10379	380050-017	Roller
A0000-12933	380009-005-02	Radiator
A0000-14798	380012-003-02	Distributor 1 4Y
A0000-26570	380050-006	Bearing Cone
A000007882	380050-005	Bearing Cup
A000007892	380050-006	Bearing Cone
A000010379	380050-017	Roller
A000013592	380010-001-02	Belt-Fan H20II-H25
CT91H2003330	380005-008-02	Starter K21-K25
D700615	380006-003-02	Pump Water HER2.7-1404
F8140-30214	380050-004	Inner Bearing
F814030214	380050-004	Inner Bearing
F8143-32212	380050-003	Outer Bearing
F814332212	380050-003	Outer Bearing
LM40AQ5019	064423	Female LP Tank Fitting
M002T-58681	380005-004-01	Starter 4G63-4G64
MCF00036	380006-003-02	Pump Water HER2.7-1404
MD079696	380010-004-02	Belt-Fan GM 3.0L
MD169418	380012-009-02	Distributor B 4G63-4G64
MD171228	380005-004-01	Starter 4G63-4G64
MD320618	380005-004-01	Starter 4G63-4G64
MD326638	380016-001-02	Coil A218371 MD358504 925969
MD358504	380016-001-02	Coil A218371 MD358504 925969
MD602756	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD602758	380015-007-02	Rotor RT-10 4G32-52-54
MD602949	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD607597	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611686	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611817	380015-001-02	Rotor RT-11 H20II
MD611850	380015-007-02	Rotor RT-10 4G32-52-54
MD618262	380015-001-02	Rotor RT-11 H20II
MD618364	380012-007-02	Distributor Cap DC-19 4G63-4G64
MD851101	380013-017-02	Spark Plug W16S-U
MD851101	380013-017-02	Spark Plug W16S-U
MD970338	380006-005-02	Pump Water 4G63-4G64
MD972033	380014-002-02	Plug Wire Set 4G63-4G64
MD972457	380006-005-02	Pump Water 4G63-4G64
MD972748	380014-002-02	Plug Wire Set 4G63-4G64
MD997476	380013-017-02	Spark Plug W16S-U
MD997476	380013-017-02	Spark Plug W16S-U
MIC-0053011	064423	Female LP Tank Fitting

Caterpillar/Towmotor Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Caterpillar/Towmotor Continued

OE Number	Crown Part No.	Description
MIC0053089	380001-010-01	Connector LPG Male 7141M
MM115231	380010-004-02	Belt-Fan GM 3.0L
MM407440	380010-009-02	Belt-Fan 4G63-4G64
MM502535	380015-006-02	Rotor RT-13 TB42 6Cyl
MM611850	380015-001-02	Rotor RT-11 H20II
MS851101	380013-006-02	Spark Plug W16EX-U
NA040025	794109-004	Bearing Assm
T232T-46772	380012-011-02	Distributor Cap DC-20 4G32-52-54
T232T-48372	380012-007-02	Distributor Cap DC-19 4G63-4G64
T880T-12273	380015-007-02	Rotor RT-10 4G32-52-54
T880T-18972	380015-001-02	Rotor RT-11 H20II
T880T12273	380015-007-02	Rotor RT-10 4G32-52-54
T880X17571	380015-006-02	Rotor RT-13 TB42 6Cyl
Century (CE)		
662145	380050-017	Roller
CC-662145	380050-017	Roller
CC662145	380050-017	Roller
Clark (CL)		
1307511	380010-002-02	Belt-Fan H20
1318727	380050-005	Bearing Cup
1318728	380050-006	Bearing Cone
1320218	380010-005-02	Belt-Fan K21-K25
1333648	380050-016	Roller
1342529	380015-009-02	Rotor RT-01 GM 6Cyl
1810436	380014-008-02	Plug Wire Set H20
1817083	794109-004	Bearing Assm
2360140	380001-002-01	Converter JB2
2361378	380010-002-02	Belt-Fan H20
2363677	380011-006-02	Alternator 4G52-4G54
2383064	380011-006-02	Alternator 4G52-4G54
2385639	380013-004-02	Spark Plug W14EXR-U
2399509	380011-006-02	Alternator 4G52-4G54
2399511	380011-006-02	Alternator 4G52-4G54
2572769	380015-006-02	Rotor RT-13 TB42 6Cyl
2575926	380015-009-02	Rotor RT-01 GM 6Cyl
2781527	380010-001-02	Belt-Fan H20II-H25
2802524	380010-004-02	Belt-Fan GM 3.0L
2807382	380011-006-02	Alternator 4G52-4G54
2814061	380010-004-02	Belt-Fan GM 3.0L
2817056	380005-005-02	Starter GM 3.0L
3490402	380010-005-02	Belt-Fan K21-K25
352780	380010-005-02	Belt-Fan K21-K25
3675433	380001-001-01	Lockoff VFF-30-2-IMP
3739054	380013-012-02	Spark Plug L14-U
3773658	380010-004-02	Belt-Fan GM 3.0L
3779914	380012-011-02	Distributor Cap DC-20 4G32-52-54
3790816	380010-004-02	Belt-Fan GM 3.0L
3799728	380050-006	Bearing Cone
3799729	380050-005	Bearing Cup
4151715	380050-003	Outer Bearing
4312314	380010-005-02	Belt-Fan K21-K25
4335221	380012-007-02	Distributor Cap DC-19 4G63-4G64
4335223	380015-001-02	Rotor RT-11 H20II
4335230	380016-001-02	Coil A218371 MD358504 925969
4338827	380013-004-02	Spark Plug W14EXR-U
4338996	380010-004-02	Belt-Fan GM 3.0L
4352365	380010-004-02	Belt-Fan GM 3.0L
444460	380015-004-02	Rotor RT-03 F2-FE
444771	380013-007-02	Spark Plug W9EP
444881	380050-004	Inner Bearing
444901	380015-006-02	Rotor RT-13 TB42 6Cyl
445268	380008-004-02	Fan Blade H20
445285	380012-005-02	Distributor C H20
445290	380015-007-02	Rotor RT-10 4G32-52-54
445292	380015-007-02	Rotor RT-10 4G32-52-54
445294	380012-012-02	Distributor Cap H20II

OE Number	Crown Part No.	Description
446097	380006-007-02	Pump Water 4Y 5-6 Series
446130	380015-002-02	Rotor RT-07 4Y
446183	380023-001-02	Brake Pedal Cover
446323	380013-008-02	Spark Plug T16PR-U
446399	380015-004-02	Rotor RT-03 F2-FE
446444	380050-037	Packing Cylinder Kit
446583	380013-017-02	Spark Plug W16S-U
542685	380010-006-02	Belt-Fan 4G52-4G63
6015-10340	380001-001-01	Lockoff VFF-30-2-IMP
6016-10470	380001-010-01	Connector LPG Male 7141M
6513962	380011-006-02	Alternator 4G52-4G54
655335	064423	Female LP Tank Fitting
659050	380010-009-02	Belt-Fan 4G63-4G64
6599739	380011-006-02	Alternator 4G52-4G54
662145	380050-017	Roller
683819	380050-018	Thrust Roller
7000201	380014-005-02	Plug Wire Set F2-FE
7000218	380014-005-02	Plug Wire Set FE
7000253	380012-012-02	Distributor Cap H20II
7000255	380012-004-02	Distributor Cap DC-6 4Y
7000272	380015-008-02	Rotor H20
7000289	380011-004-02	Alternator H20-P40-TB42
7000308	380012-005-02	Distributor C H20
7000312	380012-011-02	Distributor Cap DC-20 4G32-52-54
7000350	380010-006-02	Belt-Fan 4G52-4G63
7000351	380010-004-02	Belt-Fan GM 3.0L
7000353	380010-006-02	Belt-Fan 4G52-4G63
7000364	380010-009-02	Belt-Fan H20II
7000507	380006-001-02	Pump Water H20 New Style
7000511	380006-004-02	Pump Water FE
7000659	380010-008-02	Belt-Timing FE
7000977	380023-001-02	Brake Pedal Cover
7001049	380021-004-02	Brake Cylinder
7001081	380021-003-02	Brake Cylinder
7001125	380050-019	Roller-Lift
7001266	380050-004	Inner Bearing
7001320	380050-034	Bearing Mast
7001677	380008-004-02	Fan Blade H20
7003807	380050-007	Oil Seal
7003866	380050-033	Seal Oil Drive Axle
7003887	380050-002	Inner Seal
7004147	380050-040	Ignition Switch
7004445	380050-039	Lift Cylinder O/H Kit
715976	064423	Female LP Tank Fitting
715977	380001-010-01	Connector LPG Male 7141M
742159	380013-012-02	Spark Plug L14-U
774608	380010-010-02	Belt-Fan 4Y 5-6 Series
784250	380013-012-02	Spark Plug L14-U
866176	064423	Female LP Tank Fitting
872631	380012-012-02	Distributor Cap H20II
876983	380010-005-02	Belt-Fan K21-K25
890210	380013-017-02	Spark Plug W16S-U
890215	380013-012-02	Spark Plug L14-U
890217	380013-012-02	Spark Plug L14-U
890219	380013-017-02	Spark Plug W16S-U
890220	380013-017-02	Spark Plug W16S-U
890221	380013-012-02	Spark Plug L14-U
890222	380013-012-02	Spark Plug L14-U
890225	380013-017-02	Spark Plug W16S-U
890227	380013-012-02	Spark Plug L14-U
890236	380013-017-02	Spark Plug W16S-U
890245	380013-012-02	Spark Plug L14-U
890246	380013-012-02	Spark Plug L14-U
890247	380013-012-02	Spark Plug L14-U
890252	380013-017-02	Spark Plug W16S-U
890253	380013-017-02	Spark Plug W16S-U

Clark Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Clark Continued

OE Number	Crown Part No.	Description
890255	380013-012-02	Spark Plug L14-U
890256	380013-012-02	Spark Plug L14-U
890264	380013-012-02	Spark Plug L14-U
890265	380013-017-02	Spark Plug W16S-U
890267	380013-017-02	Spark Plug W16S-U
890271	380013-012-02	Spark Plug L14-U
890272	380013-012-02	Spark Plug L14-U
890273	380013-012-02	Spark Plug L14-U
890274	380013-012-02	Spark Plug L14-U
890276	380013-012-02	Spark Plug L14-U
905949	380011-006-02	Alternator 4G52-4G54
907621	380013-012-02	Spark Plug L14-U
907739	380011-006-02	Alternator 4G52-4G54
908106	380011-006-02	Alternator 4G52-4G54
908221	380011-006-02	Alternator 4G52-4G54
909351	380012-011-02	Distributor Cap DC-20 4G32-52-54
909353	380015-007-02	Rotor RT-10 4G32-52-54
909378	380013-006-02	Spark Plug W16EX-U
911410	380005-004-01	Starter 4G63-4G64
913259	380010-004-02	Belt-Fan GM 3.0L
913628	380013-012-02	Spark Plug L14-U
913633	380013-012-02	Spark Plug L14-U
913638	380013-012-02	Spark Plug L14-U
913639	380013-004-02	Spark Plug W14EXR-U
913831	380013-012-02	Spark Plug L14-U
916005	380012-011-02	Distributor Cap DC-20 4G32-52-54
916006	380015-007-02	Rotor RT-10 4G32-52-54
918306	380005-004-01	Starter 4G63-4G64
918313	380012-009-02	Distributor B 4G63-4G64
920165	380001-006-01	Repair Kit Cobra
920231	380010-009-02	Belt-Fan 4G63-4G64
920971	380005-004-01	Starter 4G63-4G64
920989	380014-002-02	Plug Wire Set 4G63-4G64
920990	380014-002-02	Plug Wire Set 4G63-4G64
922220	380015-009-02	Rotor RT-01 GM 6Cyl
922221	380015-009-02	Rotor RT-01 GM 6Cyl
922786	380013-016-02	Spark Plug T14PR-U
923048	380001-001-01	Lockoff VFF-30-2-IMP
923049	380001-003-01	Converter Cobra
923292	380001-006-01	Repair Kit Cobra
923626	380012-007-02	Distributor Cap DC-19 4G63-4G64
923627	380015-001-02	Rotor RT-11 H20II
923702	380013-014-02	Spark Plug PT16EPR-L13
924942	380006-006-02	Pump Water GM 3.0L
925049	380013-008-02	Spark Plug T16PR-U
925874	380005-005-02	Starter GM 3.0L
925969	380016-001-02	Coil A218371 MD358504 925969
926118	380001-010-01	Connector LPG Male 7141M
926119	064423	Female LP Tank Fitting
930707	380005-005-02	Starter GM 3.0L
930768	380010-009-02	Belt-Fan 4G63-4G64
932435	380001-003-01	Converter Cobra
932437	380001-002-01	Converter JB2
932698	380001-006-01	Repair Kit Cobra
933605	380005-005-02	Starter GM 3.0L
940328	380013-012-02	Spark Plug L14-U
992223	380010-002-02	Belt-Fan H20
Continental (CN)		
SP-200S00009RNYC	380013-004-02	Spark Plug W14EXR-U
YD6	380013-012-02	Spark Plug L14-U
Daewoo (DW)		
045019	064423	Female LP Tank Fitting
062923	380010-002-02	Belt-Fan H20
2W8554	380006-003-02	Pump Water HER2.7-1404
4W1583	380006-003-02	Pump Water HER2.7-1404

OE Number	Crown Part No.	Description
8N2236	380013-017-02	Spark Plug W16S-U
9Y5969	380006-003-02	Pump Water HER2.7-1404
A123042	380050-003	Outer Bearing
A123043	380050-003	Outer Bearing
A213066	794109-004	Bearing Assm
A213955	380001-006-01	Repair Kit Cobra
A218012	380001-003-01	Converter Cobra
A218276	380006-005-02	Pump Water 4G63-4G64
A218278	380010-002-02	Belt-Fan H20
A218315	380005-004-01	Starter 4G63-4G64
A218353	380012-007-02	Distributor Cap DC-19 4G63-4G64
A218357	380015-001-02	Rotor RT-11 H20II
A218371	380016-001-02	Coil A218371 MD358504 925969
A218377	380013-009-02	Spark Plug W16EPR-U
A218378	380014-002-02	Plug Wire Set 4G63-4G64
A218653	380006-006-02	Pump Water GM 3.0L
A218755	380014-002-02	Plug Wire Set 4G63-4G64
A218756	380013-008-02	Spark Plug T16PR-U
A219024	380013-008-02	Spark Plug T16PR-U
A223103	380013-013-02	Spark Plug Q20-PR-U
A232133	380015-009-02	Rotor RT-01 GM 6Cyl
A233320	380050-005	Bearing Cup
A273363	380020-007-02	Brake Shoe Kit (4)
A273364	380020-007-02	Brake Shoe Kit (4)
A273365	380020-007-02	Brake Shoe Kit (4)
A273823	380010-009-02	Belt-Fan 4G63-4G64
A293947	380050-004	Inner Bearing
D141267	380013-017-02	Spark Plug W16S-U
D490720	380006-002-02	Pump Water K21-K25
D490742	380012-002-02	Distributor G H20II
D490743	380012-001-02	Distributor Cap DC-10 H20II
D490744	380015-001-02	Rotor RT-11 H20II
D490816	380014-006-02	Plug Wire Set H20II
D490878	380010-001-02	Belt-Fan H20II-H25
D491452	380008-003-02	Fan Blade H20 II
D700178	064423	Female LP Tank Fitting
D700615	380006-003-02	Pump Water HER2.7-1404
D700699	380013-017-02	Spark Plug W16S-U
MD079696	380010-004-02	Belt-Fan GM 3.0L
Delco-Remy (DR)		
10455012	380005-005-02	Starter GM 3.0L
12309027	380015-008-02	Rotor H20
12309037	380015-008-02	Rotor H20
1972404	380015-008-02	Rotor H20
9000820	380005-005-02	Starter GM 3.0L
9000822	380005-005-02	Starter GM 3.0L
9000850	380005-005-02	Starter GM 3.0L
C-86	380013-012-02	Spark Plug L14-U
C-87	380013-012-02	Spark Plug L14-U
E-414	380015-008-02	Rotor H20
E-417	380015-008-02	Rotor H20
E-417-X	380015-008-02	Rotor H20
E414	380015-008-02	Rotor H20
E414Z	380015-008-02	Rotor H20
R-45-RB	380013-016-02	Spark Plug T14PR-U
R-45-TS	380013-008-02	Spark Plug T16PR-U
Doosan (DOS)		
A218012	380001-003-01	Converter Cobra
A218755	380014-007-02	Plug Wire Set GM 3.0L
Drexel (DX)		
1411740	380013-008-02	Spark Plug T16PR-U
Halla (HA)		
LT125-04	380011-004-02	Alternator H20-P40-TB42
LT125-06B	380011-004-02	Alternator H20-P40-TB42
LT130-41K	380011-004-02	Alternator H20-P40-TB42
LT130-65	380011-004-02	Alternator H20-P40-TB42

Halla Continued ▶

(IC) Truck Components

(IC) Truck Components Cross Reference by Manufacturer

Halla Continued

OE Number	Crown Part No.	Description
LT130-72	380011-004-02	Alternator H20-P40-TB42
LT130-72B	380011-004-02	Alternator H20-P40-TB42
LT130-75	380011-004-02	Alternator H20-P40-TB42
LT135-13	380011-004-02	Alternator H20-P40-TB42
LT135-13B	380011-004-02	Alternator H20-P40-TB42
LT135-17B	380011-004-02	Alternator H20-P40-TB42
LT135-19B	380011-004-02	Alternator H20-P40-TB42
LT135-19C	380011-004-02	Alternator H20-P40-TB42
LT135-19E	380011-004-02	Alternator H20-P40-TB42
LT135-20	380011-004-02	Alternator H20-P40-TB42
LT135-24	380011-004-02	Alternator H20-P40-TB42
LT135-35	380011-004-02	Alternator H20-P40-TB42
LT135-35B	380011-004-02	Alternator H20-P40-TB42
LT135-35C	380011-004-02	Alternator H20-P40-TB42
LT135-54	380011-004-02	Alternator H20-P40-TB42
LT135-68	380011-004-02	Alternator H20-P40-TB42
LT135-69	380011-004-02	Alternator H20-P40-TB42
LT150-25	380011-004-02	Alternator H20-P40-TB42
LT150-25B	380011-004-02	Alternator H20-P40-TB42
Hamech (HAM)		
4968837	380013-004-02	Spark Plug W14EXR-U
8772189	380010-005-02	Belt-Fan K21-K25
8772265	380013-002-02	Spark Plug Q14R-U11
Hyster (HY)		
0028758	380013-012-02	Spark Plug L14-U
0061755	380010-002-02	Belt-Fan H20
0079161	380013-012-02	Spark Plug L14-U
0086071	380010-010-02	Belt-Fan 4Y 5-6 Series
0097999	064423	Female LP Tank Fitting
0104728	380010-005-02	Belt-Fan K21-K25
0111107	380010-010-02	Belt-Fan 4Y 5-6 Series
0118771	380010-002-02	Belt-Fan H20
0123577	380010-010-02	Belt-Fan 4Y 5-6 Series
0123872	380013-012-02	Spark Plug L14-U
0124010	380001-010-01	Connector LPG Male 7141M
0138366	380013-012-02	Spark Plug L14-U
0155442	380010-004-02	Belt-Fan GM 3.0L
0172895	380010-004-02	Belt-Fan GM 3.0L
0175895	380010-004-02	Belt-Fan GM 3.0L
0188643	380010-004-02	Belt-Fan GM 3.0L
0191845	380010-002-02	Belt-Fan H20
0197885	380013-012-02	Spark Plug L14-U
0214998	380014-008-02	Plug Wire Set H20
0258321	380001-001-01	Lockoff VFF-30-2-IMP
0281844	380013-016-02	Spark Plug T14PR-U
0287647	380001-001-01	Lockoff VFF-30-2-IMP
0326827	380013-007-02	Spark Plug W9EP
0388361	380013-008-02	Spark Plug T16PR-U
0807004	380010-004-02	Belt-Fan GM 3.0L
0809400	380010-005-02	Belt-Fan K21-K25
0984977	380010-005-02	Belt-Fan K21-K25
104728	380010-005-02	Belt-Fan K21-K25
111107	380010-010-02	Belt-Fan 4Y 5-6 Series
118771	380010-002-02	Belt-Fan H20
1310962	380011-004-02	Alternator H20-P40-TB42
1312454	380013-017-02	Spark Plug W16S-U
1312459	380013-012-02	Spark Plug L14-U
1326394	380012-006-02	Distributor Cap DC-11 F2-FE
1326395	380015-004-02	Rotor RT-03 F2-FE
1329534	380014-007-02	Plug Wire Set GM 3.0L
1329534	380014-007-02	Plug Wire Set GM 3.0L
1330468	380013-016-02	Spark Plug T14PR-U
1332675	380013-008-02	Spark Plug T16PR-U
1332676	380013-008-02	Spark Plug T16PR-U
1332693	380013-012-02	Spark Plug L14-U
1333648	380050-016	Roller

OE Number	Crown Part No.	Description
1334403	380015-009-02	Rotor RT-01 GM 6Cyl
1334620	380020-003-02	Brake Shoe Kit (2)
1334640	380020-006-02	Brake Shoe Set (2)
1337666	380014-007-02	Plug Wire Set GM 3.0L
1339151	380012-006-02	Distributor Cap DC-11 F2-FE
1339931	380006-009-02	Pump Water VA
1342529	380015-009-02	Rotor RT-01 GM 6Cyl
1347048	380021-003-02	Brake Cylinder
1352140	380009-102	Radiator Cap
1358223	380020-006-02	Brake Shoe Set (2)
1361139	380010-006-02	Belt-Fan 4G52-4G63
1361733	380010-008-02	Belt-Timing FE
1361811	380006-004-02	Pump Water FE
1361837	380013-005-02	Spark Plug W9EXR-U
1361853	380011-005-01	Alternator D5-F2-FE
1362035	380015-004-02	Rotor RT-03 F2-FE
1362069	380005-003-01	Starter VA-F2-FE
1362113	380014-005-02	Plug Wire Set FE
1363007	380020-003-02	Brake Shoe Kit (2)
1367561	380015-004-02	Rotor RT-03 F2-FE
1369893	380014-005-02	Plug Wire Set F2-FE
1370740	380012-006-02	Distributor Cap DC-11 F2-FE
1371206	380012-008-02	Distributor DC-5 D5
1374329	380015-009-02	Rotor RT-01 GM 6Cyl
1374621	380005-005-02	Starter GM 3.0L
1375031	380001-006-01	Repair Kit Cobra
1375492	380050-004	Inner Bearing
1376005	380006-009-02	Pump Water VA
1389133	380013-014-02	Spark Plug PT16EPR-L13
1391321	380005-005-02	Starter GM 3.0L
1450928	380011-005-01	Alternator D5-F2-FE
1451269	380013-008-02	Spark Plug T16PR-U
1457047	380005-005-02	Starter GM 3.0L
1458025	380001-003-01	Converter Cobra
1459717	380001-006-01	Repair Kit Cobra
1461670	380050-006	Bearing Cone
1461673	380050-006	Bearing Cone
1467579	380013-008-02	Spark Plug T16PR-U
1486530	380005-005-02	Starter GM 3.0L
1492154	380050-040	Ignition Switch
1515374	380020-006-02	Brake Shoe Set (2)
1523530	380050-001	Outer Seal
1526078	380010-004-02	Belt-Fan GM 3.0L
1526079	380010-009-02	Belt-Fan H20II
153718	380050-011	Oil Seal
153718	380050-011	Oil Seal
1548620	380005-009-02	Starter
1554033	380012-007-02	Distributor Cap DC-23 FE-F2
1554034	380015-005-02	Rotor RT-17 FE-FE2
155442	380010-004-02	Belt-Fan GM 3.0L
1565313	380020-008-02-L	Shoe, Left Hand
1565314	380020-008-02-R	Shoe, Right Hand
1584121	380009-103	Thermostat
1650426	380005-005-02	Starter GM 3.0L
172895	380010-004-02	Belt-Fan GM 3.0L
175895	380010-004-02	Belt-Fan GM 3.0L
183614	380050-005	Bearing Cup
183614	380050-005	Bearing Cup
183615	380050-006	Bearing Cone
183615	380050-006	Bearing Cone
188643	380010-004-02	Belt-Fan GM 3.0L
191845	380010-002-02	Belt-Fan H20
195193	380001-002-01	Converter JB2
196193	380001-002-01	Converter JB2
2022312	380006-004-02	Pump Water FE
2022460	380015-004-02	Rotor RT-03 F2-FE

Hyster Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Hyster Continued

OE Number	Crown Part No.	Description
2023640	380001-003-01	Converter Cobra
2023646	380001-006-01	Repair Kit Cobra
2023647	380001-006-01	Repair Kit Cobra
2023725	380015-004-02	Rotor RT-03 F2-FE
2026467	380001-006-01	Repair Kit Cobra
2026468	380001-003-01	Converter Cobra
2026721	380001-006-01	Repair Kit Cobra
2027662	380050-004	Inner Bearing
2027663	380050-003	Outer Bearing
2027701	380050-002	Inner Seal
2027817	380050-002	Inner Seal
2035830	380050-040	Ignition Switch
2039210	380050-003	Outer Bearing
2039256	380010-005-02	Belt-Fan K21-K25
2039336	380050-034	Bearing Mast
2039337	380050-034	Bearing Mast
2064053	380009-101	Upper Hose
2064054	380009-100	Lower Hose
213549	380001-002-01	Converter JB2
2302265	380050-037	Packing Cylinder Kit
2302714	380050-041	Packing Cylinder Kit
2303610	380050-034	Bearing Mast
2303874	380050-035	Bearing Mast
2307874	380050-039	Lift Cylinder O/H Kit
2309514	380050-035	Bearing Mast
2314322	380005-003-01	Starter VA-F2-FE
233965	380010-004-02	Belt-Fan GM 3.0L
2339656	380010-004-02	Belt-Fan GM 3.0L
258321	380001-001-01	Lockoff VFF-30-2-IMP
266733	380050-011	Oil Seal
2797577	794109-004	Bearing Assm
287647	380001-001-01	Lockoff VFF-30-2-IMP
300-1555	380005-009-02	Starter
3000542	380012-011-02	Distributor Cap DC-20 4G32-52-54
3000555	380010-002-02	Belt-Fan H20
3000569	380010-006-02	Belt-Fan 4G52-4G63
3000626	380015-007-02	Rotor RT-10 4G32-52-54
3000666	380015-008-02	Rotor H20
3001582	380013-012-02	Spark Plug L14-U
3001585	380013-012-02	Spark Plug L14-U
3001586	380013-012-02	Spark Plug L14-U
3001588	380013-017-02	Spark Plug W16S-U
3001590	380013-012-02	Spark Plug L14-U
3002287	380013-012-02	Spark Plug L14-U
3002288	380013-007-02	Spark Plug W9EP
3002289	380013-017-02	Spark Plug W16S-U
3002290	380013-004-02	Spark Plug W14EXR-U
3002347	380013-004-02	Spark Plug W14EXR-U
3002348	380013-012-02	Spark Plug L14-U
3002349	380013-012-02	Spark Plug L14-U
3002535	380006-009-02	Pump Water VA
3002575	380013-012-02	Spark Plug L14-U
3002577	380013-012-02	Spark Plug L14-U
3003695	380050-035	Bearing Mast
3004951	380001-002-01	Converter JB2
3004958	380001-005-01	Repair Kit JB2
3004979	380050-004	Inner Bearing
3004980	380050-003	Outer Bearing
3020078	380011-004-02	Alternator H20-P40-TB42
3020828	380012-011-02	Distributor Cap DC-20 4G32-52-54
3020958	380012-008-02	Distributor DC-5 D5
3021276	380012-011-02	Distributor Cap DC-20 4G32-52-54
3021364	380050-035	Bearing Mast
3027413	380050-004	Inner Bearing
3029189	380011-006-02	Alternator 4G52-4G54
3035129	380050-035	Bearing Mast

OE Number	Crown Part No.	Description
3040014	380013-012-02	Spark Plug L14-U
3040033	380050-005	Bearing Cup
3040949	380050-005	Bearing Cup
3041677	380006-001-02	Pump Water H20 New Style
3042586	380050-033	Seal Oil Drive Axle
3043274	380012-011-02	Distributor Cap DC-20 4G32-52-54
3044732	794109-004	Bearing Assm
3045352	380023-001-02	Brake Pedal Cover
3045360	380006-001-02	Pump Water H20 New Style
3046220	794109-004	Bearing Assm
3046489	380050-020	Roller-Lift 94mm Dia
3046654	380011-006-02	Alternator 4G52-4G54
3046758	380006-007-02	Pump Water 4Y 5-6 Series
3046813	380015-002-02	Rotor RT-07 4Y
3046816	380012-012-02	Distributor Cap H20II
3046919	380050-019	Roller-Lift
3048471	380012-004-02	Distributor Cap DC-6 4Y
3050408	380013-012-02	Spark Plug L14-U
3051151	380013-012-02	Spark Plug L14-U
3051152	380001-010-01	Connector LPG Male 7141M
3051322	380013-012-02	Spark Plug L14-U
3051807	380050-005	Bearing Cup
3051808	380050-006	Bearing Cone
3051858	380010-004-02	Belt-Fan GM 3.0L
3051878	380010-002-02	Belt-Fan H20
3052059	380001-002-01	Converter JB2
3052065	380014-008-02	Plug Wire Set H20
3052453	380001-001-01	Lockoff VFF-30-2-IMP
3053301	794109-004	Bearing Assm
3054631	380050-034	Bearing Mast
3054910	380050-035	Bearing Mast
3054917	380050-037	Packing Cylinder Kit
3054918	380050-041	Packing Cylinder Kit
3054982	380012-006-02	Distributor Cap DC-11 F2-FE
3055603	380050-004	Inner Bearing
3056632	380050-003	Outer Bearing
3056654	380050-035	Bearing Mast
3057503	380050-011	Oil Seal
3057522	380021-003-02	Brake Cylinder
3057598	380010-005-02	Belt-Fan K21-K25
3057756	380050-039	Lift Cylinder O/H Kit
3057775	380010-008-02	Belt-Timing FE
3061901	380010-008-02	Belt-Timing FE
3061904	380010-004-02	Belt-Fan GM 3.0L
3064467	380010-005-02	Belt-Fan K21-K25
3099227	380010-004-02	Belt-Fan GM 3.0L
3115283	380010-008-02	Belt-Timing FE
3122011	380015-006-02	Rotor RT-13 TB42 6Cyl
3123249	380012-005-02	Distributor C H20
3124790	380008-004-02	Fan Blade H20
3127916	380012-007-02	Distributor Cap DC-23 FE-F2
3130754	380050-004	Inner Bearing
3132196	380050-004	Inner Bearing
3132609	380012-012-02	Distributor Cap H20II
3133089	380015-002-02	Rotor RT-07 4Y
3137615	380050-007	Oil Seal
3142510	380015-001-02	Rotor RT-11 H20II
3143266	380015-002-02	Rotor RT-07 4Y
3143902	380012-007-02	Distributor Cap DC-23 FE-F2
326774	380006-009-02	Pump Water VA
326779	380006-009-02	Pump Water VA
326827	380013-007-02	Spark Plug W9EP
360046	380013-017-02	Spark Plug W16S-U
360046	380013-017-02	Spark Plug W16S-U
368427	794109-004	Bearing Assm
368427	794109-004	Bearing Assm

Hyster Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Hyster Continued

OE Number	Crown Part No.	Description
370411	380010-002-02	Belt-Fan H20
374011	380010-002-02	Belt-Fan H20
379902	380050-040	Ignition Switch
379902	380050-040	Ignition Switch
385656	380011-006-02	Alternator 4G52-4G54
388365	380006-006-02	Pump Water GM 3.0L
402035079	380006-003-02	Pump Water HER2.7-1404
44542	380050-007	Oil Seal
44542	380050-007	Oil Seal
61755	380010-002-02	Belt-Fan H20
683819	380050-018	Thrust Roller
80-1406	380005-009-02	Starter
800136352	380005-009-02	Starter
807004	380010-004-02	Belt-Fan GM 3.0L
809400	380010-005-02	Belt-Fan K21-K25
9000890	380005-009-02	Starter
97999	064423	Female LP Tank Fitting
984977	380010-005-02	Belt-Fan K21-K25
Impco (IMP)		
1015871	380001-002-01	Converter JB2
1015887	380001-002-01	Converter JB2
1015971	380001-002-01	Converter JB2
1040397	380001-002-01	Converter JB2
1085401	380001-002-01	Converter JB2
1085402	380001-002-01	Converter JB2
COBRA	380001-003-01	Converter Cobra
JB	380001-002-01	Converter JB2
JB2	380001-002-01	Converter JB2
N00-6314A	380001-006-01	Repair Kit Cobra
RK-COBRA	380001-006-01	Repair Kit Cobra
RK-K	380001-006-01	Repair Kit Cobra
RK-K-2	380001-006-01	Repair Kit Cobra
RKJ-2	380001-005-01	Repair Kit JB2
VFF30-2	380001-001-01	Lockoff VFF-30-2-IMP
JLG (JL)		
2180387	064423	Female LP Tank Fitting
Junghenrich (JU)		
1405006	380010-005-02	Belt-Fan K21-K25
14050060	380010-005-02	Belt-Fan K21-K25
14087210	380010-010-02	Belt-Fan 4Y 5-6 Series
1408732	380010-005-02	Belt-Fan K21-K25
14087320	380010-005-02	Belt-Fan K21-K25
1409636	380050-035	Bearing Mast
14096360	380050-035	Bearing Mast
14105900	380010-005-02	Belt-Fan K21-K25
14148410	380013-016-02	Spark Plug T14PR-U
14364210	380010-008-02	Belt-Timing FE
14364620	380014-005-02	Plug Wire Set F2-FE
14365400	380006-004-02	Pump Water FE
14365450	380006-004-02	Pump Water FE
1436990	380050-035	Bearing Mast
14369900	380050-035	Bearing Mast
143699003	380050-035	Bearing Mast
1437448	380050-002	Inner Seal
14374480	380050-002	Inner Seal
1438437	380050-034	Bearing Mast
14384370	380050-034	Bearing Mast
14384440	380050-034	Bearing Mast
14415530	380012-006-02	Distributor Cap DC-11 F2-FE
1444116	380050-041	Packing Cylinder Kit
14441160	380050-041	Packing Cylinder Kit
14458080	380050-007	Oil Seal
14462360	380050-037	Packing Cylinder Kit
14473480	380050-007	Oil Seal
14483690	380050-040	Ignition Switch
14485060	380011-005-01	Alternator D5-F2-FE

OE Number	Crown Part No.	Description
14491840	380012-006-02	Distributor Cap DC-11 F2-FE
14495050	380014-005-02	Plug Wire Set FE
14495460	380021-003-02	Brake Cylinder
14501360	380012-006-02	Distributor Cap DC-11 F2-FE
14518910	380001-006-01	Repair Kit Cobra
14520447	380006-004-02	Pump Water FE
14704390	380010-008-02	Belt-Timing FE
1470500	380011-006-02	Alternator 4G52-4G54
14705000	380011-006-02	Alternator 4G52-4G54
50018782	380005-005-02	Starter GM 3.0L
50137926	380005-005-02	Starter GM 3.0L
50148397	380010-004-02	Belt-Fan GM 3.0L
Kalmar (KM)		
4920209	380005-004-01	Starter 4G63-4G64
DV68923	380010-005-02	Belt-Fan K21-K25
Komatsu (KO)		
02117-20021	380010-005-02	Belt-Fan K21-K25
02117-21521	380010-005-02	Belt-Fan K21-K25
02117-23021	380010-005-02	Belt-Fan K21-K25
02117-23523	380010-005-02	Belt-Fan K21-K25
06000-30214	380050-004	Inner Bearing
06000-30214L	380050-004	Inner Bearing
06000-32011	794109-004	Bearing Assm
06000-32021	794109-004	Bearing Assm
06002-30214	380050-004	Inner Bearing
06002-30214L	380050-004	Inner Bearing
11720-52H01-F1	380010-001-02	Belt-Fan H20II-H25
11720-77702	380010-009-02	Belt-Fan 4G63-4G64
11720-87V10	380010-001-02	Belt-Fan H20II-H25
11720-87V10A	380010-001-02	Belt-Fan H20II-H25
11720-B1101	380010-002-02	Belt-Fan H20
11720-F2700	380010-009-02	Belt-Fan 4G63-4G64
11720-K4080	380010-001-02	Belt-Fan H20II-H25
11720-K4080A	380010-001-02	Belt-Fan H20II-H25
11720-K7201	380010-004-02	Belt-Fan GM 3.0L
11720-L1102	380010-002-02	Belt-Fan H20
1310-FT860	380001-012-01	Vaporizer Assembly
20-200	380012-005-02	Distributor C H20
20-203	380012-002-02	Distributor G H20II
21010-50K01	380006-002-02	Pump Water H20II-H25
21010-50K02	380006-002-02	Pump Water H20II-H25
21010-50K26	380006-011-02	Pump Water H20II-H25
21010-50K28	380006-011-02	Pump Water H20II-H25
21010-50K29	380006-011-02	Pump Water H20II-H25
21010-FF225	380006-011-02	Pump Water H20II-H25
21010-L1100	380006-001-02	Pump Water H20 New Style
21010-L1101	380006-001-02	Pump Water H20 New Style
21010-L1125	380006-001-02	Pump Water H20 New Style
21010-L1126	380006-001-02	Pump Water H20 New Style
21010-L1128	380006-001-02	Pump Water H20 New Style
21010-P7526	380006-002-02	Pump Water H20II-H25
21060-48210	380008-004-02	Fan Blade H20
21060-49003	380008-004-02	Fan Blade H20
21060-50K00	380008-003-02	Fan Blade H20 II
21060-87V00	380008-003-02	Fan Blade H20 II
21060-FU40A	380008-001-02	Fan Blade K21-K25
22100-50K10	380012-002-02	Distributor G H20II
22100-50K15	380012-002-02	Distributor G H20II
22100-55K10	380012-002-02	Distributor G H20II
22100-K7201	380012-005-02	Distributor C H20
22157-05M02	380015-008-02	Rotor H20
22157-10B10	380015-007-02	Rotor RT-10 4G32-52-54
22157-52H20	380015-006-02	Rotor RT-13 TB42 6Cyl
22157-55K10	380015-001-02	Rotor RT-11 H20II
22157-71300	380015-008-02	Rotor H20
22157-78500	380015-008-02	Rotor H20

Komatsu Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Komatsu Continued

OE Number	Crown Part No.	Description
22157-D1200	380015-008-02	Rotor H20
22157-H1000	380015-008-02	Rotor H20
22157-H1001	380015-008-02	Rotor H20
22157-R9006	380015-007-02	Rotor RT-10 4G32-52-54
22157-R9007	380015-007-02	Rotor RT-10 4G32-52-54
22157-R9007L	380015-008-02	Rotor H20
22162-23G15	380012-012-02	Distributor Cap H20II
22162-25G11	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-55K10	380012-001-02	Distributor Cap DC-10 H20II
22162-78A10	380012-012-02	Distributor Cap H20II
22162-G5710	380012-012-02	Distributor Cap H20II
22162-G5711	380012-012-02	Distributor Cap H20II
22162-R9006	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-R9007	380012-011-02	Distributor Cap DC-20 4G32-52-54
22401-58001	380013-001-02	Spark Plug W20ES-U
22401-FU412	380013-002-02	Spark Plug Q14R-U11
22401-L1600	380013-007-02	Spark Plug W9EP
22401-M7714	380013-001-02	Spark Plug W20ES-U
22401-M7716	380013-001-02	Spark Plug W20ES-U
22401-V1414	380013-004-02	Spark Plug W14EXR-U
22401-W8914	380013-007-02	Spark Plug W9EP
22450-50K25	380014-006-02	Plug Wire Set H20II
22450-50K50	380014-006-02	Plug Wire Set H20II
22450-50KA0	380014-006-02	Plug Wire Set H20II
23100-B9810	380011-004-02	Alternator H20-P40-TB42
23100-C6000	380011-007-02	Alternator H20
23100-FU410	380011-001-01	Alternator K21-K25
23100-M0413	380011-007-02	Alternator H20
23100-M0414	380011-007-02	Alternator H20
23100-U0105	380011-007-02	Alternator H20
23300-00H10	380005-006-01	Starter H20
23300-00H11	380005-006-01	Starter H20
23300-GS20A	380005-008-02	Starter K21-K25
23300-K9160	380005-001-01	Starter H20-H20II-H25
25-003	380012-012-02	Distributor Cap H20II
25-011	380012-001-02	Distributor Cap DC-10 H20II
26-002	380015-007-02	Rotor RT-10 4G32-52-54
26-011	380015-001-02	Rotor RT-11 H20II
32532-21500	380020-007-02	Brake Shoe Kit (4)
32532-21600	380020-007-02	Brake Shoe Kit (4)
34A-21-13210	380050-003	Outer Bearing
34B-04-46310	380001-001-01	Lockoff VFF-30-2-IMP
37Z-02-HR301A	380015-008-02	Rotor H20
37Z-02-HR301L	380015-008-02	Rotor H20
37Z-02-HR901	380015-008-02	Rotor H20
37Z-02-SP02E	380013-007-02	Spark Plug W9EP
37Z-02-SP04A	380013-001-02	Spark Plug W20ES-U
37Z-02-SP05A	380013-001-02	Spark Plug W20ES-U
3BA-30-31731	380020-005-02	Brake Pad (1)
3BD-22-11280	380050-003	Outer Bearing
3EA-30-11410	380020-007-02	Brake Shoe Kit (4)
3EA-30-11420	380020-007-02	Brake Shoe Kit (4)
3EA-30-11430	380020-007-02	Brake Shoe Kit (4)
3EA-30-1144C	380020-002-02	Brake Shoe Kit (2)
3EA-30-1145C	380020-002-02	Brake Shoe Kit (2)
3EA-30-31150	380020-007-02	Brake Shoe Kit (4)
3EA-30-31160	380020-007-02	Brake Shoe Kit (4)
3EA-30-31170	380020-007-02	Brake Shoe Kit (4)
3EB-03-22110	380007-001-02	Muffler KO3EB-03-22110
3EB-04-A5111	380009-001-02	Radiator
3EB-04-A6110	380009-007-02	Radiator K21-K25
3EB-30-2300K	380020-006-02	Brake Shoe Set (2)
3EB-30-23450	380020-006-02	Brake Shoe Set (2)
3EB-30-31150	380020-004-02	Brake Shoe (1)
3EB-30-31160	380020-004-02	Brake Shoe (1)

OE Number	Crown Part No.	Description
3EB-30-31170	380020-004-02	Brake Shoe (1)
3EB-30-A31180	380020-001-02	Brake Shoe Kit (4)
3EB-36-31130	380023-001-02	Brake Pedal Cover
3EB-36-31280	380021-001-02	Brake Cylinder
3EB-36-31281	380021-001-02	Brake Cylinder
3EB-K3-0203C	380020-008-02-L	Shoe, Left Hand
3EB-K3-0204C	380020-008-02-R	Shoe, Right Hand
3ED-22-11280	380050-003	Outer Bearing
5-81326-001-0	380015-008-02	Rotor H20
64-101	380006-001-02	Pump Water H20 New Style
64-102	380006-011-02	Pump Water H20II-H25
662142	380050-017	Roller
683819	380050-018	Thrust Roller
683919	380050-018	Thrust Roller
7141-F	064423	Female LP Tank Fitting
7141F	064423	Female LP Tank Fitting
7141M	380001-010-01	Connector LPG Male 7141M
8-94243-346-0	380015-008-02	Rotor H20
8-94243-346-1	380015-008-02	Rotor H20
9-8231-1912-0	380015-008-02	Rotor H20
9-8232-1911-0	380015-008-02	Rotor H20
9-8232-1912-0	380015-008-02	Rotor H20
CC-683819	380050-018	Thrust Roller
CC-683919	380050-018	Thrust Roller
CC662145	380050-017	Roller
CC662145A	380050-017	Roller
CC683919	380050-018	Thrust Roller
FN-200	380008-004-02	Fan Blade H20
FN-201	380008-003-02	Fan Blade H20 II
HE-2500753	380014-008-02	Plug Wire Set H20
HE-2500754	380014-008-02	Plug Wire Set H20
HE0052048-00	380013-017-02	Spark Plug W16S-U
HE0110256-00	380013-017-02	Spark Plug W16S-U
HE0110526-00	380013-017-02	Spark Plug W16S-U
HE40-2035063	380006-003-02	Pump Water HER2.7-1404
HE40-2035078	380006-003-02	Pump Water HER2.7-1404
HE40-2035079	380006-003-02	Pump Water HER2.7-1404
HE40-2502314	380013-017-02	Spark Plug W16S-U
HE52892	380013-017-02	Spark Plug W16S-U
JB	380001-002-01	Converter JB2
KO23300-FU410	380005-008-02	Starter K21-K25
MY022-8098-00	380021-001-02	Brake Cylinder
RK-VFF30-2	380001-004-01	Repair Kit VFF30-2
TB260	137811	Clamp Toggle
TJ-90098-09125	380013-007-02	Spark Plug W9EP
TJ-90919-01055	380013-007-02	Spark Plug W9EP
TJ-90919-01950-71	380013-007-02	Spark Plug W9EP
TJ-99312-01035	380010-006-02	Belt-Fan 4G52-4G63
TJ-99321-01035	380010-006-02	Belt-Fan 4G52-4G63
TJ-99512-11039	380010-006-02	Belt-Fan 4G52-4G63
TJ27060-78003-71	380011-002-01	Alternator 4Y - GN81-41
TJ270607800371	380011-002-01	Alternator 4Y - GN81-41
YM129900-4470	380008-002-02	Fan Blade 4Y 6-7 Series
YM129900-44700	380008-002-02	Fan Blade 4Y 6-7 Series
Linde (LI)		
219990	380050-033	Seal Oil Drive Axle
241238	380050-033	Seal Oil Drive Axle
6022	380050-006	Bearing Cone
6022	380050-006	Bearing Cone
6024	380050-005	Bearing Cup
6024	380050-005	Bearing Cup
9246860	794109-004	Bearing Assm
9247374	794109-004	Bearing Assm
9509000865	794109-004	Bearing Assm

Linde Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Linde Continued

OE Number	Crown Part No.	Description
D0009246860	794109-004	Bearing Assm
FM53100008	380050-004	Inner Bearing
LD0009246860	794109-004	Bearing Assm
Mazda (MZ)		
F829-18-V05	380015-004-02	Rotor RT-03 F2-FE
FE09-12-205	380010-008-02	Belt-Timing FE
FE25-18-V05	380015-004-02	Rotor RT-03 F2-FE
FE7915010C	380006-004-02	Pump Water FE
GE01-18-300	380011-004-02	Alternator H20-P40-TB42
Mercury-Pettibone (ME)		
41073	380013-012-02	Spark Plug L14-U
41273	380013-012-02	Spark Plug L14-U
41663	380013-012-02	Spark Plug L14-U
BM15-10	380010-006-02	Belt-Fan 4G52-4G63
CHI70269-001	380001-001-01	Lockoff VFF-30-2-IMP
Mitsubishi (MB)		
0415-30214	380050-004	Inner Bearing
05910-10041	380010-006-02	Belt-Fan 4G52-4G63
1009115	794109-004	Bearing Assm
1015754	380010-006-02	Belt-Fan 4G52-4G63
1015776	380021-004-02	Brake Cylinder
1015874	064423	Female LP Tank Fitting
1017001	380015-007-02	Rotor RT-10 4G32-52-54
1017046	380012-011-02	Distributor Cap DC-20 4G32-52-54
1017158	380010-004-02	Belt-Fan GM 3.0L
1017268	380013-004-02	Spark Plug W14EXR-U
1038060	380015-006-02	Rotor RT-13 TB42 6Cyl
1038083	380013-006-02	Spark Plug W16EX-U
1039078	380010-006-02	Belt-Fan 4G52-4G63
1041457	380012-009-02	Distributor B 4G63-4G64
1041551	380015-007-02	Rotor RT-10 4G32-52-54
1041623	380010-009-02	Belt-Fan 4G63-4G64
1075032	380050-006	Bearing Cone
1075034	380050-005	Bearing Cup
1085017	380014-002-02	Plug Wire Set 4G63-4G64
1832A002	380016-001-02	Coil A218371 MD358504 925969
2A3643	380013-012-02	Spark Plug L14-U
215812	380050-034	Bearing Mast
216276	380012-012-02	Distributor Cap H20II
2N159	380010-002-02	Belt-Fan H20
41530214	380050-004	Inner Bearing
67204C7	380010-002-02	Belt-Fan H20
683819	380050-018	Thrust Roller
7N314	380001-001-01	Lockoff VFF-30-2-IMP
7W717	380010-004-02	Belt-Fan GM 3.0L
801985	794109-004	Bearing Assm
8N2630	380013-012-02	Spark Plug L14-U
90420-01480	380015-009-02	Rotor RT-01 GM 6Cyl
90420-01620	380013-014-02	Spark Plug PT16EPR-L13
91202-07400	380008-005-02	Fan Blade 4G63-4G64 K Series
91202-17400	380008-005-02	Fan Blade 4G63-4G64 K Series
91246-16800	380020-007-02	Brake Shoe Kit (4)
91246-16900	380020-007-02	Brake Shoe Kit (4)
91246-17100	380020-007-02	Brake Shoe Kit (4)
9136103501	380001-010-01	Connector LPG Male 7141M
9136113500	380001-010-01	Connector LPG Male 7141M
91401-09700	380010-006-02	Belt-Fan 4G52-4G63
91401-09800	380010-006-02	Belt-Fan 4G52-4G63
91484-17100	380021-004-02	Brake Cylinder
91484-27100	380021-004-02	Brake Cylinder
91484-27101	380021-004-02	Brake Cylinder
91484-37100	380021-004-02	Brake Cylinder
91865-03100	380001-001-01	Lockoff VFF-30-2-IMP
91H20-02560	380010-005-02	Belt-Fan K21-K25
91H20-02570	380010-005-02	Belt-Fan K21-K25
91H20-03270	380011-001-01	Alternator K21-K25

OE Number	Crown Part No.	Description
91H20-04710	380015-001-02	Rotor RT-11 H20II
91H2002560	380010-005-02	Belt-Fan K21-K25
91H2002570	380010-005-02	Belt-Fan K21-K25
9300201300	380001-010-01	Connector LPG Male 7141M
93146-02500	380021-002-02	Brake Cylinder
93146-12500	380021-002-02	Brake Cylinder
93165-03110I	380001-005-01	Repair Kit JB2
93165-03600	064423	Female LP Tank Fitting
93165-03800	064423	Female LP Tank Fitting
93165-13110	380001-006-01	Repair Kit Cobra
9316503500	380001-010-01	Connector LPG Male 7141M
972433	380050-035	Bearing Mast
9I4658	380015-001-02	Rotor RT-11 H20II
9S3581	380050-005	Bearing Cup
9S3582	380050-006	Bearing Cone
9Y5969	380006-003-02	Pump Water HER2.7-1404
A0000-10379	380050-017	Roller
A0000-26570	380050-006	Bearing Cone
A000010379	380050-017	Roller
A000026570	380050-006	Bearing Cone
A1T20271	380011-004-02	Alternator H20-P40-TB42
A1T21171	380011-004-02	Alternator H20-P40-TB42
A1T22581	380011-004-02	Alternator H20-P40-TB42
A1T24371	380011-004-02	Alternator H20-P40-TB42
AG2025A	380011-004-02	Alternator H20-P40-TB42
AG2030A	380011-004-02	Alternator H20-P40-TB42
AG2035A	380011-004-02	Alternator H20-P40-TB42
AG2035A2	380011-004-02	Alternator H20-P40-TB42
AG2035N1	380011-004-02	Alternator H20-P40-TB42
AH2035N1	380011-004-02	Alternator H20-P40-TB42
C0053321	380001-001-01	Lockoff VFF-30-2-IMP
D700615	380006-003-02	Pump Water HER2.7-1404
F8140-30214	380050-004	Inner Bearing
F814030214	380050-004	Inner Bearing
F8143-32212	380050-003	Outer Bearing
F814332212	380050-003	Outer Bearing
K0000-10379	380050-017	Roller
K000010379	380050-017	Roller
LM40AQ5019	064423	Female LP Tank Fitting
M002T-58681	380005-004-01	Starter 4G63-4G64
M2T58581	380005-004-01	Starter 4G63-4G64
M3T21882D	380005-006-01	Starter H20
MB1017268	380013-004-02	Spark Plug W14EXR-U
MB8N2236	380013-017-02	Spark Plug W16S-U
MB91H2003330	380005-008-02	Starter K21-K25
MCF00036	380006-003-02	Pump Water HER2.7-1404
MD079696	380010-004-02	Belt-Fan GM 3.0L
MD169418	380012-009-02	Distributor B 4G63-4G64
MD171228	380005-004-01	Starter 4G63-4G64
MD320618	380005-004-01	Starter 4G63-4G64
MD326638	380016-001-02	Coil A218371 MD358504 925969
MD358504	380016-001-02	Coil A218371 MD358504 925969
MD602756	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD602758	380015-007-02	Rotor RT-10 4G32-52-54
MD602949	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD607597	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611686	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611817	380015-001-02	Rotor RT-11 H20II
MD611850	380015-007-02	Rotor RT-10 4G32-52-54
MD618262	380015-001-02	Rotor RT-11 H20II
MD618364	380012-007-02	Distributor Cap DC-19 4G63-4G64
MD970338	380006-005-02	Pump Water 4G63-4G64
MD972457	380006-005-02	Pump Water 4G63-4G64
MD997476	380013-017-02	Spark Plug W16S-U
MDI-700210I	380001-005-01	Repair Kit JB2
MDI-700210I	380001-005-01	Repair Kit JB2

Mitsubishi Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Mitsubishi Continued

OE Number	Crown Part No.	Description
MDI700050	064423	Female LP Tank Fitting
MIC-0053100I	380001-005-01	Repair Kit JB2
MIC-0053110I	380001-005-01	Repair Kit JB2
MIC0053011	064423	Female LP Tank Fitting
MIC0053089	380001-010-01	Connector LPG Male 7141M
MM115231	380010-004-02	Belt-Fan GM 3.0L
MM407440	380010-009-02	Belt-Fan 4G63-4G64
MM502535	380015-006-02	Rotor RT-13 TB42 6Cyl
MM611850	380015-001-02	Rotor RT-11 H20II
MS851022	380013-006-02	Spark Plug W16EX-U
MS851101	380013-006-02	Spark Plug W16EX-U
NA040025	794109-004	Bearing Assm
P344049015	380010-006-02	Belt-Fan 4G52-4G63
T232T-46772	380012-011-02	Distributor Cap DC-20 4G32-52-54
T232T-48372	380012-007-02	Distributor Cap DC-19 4G63-4G64
T3T65675	380012-009-02	Distributor B 4G63-4G64
T45327	380012-006-02	Distributor Cap DC-11 F2-FE
T46371	380012-012-02	Distributor Cap H20II
T880T-18972	380015-001-02	Rotor RT-11 H20II
T880T12273	380015-007-02	Rotor RT-10 4G32-52-54
T880X17571	380015-006-02	Rotor RT-13 TB42 6Cyl
320618	380005-004-01	Starter 4G63-4G64
Multiton (MT)		
26500550	794109-004	Bearing Assm
410031122	794109-004	Bearing Assm
410031122	794109-004	Bearing Assm
4207748133	794109-004	Bearing Assm
4207748133	794109-004	Bearing Assm
4208848227	794109-004	Bearing Assm
4208848227	794109-004	Bearing Assm
650055	794109-004	Bearing Assm
Napa (NP)		
EP-312	380015-008-02	Rotor H20
EP-335	380012-007-02	Distributor Cap DC-19 4G63-4G64
EP-339	380015-004-02	Rotor RT-03 F2-FE
EP-342	380015-007-02	Rotor RT-10 4G32-52-54
EP-780	380015-004-02	Rotor RT-03 F2-FE
FA-164	380012-008-02	Distributor DC-5 D5
UD-16	380013-012-02	Spark Plug L14-U
NGK (NG)		
NGBCPR6E	380013-013-02	Spark Plug Q20-PR-U
Nippondenso (ND)		
100211-4540	380011-002-01	Alternator 4Y - GN81-41
290000621	380012-003-02	Distributor I 4Y
L14-U	380013-012-02	Spark Plug L14-U
NDW16S-U	380013-017-02	Spark Plug W16S-U
PT16EPR-L13	380013-014-02	Spark Plug PT16EPR-L13
T14PR-U	380013-016-02	Spark Plug T14PR-U
T16PRU	380013-008-02	Spark Plug T16PR-U
T20EPRU	380013-008-02	Spark Plug T16PR-U
W16EXR-U	380013-004-02	Spark Plug W14EXR-U
W9EP	380013-007-02	Spark Plug W9EP
Nissan (NI)		
01978-11004	380010-009-02	Belt-Fan 4G63-4G64
02117-00511	380010-009-02	Belt-Fan H20II
02117-01011	380010-002-02	Belt-Fan H20
02117-03011	380010-002-02	Belt-Fan H20
02117-20021	380010-005-02	Belt-Fan K21-K25
02117-21521	380010-005-02	Belt-Fan K21-K25
02117-23021	380010-005-02	Belt-Fan K21-K25
08322-1201P	380050-003	Outer Bearing
11720-20H00	380010-004-02	Belt-Fan GM 3.0L
11720-22101	380010-004-02	Belt-Fan GM 3.0L
11720-69200	380010-004-02	Belt-Fan GM 3.0L
11720-87V10	380010-001-02	Belt-Fan H20II-H25
11720-B1100	380010-002-02	Belt-Fan H20

OE Number	Crown Part No.	Description
11720-B1101	380010-002-02	Belt-Fan H20
11720-F2700	380010-009-02	Belt-Fan 4G63-4G64
11720-K4080	380010-001-02	Belt-Fan H20II-H25
11720-K7201	380010-004-02	Belt-Fan GM 3.0L
11720-L1101	380010-002-02	Belt-Fan H20
11720-L1102	380010-002-02	Belt-Fan H20
11720-N9515	380010-004-02	Belt-Fan GM 3.0L
11720-Y4400	380010-002-02	Belt-Fan H20
1172022101	380010-004-02	Belt-Fan GM 3.0L
1172069200	380010-004-02	Belt-Fan GM 3.0L
11920-28L01	380010-004-02	Belt-Fan GM 3.0L
16245-VFF30	380001-001-01	Lockoff VFF-30-2-IMP
16400-90H71	380001-001-01	Lockoff VFF-30-2-IMP
20801-04261	380010-002-02	Belt-Fan H20
21010-50K00	380008-003-02	Fan Blade H20 II
21010-L1100	380006-001-02	Pump Water H20 New Style
21010-L1101	380006-001-02	Pump Water H20 New Style
21010-L1125	380006-001-02	Pump Water H20 New Style
21010-L1126	380006-001-02	Pump Water H20 New Style
21010-L1128	380006-001-02	Pump Water H20 New Style
21060-48210	380008-004-02	Fan Blade H20
21060-49001	380008-004-02	Fan Blade H20
21060-49003	380008-004-02	Fan Blade H20
21060-50K00	380008-003-02	Fan Blade H20 II
21060-87V00	380008-003-02	Fan Blade H20 II
21060-GY360	380008-001-02	Fan Blade K21-K25
21067-38800	380010-004-02	Belt-Fan GM 3.0L
21067-K7201	380010-004-02	Belt-Fan GM 3.0L
21140-90301	380010-009-02	Belt-Fan 4G63-4G64
21460-24H10	380009-006-02	Radiator
21460-6G000	380009-004-02	Radiator
21460-6G100	380009-004-02	Radiator
21460-6G101	380009-004-02	Radiator
21460-90H10	380009-006-02	Radiator
21460-90H15	380009-003-02	Radiator
21460-90H15-D	380009-003-02	Radiator
21460-G6000	380009-004-02	Radiator
22100-49206	380012-005-02	Distributor C H20
22100-49207	380012-005-02	Distributor C H20
22100-49210	380012-005-02	Distributor C H20
22100-50K10	380012-002-02	Distributor G H20II
22100-50K15	380012-002-02	Distributor G H20II
22100-55K10	380012-002-02	Distributor G H20II
22100-71305	380012-005-02	Distributor C H20
22100-71306	380012-005-02	Distributor C H20
22100-71315	380012-005-02	Distributor C H20
22100-71317	380012-005-02	Distributor C H20
22100-74011	380012-005-02	Distributor C H20
22100-K7201	380012-005-02	Distributor C H20
22157-05M02	380015-008-02	Rotor H20
22157-10B10	380015-007-02	Rotor RT-10 4G32-52-54
22157-52H20	380015-006-02	Rotor RT-13 TB42 6Cyl
22157-55K10	380015-001-02	Rotor RT-11 H20II
22157-55K15	380015-001-02	Rotor RT-11 H20II
22157-71300	380015-008-02	Rotor H20
22157-78500	380015-008-02	Rotor H20
22157-D1200	380015-008-02	Rotor H20
22157-H1000	380015-008-02	Rotor H20
22157-H1001	380015-008-02	Rotor H20
22157-R9006	380015-007-02	Rotor RT-10 4G32-52-54
22157-R9007	380015-007-02	Rotor RT-10 4G32-52-54
22157-R9007L	380015-008-02	Rotor H20
22162-11E07	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-17M01	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-17M02	380012-012-02	Distributor Cap H20II
22162-17M03	380012-011-02	Distributor Cap DC-20 4G32-52-54

Nissan Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Nissan Continued

OE Number	Crown Part No.	Description
22162-17M04	380012-012-02	Distributor Cap H20II
22162-23G15	380012-012-02	Distributor Cap H20II
22162-25G10	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-25G11	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-40F00	380012-012-02	Distributor Cap H20II
22162-40F10	380012-012-02	Distributor Cap H20II
22162-55K10	380012-001-02	Distributor Cap DC-10 H20II
22162-75A10	380012-012-02	Distributor Cap H20II
22162-78A00	380012-012-02	Distributor Cap H20II
22162-78A10	380012-012-02	Distributor Cap H20II
22162-78AX0	380012-012-02	Distributor Cap H20II
22162-A3514	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-G5710	380012-012-02	Distributor Cap H20II
22162-G5711	380012-012-02	Distributor Cap H20II
22162-R9006	380012-011-02	Distributor Cap DC-20 4G32-52-54
22162-R9007	380012-011-02	Distributor Cap DC-20 4G32-52-54
2216217M01	380012-011-02	Distributor Cap DC-20 4G32-52-54
2216217M03	380012-011-02	Distributor Cap DC-20 4G32-52-54
N-22401-L1600	380013-004-02	Spark Plug W14EXR-U
22401-M7716	380013-009-02	Spark Plug W16EPR-U
22401-V1414	380013-004-02	Spark Plug W14EXR-U
22401-W8914	380013-007-02	Spark Plug W9EP
22450-49251	380014-008-02	Plug Wire Set H20
22450-50K25	380014-006-02	Plug Wire Set H20II
22450-50K50	380014-006-02	Plug Wire Set H20II
22450-50KA0	380014-006-02	Plug Wire Set H20II
22450-L0150	380014-008-02	Plug Wire Set H20
22450-L1051	380014-008-02	Plug Wire Set H20
22450-L1051	380014-008-02	Plug Wire Set H20
22450-L1125	380014-008-02	Plug Wire Set H20
23100-06000	380011-004-02	Alternator H20-P40-TB42
23100-A4600	380011-007-02	Alternator H20
23100-A4601	380011-007-02	Alternator H20
23100-A4602	380011-004-02	Alternator H20-P40-TB42
23100-A4611	380011-007-02	Alternator H20
23100-A4800	380011-004-02	Alternator H20-P40-TB42
23100-A4810	380011-004-02	Alternator H20-P40-TB42
23100-A5500	380011-004-02	Alternator H20-P40-TB42
23100-A5501	380011-004-02	Alternator H20-P40-TB42
23100-A5502	380011-004-02	Alternator H20-P40-TB42
23100-B8001	380011-004-02	Alternator H20-P40-TB42
23100-B8002	380011-004-02	Alternator H20-P40-TB42
23100-B9802	380011-004-02	Alternator H20-P40-TB42
23100-B9810	380011-004-02	Alternator H20-P40-TB42
23100-B9810-B	380011-004-02	Alternator H20-P40-TB42
23100-C6000	380011-007-02	Alternator H20
23100-E5200	380011-004-02	Alternator H20-P40-TB42
23100-FU410	380011-001-01	Alternator K21-K25
23100-H0100	380011-004-02	Alternator H20-P40-TB42
23100-H0110	380011-004-02	Alternator H20-P40-TB42
23100-H0300	380011-004-02	Alternator H20-P40-TB42
23100-H0310	380011-004-02	Alternator H20-P40-TB42
23100-H6215	380011-007-02	Alternator H20
23100-H7703	380011-007-02	Alternator H20
23100-M0400	380011-004-02	Alternator H20-P40-TB42
23100-M0401	380011-004-02	Alternator H20-P40-TB42
23100-M0402	380011-004-02	Alternator H20-P40-TB42
23100-M0410	380011-004-02	Alternator H20-P40-TB42
23100-M0413	380011-007-02	Alternator H20
23100-M0414	380011-007-02	Alternator H20
23100-M6601	380011-007-02	Alternator H20
23100-U0100	380011-007-02	Alternator H20
23100-U0102	380011-007-02	Alternator H20
23100-U0103	380011-007-02	Alternator H20
23100-U0104	380011-007-02	Alternator H20
23100-U0105	380011-007-02	Alternator H20

OE Number	Crown Part No.	Description
23100-U0110	380011-007-02	Alternator H20
23100-U0111	380011-004-02	Alternator H20-P40-TB42
23100-U0112	380011-007-02	Alternator H20
23100-U0113	380011-007-02	Alternator H20
23100-U0114	380011-007-02	Alternator H20
23100-U4601	380011-007-02	Alternator H20
23100A4602	380011-004-02	Alternator H20-P40-TB42
23100A4800	380011-004-02	Alternator H20-P40-TB42
23100A4810	380011-004-02	Alternator H20-P40-TB42
23100A5500	380011-004-02	Alternator H20-P40-TB42
23100A5501	380011-004-02	Alternator H20-P40-TB42
23100A5502	380011-004-02	Alternator H20-P40-TB42
23100B8001	380011-004-02	Alternator H20-P40-TB42
23100B8002	380011-004-02	Alternator H20-P40-TB42
23100E5200	380011-004-02	Alternator H20-P40-TB42
23100H0100	380011-004-02	Alternator H20-P40-TB42
23100H0110	380011-004-02	Alternator H20-P40-TB42
23100H0300	380011-004-02	Alternator H20-P40-TB42
23100H0310	380011-004-02	Alternator H20-P40-TB42
23100M0400	380011-004-02	Alternator H20-P40-TB42
23100M0401	380011-004-02	Alternator H20-P40-TB42
23100M0402	380011-004-02	Alternator H20-P40-TB42
23100M0410	380011-004-02	Alternator H20-P40-TB42
23100U0101	380011-004-02	Alternator H20-P40-TB42
23100U0111	380011-004-02	Alternator H20-P40-TB42
23300-00H10	380005-006-01	Starter H20
23300-00H11	380005-006-01	Starter H20
23300-K9160	380005-001-01	Starter H20-H20II-H25
23300-L2910	380005-006-01	Starter H20
23300-L2911	380005-006-01	Starter H20
23300-L2912	380005-006-01	Starter H20
38440-61500	380050-003	Outer Bearing
38440-86160	380050-004	Inner Bearing
40211-49000	380050-003	Outer Bearing
40211-49001	380050-003	Outer Bearing
40215-10360	794109-004	Bearing Assm
43215-76000	794109-004	Bearing Assm
43215-T8000	794109-004	Bearing Assm
43533-L1100	380050-033	Seal Oil Drive Axle
44060-00H60	380020-007-02	Brake Shoe Kit (4)
44060-11H03	380020-007-02	Brake Shoe Kit (4)
44060-11H06	380020-007-02	Brake Shoe Kit (4)
44060-22H60	380020-004-02	Brake Shoe (1)
44060-FJ500	380020-007-02	Brake Shoe Kit (4)
44060-L0105	380020-007-02	Brake Shoe Kit (4)
44070-00H60	380020-007-02	Brake Shoe Kit (4)
44070-00H70	380020-007-02	Brake Shoe Kit (4)
44070-0K301	380020-007-02	Brake Shoe Kit (4)
44070-0K311	380020-007-02	Brake Shoe Kit (4)
44070-11H06	380020-007-02	Brake Shoe Kit (4)
44070-11H16	380020-007-02	Brake Shoe Kit (4)
44070-22H60	380020-004-02	Brake Shoe (1)
44070-22H70	380020-004-02	Brake Shoe (1)
44070-FJ500	380020-007-02	Brake Shoe Kit (4)
44070-FJ510	380020-007-02	Brake Shoe Kit (4)
44999-22H00	380020-001-02	Brake Shoe Kit (4)
59117-01H00	380050-020	Roller-Lift 94mm Dia
59117-01H03	380050-020	Roller-Lift 94mm Dia
59117-20H00	380050-019	Roller-Lift
59117-20H03	380050-019	Roller-Lift
6016-10330	380001-003-01	Converter Cobra
662145	380050-017	Roller
683819	380050-018	Thrust Roller
78001-7141F	064423	Female LP Tank Fitting
78001-7141M	380001-010-01	Connector LPG Male 7141M
7B001-7141N	380001-010-01	Connector LPG Male 7141M

Nissan
Components

Nissan Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Nissan Continued

OE Number	Crown Part No.	Description
91H20-03330	380005-001-01	Starter H20-H20II-H25
CK1318727	380050-005	Bearing Cup
CK1318728	380050-006	Bearing Cone
CK1817083	794109-004	Bearing Assm
CK3779914	380012-011-02	Distributor Cap DC-20 4G32-52-54
CK715977	380001-010-01	Connector LPG Male 7141M
CK909353	380015-007-02	Rotor RT-10 4G32-52-54
CK913628	380013-012-02	Spark Plug L14-U
CK916006	380015-007-02	Rotor RT-10 4G32-52-54
CK923626	380012-007-02	Distributor Cap DC-19 4G63-4G64
CK923627	380015-001-02	Rotor RT-11 H20II
CK930768	380010-009-02	Belt-Fan 4G63-4G64
D700615	380006-003-02	Pump Water HER2.7-1404
MD169418	380012-009-02	Distributor B 4G63-4G64
MD171228	380005-004-01	Starter 4G63-4G64
MD320618	380005-004-01	Starter 4G63-4G64
MD611686	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611850	380015-007-02	Rotor RT-10 4G32-52-54
MD618364	380012-007-02	Distributor Cap DC-19 4G63-4G64
NF90420-01480	380015-009-02	Rotor RT-01 GM 6Cyl
NF90420-01620	380013-014-02	Spark Plug PT16EPR-L13
NF91865-13100	380001-001-01	Lockoff VFF-30-2-IMP
NF93165-03600	064423	Female LP Tank Fitting
NF93165-13110	380001-006-01	Repair Kit Cobra
NFF8140-30214	380050-004	Inner Bearing
NI16010-JBREG	380001-002-01	Converter JB2
NI23300-FU410	380005-008-02	Starter K21-K25
NYK (NY)		
30214	380050-004	Inner Bearing
41530214	380050-004	Inner Bearing
434035070	380050-004	Inner Bearing
F814030214	380050-004	Inner Bearing
Peugeot (PG)		
7141F	064423	Female LP Tank Fitting
7141M3	380001-011-02	Seal Ring Rubber 7141M3
C-971-3	064423	Female LP Tank Fitting
C-971-4	380001-010-01	Connector LPG Male 7141M
GO7141M	380001-010-01	Connector LPG Male 7141M
REGO7141F	064423	Female LP Tank Fitting
Plug OEM (PL)		
1Y00-18-110	380013-009-02	Spark Plug W16EPR-U
3322	380013-009-02	Spark Plug W16EPR-U
394	380013-001-02	Spark Plug W20ES-U
4056	380013-001-02	Spark Plug W20ES-U
4253	380013-006-02	Spark Plug W16EX-U
43N	380013-001-02	Spark Plug W20ES-U
43XL	380013-001-02	Spark Plug W20ES-U
44N	380013-001-02	Spark Plug W20ES-U
44NS	380013-006-02	Spark Plug W16EX-U
44XL	380013-001-02	Spark Plug W20ES-U
AG3	380013-001-02	Spark Plug W20ES-U
AG30C	380013-001-02	Spark Plug W20ES-U
AG3CX	380013-001-02	Spark Plug W20ES-U
AG3X	380013-001-02	Spark Plug W20ES-U
B2401-89904	380013-006-02	Spark Plug W16EX-U
B6ES	380013-001-02	Spark Plug W20ES-U
B6ES-11	380013-001-02	Spark Plug W20ES-U
BCP4ES	380013-002-02	Spark Plug Q14R-U11
BCP4ES11	380013-002-02	Spark Plug Q14R-U11
BCPR4ES11	380013-002-02	Spark Plug Q14R-U11
BCPR4EY11	380013-002-02	Spark Plug Q14R-U11
BP5EA-L	380013-006-02	Spark Plug W16EX-U
BP5EY	380013-006-02	Spark Plug W16EX-U
BPR2E	380013-005-02	Spark Plug W9EXR-U
BPR2ES	380013-005-02	Spark Plug W9EXR-U
BPR5E	380013-009-02	Spark Plug W16EPR-U

OE Number	Crown Part No.	Description
C43N	380013-001-02	Spark Plug W20ES-U
C44N	380013-001-02	Spark Plug W20ES-U
C44NS	380013-006-02	Spark Plug W16EX-U
CR425XLS	380013-009-02	Spark Plug W16EPR-U
CR43CXLS	380013-009-02	Spark Plug W16EPR-U
CR44NS	380013-009-02	Spark Plug W16EPR-U
DCPR4E7	380013-002-02	Spark Plug Q14R-U11
DCPR4ES	380013-002-02	Spark Plug Q14R-U11
DCPR4ES11	380013-002-02	Spark Plug Q14R-U11
DCPR4EY11	380013-002-02	Spark Plug Q14R-U11
FR9DCX	380013-002-02	Spark Plug Q14R-U11
MS851243	380013-006-02	Spark Plug W16EX-U
N11YC	380013-006-02	Spark Plug W16EX-U
N12YC	380013-006-02	Spark Plug W16EX-U
N288	380013-001-02	Spark Plug W20ES-U
N5C	380013-001-02	Spark Plug W20ES-U
ON11Y	380013-009-02	Spark Plug W16EPR-U
ON12Y	380013-009-02	Spark Plug W16EPR-U
R44LT	380013-009-02	Spark Plug W16EPR-U
RN11YCC	380013-009-02	Spark Plug W16EPR-U
RN12YCC	380013-009-02	Spark Plug W16EPR-U
RN14YC	380013-009-02	Spark Plug W16EPR-U
S43XL	380013-001-02	Spark Plug W20ES-U
S44XL	380013-001-02	Spark Plug W20ES-U
W16ES-U	380013-001-02	Spark Plug W20ES-U
W16EX-U	380013-006-02	Spark Plug W16EX-U
Prestolite (PL)		
110-460	380011-006-02	Alternator 4G52-4G54
14-4	380013-017-02	Spark Plug W16S-U
14-5	380013-017-02	Spark Plug W16S-U
14G22	380013-007-02	Spark Plug W9EP
14G82	380013-007-02	Spark Plug W9EP
14R8	380013-017-02	Spark Plug W16S-U
14RF42	380013-016-02	Spark Plug T14PR-U
14RF52	380013-016-02	Spark Plug T14PR-U
14RF62	380013-016-02	Spark Plug T14PR-U
18-10	380013-012-02	Spark Plug L14-U
18-4	380013-012-02	Spark Plug L14-U
18-8	380013-012-02	Spark Plug L14-U
18-9	380013-012-02	Spark Plug L14-U
8AR2200L	380011-006-02	Alternator 4G52-4G54
BM-15-1	380010-010-02	Belt-Fan 4Y 5-6 Series
7141M	380001-010-01	Connector LPG Male 7141M
Raymond (RA)		
1-164-912	380021-004-02	Brake Cylinder
1-164-915	380021-004-02	Brake Cylinder
447-098	380050-006	Bearing Cone
447-105	794109-004	Bearing Assm
447-562	380050-005	Bearing Cup
750	380021-004-02	Brake Cylinder
921-000-195	794109-004	Bearing Assm
990-253	380021-004-02	Brake Cylinder
DS223655	380050-006	Bearing Cone
DS223657	380050-005	Bearing Cup
Rego (RE)		
7141F	064423	Female LP Tank Fitting
7141M	380001-010-01	Connector LPG Male 7141M
RE7141M-3R	380001-011-02	Seal Ring Rubber 7141M3
Rotor Number (RN)		
J5-5610	380015-001-02	Rotor RT-11 H20II
J5-5611	380015-001-02	Rotor RT-11 H20II
J5-5612	380015-006-02	Rotor RT-13 TB42 6Cyl
J5-5613	380015-002-02	Rotor RT-07 4Y
J5-5614	380015-004-02	Rotor RT-03 F2-FE
J5-5615	380015-004-02	Rotor RT-03 F2-FE
J5-5620	380015-007-02	Rotor RT-10 4G32-52-54

(IC) Truck
 Components

(IC) Truck Components Cross Reference by Manufacturer

OE Number	Crown Part No.	Description
Samsung (SG)		
1318727	380050-005	Bearing Cup
1318728	380050-006	Bearing Cone
2383064	380011-006-02	Alternator 4G52-4G54
3779914	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611685	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD611686	380012-011-02	Distributor Cap DC-20 4G32-52-54
MD618364	380012-007-02	Distributor Cap DC-19 4G63-4G64
Still (SL)		
141231	380050-017	Roller
144483	380013-007-02	Spark Plug W9EP
145542	794109-004	Bearing Assm
149244	380010-004-02	Belt-Fan GM 3.0L
40955	380010-005-02	Belt-Fan K21-K25
5411744	380050-004	Inner Bearing
S200851	380050-007	Oil Seal
TCM (TC)		
02117-00511	380010-009-02	Belt-Fan H20II
03071-30214	380050-004	Inner Bearing
11720-B1101	380010-002-02	Belt-Fan H20
11720-L1102	380010-002-02	Belt-Fan H20
20801-04081	380010-005-02	Belt-Fan K21-K25
20801-04101	380010-009-02	Belt-Fan H20II
20801-04261	380010-002-02	Belt-Fan H20
20801-0A041	380013-007-02	Spark Plug W9EP
20801-0K041	380014-006-02	Plug Wire Set H20II
20801-0K042	380014-006-02	Plug Wire Set H20II
20801-0K052	380014-001-02	Plug Wire Set 4Y
20803-71151	380020-002-02	Brake Shoe Kit (2)
20803-71161	380020-002-02	Brake Shoe Kit (2)
212T1-05981	380008-002-02	Fan Blade 4Y 6-7 Series
212T1-06101	380012-003-02	Distributor I 4Y
212T1-06111	380012-004-02	Distributor Cap DC-6 4Y
212T1-06121	380015-002-02	Rotor RT-07 4Y
212T1-06941	380011-002-01	Alternator 4Y - GN81-41
212T1-07201	380005-002-01	Starter 4P-4Y-5R-5P
212T1-08551	380014-001-02	Plug Wire Set 4Y
212T1-09101	380010-010-02	Belt-Fan 4Y 5-6 Series
212T1-09451	380006-010-02	Pump Water 4Y 7 Series
22162-55K10	380012-001-02	Distributor Cap DC-10 H20II
22162-55K11	380012-001-02	Distributor Cap DC-10 H20II
22433-79901	380020-006-02	Brake Shoe Set (2)
22450-L1051	380014-008-02	Plug Wire Set H20
23100-M0413	380011-007-02	Alternator H20
23100-U0103	380011-007-02	Alternator H20
23300-00H10	380005-006-01	Starter H20
23300-K9160	380005-001-01	Starter H20-H20II-H25
53032-72601	380011-004-02	Alternator H20-P40-TB42
53032-72621	380010-002-02	Belt-Fan H20
53320-50401	380001-001-01	Lockoff VFF-30-2-IMP
53320-50501	380001-002-01	Converter JB2
7141M	380001-010-01	Connector LPG Male 7141M
C51M001507405	380020-005-02	Brake Pad (1)
CK21122083000	380020-006-02	Brake Shoe Set (2)
N-02117-00511	380010-009-02	Belt-Fan H20II
N-11720-B1101	380010-002-02	Belt-Fan H20
N-11720-K4080	380010-001-02	Belt-Fan H20II-H25
N-11720-K7201	380010-004-02	Belt-Fan GM 3.0L
N-11720-L1101	380010-002-02	Belt-Fan H20
N-11720-L1102	380010-002-02	Belt-Fan H20
N-11720-Y4400	380010-002-02	Belt-Fan H20
N-21010-50K26	380006-011-02	Pump Water H20II-H25
N-21010-50K28	380006-011-02	Pump Water H20II-H25
N-21010-L1100	380006-001-02	Pump Water H20 New Style
N-21010-L1125	380006-001-02	Pump Water H20 New Style

OE Number	Crown Part No.	Description
N-21010-L1126	380006-001-02	Pump Water H20 New Style
N-21060-48210	380008-004-02	Fan Blade H20
N-21060-50K00	380008-003-02	Fan Blade H20 II
N-21067-K7201	380010-004-02	Belt-Fan GM 3.0L
N-22020-10B10	380015-007-02	Rotor RT-10 4G32-52-54
N-22100-49207	380012-005-02	Distributor C H20
N-22100-50K10	380012-002-02	Distributor G H20II
N-22100-71306	380012-005-02	Distributor C H20
N-22100-71317	380012-005-02	Distributor C H20
N-22100-K7201	380012-005-02	Distributor C H20
N-22157-05M02	380015-008-02	Rotor H20
N-22157-10810	380015-007-02	Rotor RT-10 4G32-52-54
N-22157-10B10	380015-007-02	Rotor RT-10 4G32-52-54
N-22157-52H20	380015-006-02	Rotor RT-13 TB42 6Cyl
N-22157-55K10	380015-001-02	Rotor RT-11 H20II
N-22157-71300	380015-008-02	Rotor H20
N-22157-76500	380015-008-02	Rotor H20
N-22157-78500	380015-008-02	Rotor H20
N-22157-D1200	380015-008-02	Rotor H20
N-22157-H1000	380015-008-02	Rotor H20
N-22157-H1001	380015-008-02	Rotor H20
N-22157-R9006	380015-007-02	Rotor RT-10 4G32-52-54
N-22157-R9007	380015-007-02	Rotor RT-10 4G32-52-54
N-22162-23G15	380012-012-02	Distributor Cap H20II
N-22162-25G10	380012-011-02	Distributor Cap DC-20 4G32-52-54
N-22162-25G11	380012-011-02	Distributor Cap DC-20 4G32-52-54
N-22162-78A10	380012-012-02	Distributor Cap H20II
N-22162-G5710	380012-012-02	Distributor Cap H20II
N-22162-G5711	380012-012-02	Distributor Cap H20II
N-22162-R9006	380012-011-02	Distributor Cap DC-20 4G32-52-54
N-22162-R9007	380012-011-02	Distributor Cap DC-20 4G32-52-54
N-22401-L1600	380013-004-02	Spark Plug W14EXR-U
N-22401-W8914	380013-007-02	Spark Plug W9EP
N-22450-50K50	380014-006-02	Plug Wire Set H20II
N-23100-B9810	380011-004-02	Alternator H20-P40-TB42
N-23100-C6000	380011-007-02	Alternator H20
N-23100-FU410	380011-001-01	Alternator K21-K25
N-23100-M0413	380011-007-02	Alternator H20
N-23100-M0414	380011-007-02	Alternator H20
N-23100-U0100	380011-007-02	Alternator H20
N-23100-U0102	380011-007-02	Alternator H20
N-23100-U0103	380011-007-02	Alternator H20
N-23300-B9810	380011-004-02	Alternator H20-P40-TB42
N21060FU40A	380008-001-02	Fan Blade K21-K25
T-F829-18-V05	380015-004-02	Rotor RT-03 F2-FE
T-FE2S-18-V05	380015-004-02	Rotor RT-03 F2-FE
T-FEEN-18-V00	380012-006-02	Distributor Cap DC-11 F2-FE
TCN-23300-FU410	380005-008-02	Starter K21-K25
W9EP	380013-007-02	Spark Plug W9EP
Z-8-94144-301-0	380010-005-02	Belt-Fan K21-K25
Tennant (TN)		
07764	380013-008-02	Spark Plug T16PR-U
39046	380013-008-02	Spark Plug T16PR-U
Timken TM		
JLM104910	380050-005	Bearing Cup
JLM104948	380050-006	Bearing Cone
Toyota (TY)		
00590-00414-71	794109-004	Bearing Assm
00590-00909-71	380050-006	Bearing Cone
00590-00911	380050-005	Bearing Cup
00590-00911-71	380050-005	Bearing Cup
00591-00152-81	380014-008-02	Plug Wire Set H20
00591-00643-81	380050-005	Bearing Cup
00591-00644-81	380050-006	Bearing Cone

Toyota Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Toyota Continued

OE Number	Crown Part No.	Description
00591-01133-81	380014-008-02	Plug Wire Set H20
00591-02042-81	380013-004-02	Spark Plug W14EXR-U
00591-02732-81	380010-004-02	Belt-Fan GM 3.0L
00591-03628-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-03630-81	380015-007-02	Rotor RT-10 4G32-52-54
00591-05493-81	380013-017-02	Spark Plug W16S-U
00591-05705-81	380006-003-02	Pump Water HER2.7-1404
00591-06004-81	380012-006-02	Distributor Cap DC-11 F2-FE
00591-06005-81	380015-004-02	Rotor RT-03 F2-FE
00591-06008-81	380050-016	Roller
00591-06095-81	380010-004-02	Belt-Fan GM 3.0L
00591-06165-81	380013-008-02	Spark Plug T16PR-U
00591-06208-81	380013-007-02	Spark Plug W9EP
00591-06209-81	380013-007-02	Spark Plug W9EP
00591-06238-81	380010-002-02	Belt-Fan H20
00591-06240-81	380050-040	Ignition Switch
00591-06279-81	380050-004	Inner Bearing
00591-06286-81	380014-008-02	Plug Wire Set H20
00591-06324-81	380007-001-02	Muffler KO3EB-03-22110
00591-06467-81	380050-035	Bearing Mast
00591-07107-81	380010-004-02	Belt-Fan GM 3.0L
00591-07109-81	380010-002-02	Belt-Fan H20
00591-07192-81	380008-004-02	Fan Blade H20
00591-07207-81	380012-005-02	Distributor C H20
00591-07214-81	380015-008-02	Rotor H20
00591-07216-81	380012-012-02	Distributor Cap H20II
00591-07374-81	380050-033	Seal Oil Drive Axle
00591-07485-81	380050-020	Roller-Lift 94mm Dia
00591-07487-81	380050-019	Roller-Lift
00591-07632-81	064423	Female LP Tank Fitting
00591-07633-81	380001-010-01	Connector LPG Male 7141M
00591-07885-81	380013-012-02	Spark Plug L14-U
00591-07896-81	380013-012-02	Spark Plug L14-U
00591-07978-81	380006-001-02	Pump Water H20 New Style
00591-08089-81	380011-007-02	Alternator H20
00591-08206-81	380001-001-01	Lockoff VFF-30-2-IMP
00591-10723-81	380006-007-02	Pump Water 4Y 5-6 Series
00591-10752-81	380012-004-02	Distributor Cap DC-6 4Y
00591-10757-81	380015-002-02	Rotor RT-07 4Y
00591-10795-81	380011-002-01	Alternator 4Y - GN81-41
00591-10808-81	380023-001-02	Brake Pedal Cover
00591-10918-81	380013-008-02	Spark Plug T16PR-U
00591-10919-81	380013-017-02	Spark Plug W16S-U
00591-10954-81	380010-006-02	Belt-Fan 4G52-4G63
00591-10963-81	380010-006-02	Belt-Fan 4G52-4G63
00591-10965-81	380010-010-02	Belt-Fan 4Y 5-6 Series
00591-11046-81	380015-004-02	Rotor RT-03 F2-FE
00591-11105-81	380014-005-02	Plug Wire Set F2-FE
00591-11106-81	380012-008-02	Distributor DC-5 D5
00591-11157-81	064423	Female LP Tank Fitting
00591-14608-81	380001-006-01	Repair Kit Cobra
00591-14708-81	380001-005-01	Repair Kit JB2
00591-14711-81	380001-006-01	Repair Kit Cobra
00591-20174-81	380013-017-02	Spark Plug W16S-U
00591-20561-81	380050-011	Oil Seal
00591-20723-81	380015-006-02	Rotor RT-13 TB42 6Cyl
00591-21011-81	380006-011-02	Pump Water H20II-H25
00591-21035-81	380011-006-02	Alternator 4G52-4G54
00591-22382-81	380050-037	Packing Cylinder Kit
00591-22425-81	380010-008-02	Belt-Timing FE
00591-22426-81	380006-004-02	Pump Water FE
00591-23164-81	380015-001-02	Rotor RT-11 H20II
00591-23165-81	380012-001-02	Distributor Cap DC-10 H20II
00591-27353-81	380012-002-02	Distributor G H20II
00591-27362-81	380011-006-02	Alternator 4G52-4G54
00591-27394-81	380021-001-02	Brake Cylinder

OE Number	Crown Part No.	Description
00591-27426-81	380016-001-02	Coil A218371 MD358504 925969
00591-27429-81	380008-005-02	Fan Blade 4G63-4G64 K Series
00591-30316-81	380050-006	Bearing Cone
00591-30336-81	380050-035	Bearing Mast
00591-30424-81	380050-034	Bearing Mast
00591-31074-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-31680-81	380012-006-02	Distributor Cap DC-11 F2-FE
00591-31681-81	380015-004-02	Rotor RT-03 F2-FE
00591-31692-81	064423	Female LP Tank Fitting
00591-31696-81	380001-010-01	Connector LPG Male 7141M
00591-31700-81	380001-001-01	Lockoff VFF-30-2-IMP
00591-31734-81	380001-011-02	Seal Ring Rubber 7141M3
00591-31740-81	380001-011-02	Seal Ring Rubber 7141M3
00591-31813-81	380015-004-02	Rotor RT-03 F2-FE
00591-31814-81	380015-007-02	Rotor RT-10 4G32-52-54
00591-32069-81	380050-007	Oil Seal
00591-32092-81	380050-011	Oil Seal
00591-32300-81	380050-040	Ignition Switch
00591-32404-81	380050-037	Packing Cylinder Kit
00591-32407-81	380050-041	Packing Cylinder Kit
00591-32686-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-32687-81	380012-012-02	Distributor Cap H20II
00591-32688-81	380012-004-02	Distributor Cap DC-6 4Y
00591-32691-81	380013-012-02	Spark Plug L14-U
00591-32692-81	380013-008-02	Spark Plug T16PR-U
00591-32695-81	380013-007-02	Spark Plug W9EP
00591-32718-81	380012-005-02	Distributor C H20
00591-32723-81	380014-008-02	Plug Wire Set H20
00591-32887-81	380006-001-02	Pump Water H20 New Style
00591-32889-81	380006-007-02	Pump Water 4Y 5-6 Series
00591-32891-81	380006-004-02	Pump Water FE
00591-33124-81	380050-002	Inner Seal
00591-33553-81	380014-005-02	Plug Wire Set F2-FE
00591-33593-81	380014-005-02	Plug Wire Set FE
00591-33605-81	380014-006-02	Plug Wire Set H20II
00591-33616-81	380011-006-02	Alternator 4G52-4G54
00591-33617-81	380015-004-02	Rotor RT-03 F2-FE
00591-33646-81	380013-004-02	Spark Plug W14EXR-U
00591-33649-81	380013-007-02	Spark Plug W9EP
00591-33666-81	380012-006-02	Distributor Cap DC-11 F2-FE
00591-33685-81	380015-009-02	Rotor RT-01 GM 6Cyl
00591-33686-81	380015-004-02	Rotor RT-03 F2-FE
00591-33687-81	380013-017-02	Spark Plug W16S-U
00591-33703-81	380015-008-02	Rotor H20
00591-33710-81	380015-004-02	Rotor RT-03 F2-FE
00591-33739-81	380011-004-02	Alternator H20-P40-TB42
00591-33765-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-33766-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-33834-81	380010-002-02	Belt-Fan H20
00591-33843-81	380010-006-02	Belt-Fan 4G52-4G63
00591-33845-81	380010-004-02	Belt-Fan GM 3.0L
00591-33846-81	380010-002-02	Belt-Fan H20
00591-33850-81	380010-006-02	Belt-Fan 4G52-4G63
00591-33855-81	380010-006-02	Belt-Fan 4G52-4G63
00591-33863-81	380010-004-02	Belt-Fan GM 3.0L
00591-33868-81	380010-004-02	Belt-Fan GM 3.0L
00591-33874-81	380010-009-02	Belt-Fan H20II
00591-33876-81	380010-004-02	Belt-Fan GM 3.0L
00591-33877-81	380010-009-02	Belt-Fan 4G63-4G64
00591-33878-81	380010-004-02	Belt-Fan GM 3.0L
00591-33879-81	380010-009-02	Belt-Fan 4G63-4G64
00591-33880-81	380010-006-02	Belt-Fan 4G52-4G63
00591-34284-81	380006-011-02	Pump Water H20II-H25
00591-34296-81	380006-009-02	Pump Water VA
00591-34661-81	380010-008-02	Belt-Timing FE
00591-35270-81	380023-001-02	Brake Pedal Cover

Toyota Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Toyota Continued

OE Number	Crown Part No.	Description
00591-35379-81	380021-004-02	Brake Cylinder
00591-35435-81	380021-003-02	Brake Cylinder
00591-35528-81	380050-005	Bearing Cup
00591-35745-81	380050-004	Inner Bearing
00591-36864-81	380008-004-02	Fan Blade H20
00591-36868-81	380008-003-02	Fan Blade H20 II
00591-41351-81	380050-033	Seal Oil Drive Axle
00591-42783-81	380012-009-02	Distributor B 4G63-4G64
00591-42798-81	380012-002-02	Distributor G H20II
00591-42808-81	380013-008-02	Spark Plug T16PR-U
00591-42813-81	380010-006-02	Belt-Fan 4G52-4G63
00591-44714-81	380001-001-01	Lockoff VFF-30-2-IMP
00591-44723-81	380001-005-01	Repair Kit JB2
00591-45306-81	380050-039	Lift Cylinder O/H Kit
00591-50056-81	380011-002-01	Alternator 4Y - GN81-41
00591-50368-81	380015-007-02	Rotor RT-10 4G32-52-54
00591-50484-81	380006-001-02	Pump Water H20 New Style
00591-50757-81	380050-006	Bearing Cone
00591-50877-81	380050-035	Bearing Mast
00591-50970-81	380013-012-02	Spark Plug L14-U
00591-50971-81	380013-012-02	Spark Plug L14-U
00591-50973-81	380013-007-02	Spark Plug W9EP
00591-50976-81	380013-007-02	Spark Plug W9EP
00591-50978-81	380013-008-02	Spark Plug T16PR-U
00591-50979-81	380013-016-02	Spark Plug T14PR-U
00591-51007-81	380010-004-02	Belt-Fan GM 3.0L
00591-51008-81	380010-004-02	Belt-Fan GM 3.0L
00591-51009-81	380010-002-02	Belt-Fan H20
00591-51010-81	380010-002-02	Belt-Fan H20
00591-51011-81	380010-010-02	Belt-Fan 4Y 5-6 Series
00591-51014-81	380010-002-02	Belt-Fan H20
00591-51025-81	380010-006-02	Belt-Fan 4G52-4G63
00591-51028-81	380010-005-02	Belt-Fan K21-K25
00591-51083-81	064423	Female LP Tank Fitting
00591-51085-81	380001-010-01	Connector LPG Male 7141M
00591-51127-81	380001-011-02	Seal Ring Rubber 7141M3
00591-51137-81	380001-001-01	Lockoff VFF-30-2-IMP
00591-51220-81	380012-005-02	Distributor C H20
00591-51265-81	380050-040	Ignition Switch
00591-51412-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-51417-81	380012-012-02	Distributor Cap H20II
00591-51418-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-51420-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-51429-81	380015-008-02	Rotor H20
00591-52483-81	380050-011	Oil Seal
00591-52666-81	380050-034	Bearing Mast
00591-53127-81	380010-004-02	Belt-Fan GM 3.0L
00591-53193-81	380006-007-02	Pump Water 4Y 5-6 Series
00591-53200-81	380012-004-02	Distributor Cap DC-6 4Y
00591-53231-81	380023-001-02	Brake Pedal Cover
00591-53307-81	380013-012-02	Spark Plug L14-U
00591-53504-81	380010-008-02	Belt-Timing FE
00591-54104-81	380006-011-02	Pump Water H20II-H25
00591-54109-81	380006-009-02	Pump Water VA
00591-54141-81	380008-003-02	Fan Blade H20 II
00591-54549-81	380010-008-02	Belt-Timing FE
00591-54654-81	380050-033	Seal Oil Drive Axle
00591-54664-81	380050-002	Inner Seal
00591-54879-81	380050-005	Bearing Cup
00591-55310-81	380013-017-02	Spark Plug W16S-U
00591-55340-81	380010-009-02	Belt-Fan H20II
00591-55347-81	380010-004-02	Belt-Fan GM 3.0L
00591-55359-81	380010-009-02	Belt-Fan 4G63-4G64
00591-55374-81	380010-004-02	Belt-Fan GM 3.0L
00591-55375-81	380010-009-02	Belt-Fan 4G63-4G64
00591-55397-81	380010-002-02	Belt-Fan H20

OE Number	Crown Part No.	Description
00591-55972-81	380011-004-02	Alternator H20-P40-TB42
00591-56004-81	380014-008-02	Plug Wire Set H20
00591-56029-81	380014-005-02	Plug Wire Set FE
00591-56038-81	380014-006-02	Plug Wire Set H20II
00591-56299-81	380012-006-02	Distributor Cap DC-11 F2-FE
00591-56301-81	380012-011-02	Distributor Cap DC-20 4G32-52-54
00591-56303-81	380012-006-02	Distributor Cap DC-11 F2-FE
00591-56318-81	380015-004-02	Rotor RT-03 F2-FE
00591-56319-81	380015-004-02	Rotor RT-03 F2-FE
00591-56321-81	380015-004-02	Rotor RT-03 F2-FE
00591-56322-81	380015-009-02	Rotor RT-01 GM 6Cyl
00591-58010-81	380021-004-02	Brake Cylinder
00591-58023-81	380021-003-02	Brake Cylinder
00591-60402-81	380050-007	Oil Seal
00591-60962-81	380050-037	Packing Cylinder Kit
00591-60963-81	380050-041	Packing Cylinder Kit
00591-61180-81	380006-004-02	Pump Water FE
00591-61181-81	380014-005-02	Plug Wire Set F2-FE
00591-61205-81	380050-004	Inner Bearing
00591-63393-81	380015-002-02	Rotor RT-07 4Y
00591-64562-81	380001-005-01	Repair Kit JB2
00591-71480-81	380050-002	Inner Seal
00591-74115-81	380010-009-02	Belt-Fan 4G63-4G64
00591-74817-81	380010-009-02	Belt-Fan 4G63-4G64
00591-75169-81	380010-006-02	Belt-Fan 4G52-4G63
00591-75236-81	380012-007-02	Distributor Cap DC-19 4G63-4G64
00591-75559-81	380010-001-02	Belt-Fan H20II-H25
00591-76004-81	794109-004	Bearing Assm
00591-76586-81	380050-038	Lift Cylinder O/H Kit
00591-76611-81	380014-005-02	Plug Wire Set FE
00591-76642-81	380050-041	Packing Cylinder Kit
00591-76827-81	380050-034	Bearing Mast
00591-76873-81	380050-002	Inner Seal
04255-U201171	380001-005-01	Repair Kit JB2
04421-27010	794109-004	Bearing Assm
04421-27050	794109-004	Bearing Assm
04421-30010	794109-004	Bearing Assm
04421-30011	794109-004	Bearing Assm
04421-30012	794109-004	Bearing Assm
16100-U2120-71	380006-006-02	Pump Water GM 3.0L
16110-78156-71	380006-010-02	Pump Water 4Y 7 Series
16120-78151-71	380006-007-02	Pump Water 4Y 5-6 Series
16120-96151-71	380006-007-02	Pump Water 4Y 5-6 Series
16361-23860-71	380008-002-02	Fan Blade 4Y 6-7 Series
16363-32870-71	380010-006-02	Belt-Fan 4G52-4G63
16371-20100-71	380010-006-02	Belt-Fan 4G52-4G63
16371-76001-71	380010-006-02	Belt-Fan 4G52-4G63
16371-76002-71	380010-006-02	Belt-Fan 4G52-4G63
16371-76011-71	380010-006-02	Belt-Fan 4G52-4G63
16371-76014-71	380010-006-02	Belt-Fan 4G52-4G63
16372-13010-71	380010-005-02	Belt-Fan K21-K25
16410-23010-71	380009-005-02	Radiator
16410-23070-71	380009-005-02	Radiator
16410-F1100-71	380009-002-02	Radiator
16410-U2000-71	380009-005-02	Radiator
16410-U2200-71	380009-002-02	Radiator
16410-U2201-71	380009-002-02	Radiator
19030-78150-71	380012-003-02	Distributor I 4Y
19030-78151-71	380012-003-02	Distributor I 4Y
19030-78154-71	380012-003-02	Distributor I 4Y
19030-96150	380012-003-02	Distributor I 4Y
19101-71010-71	380012-004-02	Distributor Cap DC-6 4Y
19101-76007-71	380012-004-02	Distributor Cap DC-6 4Y
19101-76013-71	380012-004-02	Distributor Cap DC-6 4Y
19102-16020	380015-002-02	Rotor RT-07 4Y
19102-16040	380015-002-02	Rotor RT-07 4Y

**(IC) Truck
Components**

Toyota Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Toyota Continued

OE Number	Crown Part No.	Description
19102-31720-71	380015-009-02	Rotor RT-01 GM 6Cyl
19102-33010-71	380015-002-02	Rotor RT-07 4Y
19102-63010-71	380015-002-02	Rotor RT-07 4Y
19102-73020	380015-002-02	Rotor RT-07 4Y
19102-73021	380015-002-02	Rotor RT-07 4Y
19102-73180	380015-002-02	Rotor RT-07 4Y
19102-76007-71	380015-002-02	Rotor RT-07 4Y
19102-76009-71	380015-002-02	Rotor RT-07 4Y
19102-76013-71	380015-002-02	Rotor RT-07 4Y
19102-U3160-71	380015-009-02	Rotor RT-01 GM 6Cyl
19111-31720-71	380013-014-02	Spark Plug PT16EPR-L13
19111-31721-71	380013-014-02	Spark Plug PT16EPR-L13
19111-90098-71	380013-014-02	Spark Plug PT16EPR-L13
19111-U2120-71	380013-016-02	Spark Plug T14PR-U
19111-U3161-71	380013-014-02	Spark Plug PT16EPR-L13
19335-U2120-71	380014-007-02	Plug Wire Set GM 3.0L
23530-2280071	380001-002-01	Converter JB2
23530-U1100-71	380001-008-01	Regulator LPG
23530-U1101-71	380001-008-01	Regulator LPG
23530-U1102-71	380001-008-01	Regulator LPG
23530-U1103-71	380001-008-01	Regulator LPG
23530-U1104-71	380001-008-01	Regulator LPG
23560-U2100-71	064423	Female LP Tank Fitting
23560-U2101-71	064423	Female LP Tank Fitting
23640-U2000-71	380001-001-01	Lockoff VFF-30-2-IMP
27060-78003-71	380011-002-01	Alternator 4Y - GN81-41
27060-78153-71	380011-003-02	Alternator 4Y
27060-78156-71	380011-003-02	Alternator 4Y
27060-78158-71	380011-003-02	Alternator 4Y
28100-20553	380005-002-01	Starter 4P-4Y-5R-5P
28100-20553-71	380005-002-01	Starter 4P-4Y-5R-5P
28300-22003	380005-002-01	Starter 4P-4Y-5R-5P
31319-20540-71	380023-001-02	Brake Pedal Cover
31319-22000-71	380023-001-02	Brake Pedal Cover
31319-23000-71	380023-001-02	Brake Pedal Cover
43815-31620-71	380050-003	Outer Bearing
47117-1224071	380020-005-02	Brake Pad (1)
47403-12810-71	380020-007-02	Brake Shoe Kit (4)
47403-16600-71	380020-007-02	Brake Shoe Kit (4)
47404-12620-71	380020-007-02	Brake Shoe Kit (4)
47404-12810-71	380020-007-02	Brake Shoe Kit (4)
47404-13300-71	380020-007-02	Brake Shoe Kit (4)
47405-12620-71	380020-007-02	Brake Shoe Kit (4)
47405-12810-71	380020-007-02	Brake Shoe Kit (4)
47405-13000-71	380020-007-02	Brake Shoe Kit (4)
47405-13300-71	380020-007-02	Brake Shoe Kit (4)
47405-1660071	380020-007-02	Brake Shoe Kit (4)
47406-13000-71	380020-007-02	Brake Shoe Kit (4)
47503-3386071	380020-004-02	Brake Shoe (1)
47504-3386071	380020-004-02	Brake Shoe (1)
47505-1300071	380020-007-02	Brake Shoe Kit (4)
47505-3386071	380020-004-02	Brake Shoe (1)
47506-1300071	380020-007-02	Brake Shoe Kit (4)
47510-U113071	380020-002-02	Brake Shoe Kit (2)
47512-3306071	380020-004-02	Brake Shoe (1)
47513-3306071	380020-004-02	Brake Shoe (1)
47514-3306071	380020-004-02	Brake Shoe (1)
47520-U113071	380020-002-02	Brake Shoe Kit (2)
47530-42100-71	380021-004-02	Brake Cylinder
5910015281	380014-008-02	Plug Wire Set H20
5910113381	380014-008-02	Plug Wire Set H20
5910628681	380014-008-02	Plug Wire Set H20
5915600481	380014-008-02	Plug Wire Set H20
80098-76004-71	380013-017-02	Spark Plug W16S-U
80098-76005-71	380013-017-02	Spark Plug W16S-U
80098-76006-71	380013-007-02	Spark Plug W9EP
80919-76004-71	380013-007-02	Spark Plug W9EP

OE Number	Crown Part No.	Description
80919-76005-71	380013-007-02	Spark Plug W9EP
80919-76008-71	380013-007-02	Spark Plug W9EP
80919-76009-71	380013-007-02	Spark Plug W9EP
80919-76011-71	380013-007-02	Spark Plug W9EP
80919-76102-71	380014-001-02	Plug Wire Set 4Y
80919-76106-71	380014-001-02	Plug Wire Set 4Y
80999-76018-71	380013-007-02	Spark Plug W9EP
89322-76007-71	380010-006-02	Belt-Fan 4G52-4G63
90098-09125	380013-007-02	Spark Plug W9EP
90098-14785	380013-016-02	Spark Plug T14PR-U
90098-16785	380013-008-02	Spark Plug T16PR-U
90098-20395	380013-007-02	Spark Plug W9EP
90098-64015	380013-014-02	Spark Plug L14-U
90098-66113-71	380013-014-02	Spark Plug PT16EPR-L13
90369-35003	794109-004	Bearing Assm
90420-01190-71	380013-014-02	Spark Plug PT16EPR-L13
90916-02952-71	380010-010-02	Belt-Fan 4Y 5-6 Series
90916-02975-71	380010-003-02	Belt-Fan 4Y 7 Series
90916-02976-71	380010-005-02	Belt-Fan K21-K25
90919-01021	380013-007-02	Spark Plug W9EP
90919-01055-71	380013-007-02	Spark Plug W9EP
90919-01950-71	380013-007-02	Spark Plug W9EP
90919-01954	380013-006-02	Spark Plug W16EX-U
90919-01954-71	380013-005-02	Spark Plug W9EXR-U
90919-22132	380014-001-02	Plug Wire Set 4Y
90928-29006-71	380005-002-01	Starter 4P-4Y-5R-5P
90999-09001-71	380013-007-02	Spark Plug W9EP
90999-09002-71	380013-007-02	Spark Plug W9EP
97600-32011-71	794109-004	Bearing Assm
99312-01035	380010-006-02	Belt-Fan 4G52-4G63
99312-01065	380010-006-02	Belt-Fan 4G52-4G63
99512-11039	380010-006-02	Belt-Fan 4G52-4G63
99512-11068	380010-006-02	Belt-Fan 4G52-4G63
Uniroyal (UN)		
13405	380010-002-02	Belt-Fan H20
15405	380010-002-02	Belt-Fan H20
17420	380010-006-02	Belt-Fan 4G52-4G63
17460	380010-010-02	Belt-Fan 4Y 5-6 Series
V-Belts (VB)		
12.5X1200	380010-005-02	Belt-Fan K21-K25
12.7X1250	380010-005-02	Belt-Fan K21-K25
1251150	380010-010-02	Belt-Fan 4Y 5-6 Series
1251212	380010-005-02	Belt-Fan K21-K25
13365	380010-004-02	Belt-Fan GM 3.0L
13371	380010-004-02	Belt-Fan GM 3.0L
13375	380010-004-02	Belt-Fan GM 3.0L
13391	380010-002-02	Belt-Fan H20
13395	380010-002-02	Belt-Fan H20
13401	380010-002-02	Belt-Fan H20
13411	380010-002-02	Belt-Fan H20
13415	380010-002-02	Belt-Fan H20
13421	380010-002-02	Belt-Fan H20
13461	380010-010-02	Belt-Fan 4Y 5-6 Series
13465	380010-010-02	Belt-Fan 4Y 5-6 Series
13471	380010-010-02	Belt-Fan 4Y 5-6 Series
13496	380010-002-02	Belt-Fan H20
13499	380010-002-02	Belt-Fan H20
13502	380010-002-02	Belt-Fan H20
1697	380010-010-02	Belt-Fan 4Y 5-6 Series
17415	380010-006-02	Belt-Fan 4G52-4G63
17421	380010-006-02	Belt-Fan 4G52-4G63
17480	380010-005-02	Belt-Fan K21-K25
17481	380010-005-02	Belt-Fan K21-K25
17484	380010-005-02	Belt-Fan K21-K25
17491	380010-005-02	Belt-Fan K21-K25
1845	380010-002-02	Belt-Fan H20
1853	380010-002-02	Belt-Fan H20

IC) Truck Components

(IC) Truck Components Cross Reference by Manufacturer

V-Belts Continued

OE Number	Crown Part No.	Description
21-W	380010-006-02	Belt-Fan 4G52-4G63
27-W	380010-004-02	Belt-Fan GM 3.0L
41-W	380010-002-02	Belt-Fan H20
4637	380010-010-02	Belt-Fan 4Y 5-6 Series
5106	380010-002-02	Belt-Fan H20
7417	380010-002-02	Belt-Fan H20
7465	380010-010-02	Belt-Fan 4Y 5-6 Series
7495	380010-002-02	Belt-Fan H20
8216	380010-002-02	Belt-Fan H20
8222	380010-010-02	Belt-Fan 4Y 5-6 Series
8223	380010-010-02	Belt-Fan 4Y 5-6 Series
8227	380010-002-02	Belt-Fan H20
8300	380010-006-02	Belt-Fan 4G52-4G63
8361	380010-004-02	Belt-Fan GM 3.0L
8467	380010-006-02	Belt-Fan 4G52-4G63
8771	380010-002-02	Belt-Fan H20
9.5X1175	380010-010-02	Belt-Fan 4Y 5-6 Series
9.5X1250	380010-005-02	Belt-Fan K21-K25
9.5X1275	380010-002-02	Belt-Fan H20
9481	380010-002-02	Belt-Fan H20
9490	380010-005-02	Belt-Fan K21-K25
951162	380010-010-02	Belt-Fan 4Y 5-6 Series
951250	380010-002-02	Belt-Fan H20
95905	380010-004-02	Belt-Fan GM 3.0L
95925	380010-004-02	Belt-Fan GM 3.0L
95962	380010-009-02	Belt-Fan H20II
95985	380010-009-02	Belt-Fan 4G63-4G64
9813	380010-002-02	Belt-Fan H20
B-13371	380010-004-02	Belt-Fan GM 3.0L
B-13395	380010-002-02	Belt-Fan H20
B-13415	380010-002-02	Belt-Fan H20
B-13465-A	380010-010-02	Belt-Fan 4Y 5-6 Series
B-13502	380010-002-02	Belt-Fan H20
B-17484-A	380010-005-02	Belt-Fan K21-K25
JA-415-R	380010-002-02	Belt-Fan H20
JA-502-R	380010-002-02	Belt-Fan H20
JC-415-R	380010-006-02	Belt-Fan 4G52-4G63
JC-483	380010-005-02	Belt-Fan K21-K25
N-7365	380010-004-02	Belt-Fan GM 3.0L
N-7370	380010-004-02	Belt-Fan GM 3.0L
N-7390	380010-002-02	Belt-Fan H20
N-7395	380010-002-02	Belt-Fan H20
N-7400	380010-002-02	Belt-Fan H20
N-7410	380010-002-02	Belt-Fan H20
N-7414	380010-002-02	Belt-Fan H20
N-7460	380010-010-02	Belt-Fan 4Y 5-6 Series
N-7470	380010-010-02	Belt-Fan 4Y 5-6 Series
N-7500	380010-002-02	Belt-Fan H20
N-9415	380010-006-02	Belt-Fan 4G52-4G63
N-9420	380010-006-02	Belt-Fan 4G52-4G63
N-9480	380010-005-02	Belt-Fan K21-K25
V-5034	380010-004-02	Belt-Fan GM 3.0L
V-5048	380010-002-02	Belt-Fan H20
V-5546	380010-005-02	Belt-Fan K21-K25
110532	380013-012-02	Spark Plug L14-U
209316	380013-012-02	Spark Plug L14-U
White Mobilift (WM)		
10-R-385	380013-012-02	Spark Plug L14-U
10A16423	380010-010-02	Belt-Fan 4Y 5-6 Series
10R1191	380013-012-02	Spark Plug L14-U
20-7000680	380013-012-02	Spark Plug L14-U
20-7000681	380013-012-02	Spark Plug L14-U
20-7000949	380013-012-02	Spark Plug L14-U
20-7100035	380013-012-02	Spark Plug L14-U
35A9481	380001-010-01	Connector LPG Male 7141M
35A9482	064423	Female LP Tank Fitting

OE Number	Crown Part No.	Description
35P517	380001-010-01	Connector LPG Male 7141M
35P519	064423	Female LP Tank Fitting
Yale (YT)		
016254800	380013-012-02	Spark Plug L14-U
016255000	380013-012-02	Spark Plug L14-U
016255100	380013-012-02	Spark Plug L14-U
031314500	380013-012-02	Spark Plug L14-U
063194200	380013-012-02	Spark Plug L14-U
067048100	380010-002-02	Belt-Fan H20
132614401	380050-006	Bearing Cone
132614402	380050-005	Bearing Cup
136350101	380001-010-01	Connector LPG Male 7141M
136350102	064423	Female LP Tank Fitting
1500132-07	380020-003-02	Brake Shoe Kit (2)
150014500	380011-004-02	Alternator H20-P40-TB42
150015100	380013-012-02	Spark Plug L14-U
150022504	380011-004-02	Alternator H20-P40-TB42
150022510	380015-004-02	Rotor RT-03 F2-FE
150022511	380012-006-02	Distributor Cap DC-11 F2-FE
150031100	380050-035	Bearing Mast
150038500	380013-007-02	Spark Plug W9EP
150112405	380013-012-02	Spark Plug L14-U
150112406	380013-012-02	Spark Plug L14-U
150112407	380013-012-02	Spark Plug L14-U
150112408	380013-012-02	Spark Plug L14-U
150112409	380013-012-02	Spark Plug L14-U
150112410	380013-012-02	Spark Plug L14-U
150112411	380013-012-02	Spark Plug L14-U
150112413	380013-012-02	Spark Plug L14-U
150112420	380013-012-02	Spark Plug L14-U
150112427	380013-012-02	Spark Plug L14-U
150112453	380013-008-02	Spark Plug T16PR-U
150112466	380013-004-02	Spark Plug W14EXR-U
150112473	380013-017-02	Spark Plug W16S-U
150112490	380013-017-02	Spark Plug W16S-U
220000727	380012-011-02	Distributor Cap DC-20 4G32-52-54
220000750	380015-007-02	Rotor RT-10 4G32-52-54
220001588	380010-010-02	Belt-Fan 4Y 5-6 Series
220001599	380013-007-02	Spark Plug W9EP
220002518	380010-004-02	Belt-Fan GM 3.0L
220002521	380010-009-02	Belt-Fan H20II
220003423	380050-040	Ignition Switch
220004289	380023-001-02	Brake Pedal Cover
220004547	380012-004-02	Distributor Cap DC-6 4Y
220005010	380011-006-02	Alternator 4G52-4G54
220007160	380006-003-02	Pump Water HER2.7-1404
220007409	380006-009-02	Pump Water VA
220007428	380013-012-02	Spark Plug L14-U
220007606	380006-001-02	Pump Water H20 New Style
220010746	380006-007-02	Pump Water 4Y 5-6 Series
220010987	380013-012-02	Spark Plug L14-U
220011080	380013-012-02	Spark Plug L14-U
220011107	380013-012-02	Spark Plug L14-U
220011118	380010-005-02	Belt-Fan K21-K25
220011205	380013-012-02	Spark Plug L14-U
220011358	794109-004	Bearing Assm
220012748	380012-012-02	Distributor Cap H20II
220012921	380012-011-02	Distributor Cap DC-20 4G32-52-54
220013371	380013-016-02	Spark Plug T14PR-U
220014644	064423	Female LP Tank Fitting
220015777	380050-004	Inner Bearing
220016206	380050-035	Bearing Mast
220016273	380012-011-02	Distributor Cap DC-20 4G32-52-54
220018323	380015-006-02	Rotor RT-13 TB42 6Cyl
220019999	380050-003	Outer Bearing
220020015	380012-006-02	Distributor Cap DC-11 F2-FE

**(IC) Truck
Components**

Yale Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Yale Continued

OE Number	Crown Part No.	Description
220020044	380050-002	Inner Seal
220021100	380050-037	Packing Cylinder Kit
220021877	380050-041	Packing Cylinder Kit
220022013	380012-007-02	Distributor Cap DC-19 4G63-4G64
220023796	380050-004	Inner Bearing
220024204	380012-005-02	Distributor C H20
220024209	380012-012-02	Distributor Cap H20II
220025194	380012-005-02	Distributor C H20
220025671	380015-001-02	Rotor RT-11 H20II
220027712	380050-004	Inner Bearing
220029615	380050-007	Oil Seal
220034034	380050-034	Bearing Mast
220034759	380008-002-02	Fan Blade 4Y 6-7 Series
220035887	380050-035	Bearing Mast
220036635	380050-003	Outer Bearing
220037503	380050-011	Oil Seal
220037522	380021-003-02	Brake Cylinder
220037756	380050-039	Lift Cylinder O/H Kit
220042179	380011-002-01	Alternator 4Y - GN81-41
220042751	380010-009-02	Belt-Fan 4G63-4G64
220043902	380012-007-02	Distributor Cap DC-19 4G63-4G64
220044332	380005-005-02	Starter GM 3.0L
220050482	064423	Female LP Tank Fitting
220050483	380001-010-01	Connector LPG Male 7141M
220051134	380050-006	Bearing Cone
220051135	380050-005	Bearing Cup
220052043	380010-005-02	Belt-Fan K21-K25
220052061	380010-004-02	Belt-Fan GM 3.0L
220052160	380050-004	Inner Bearing
220052206	380013-012-02	Spark Plug L14-U
220052533	380015-008-02	Rotor H20
220054038	380012-011-02	Distributor Cap DC-20 4G32-52-54
220054163	380050-033	Seal Oil Drive Axle
220054193	380012-011-02	Distributor Cap DC-20 4G32-52-54
220070181	380006-009-02	Pump Water VA
220070292	380012-012-02	Distributor Cap H20II
220070293	380015-004-02	Rotor RT-03 F2-FE
220070685	380050-020	Roller-Lift 94mm Dia
220070718	380050-019	Roller-Lift
220072690	380050-016	Roller
220075001	380050-007	Oil Seal
220075023	380050-011	Oil Seal
220075153	794109-004	Bearing Assm
220079608	380006-004-02	Pump Water FE
220100562	380014-005-02	Plug Wire Set F2-FE
220100725	380010-008-02	Belt-Timing FE
251102100	064423	Female LP Tank Fitting
253851100	380050-035	Bearing Mast
258086900	380050-004	Inner Bearing
277154700	794109-004	Bearing Assm
295675600	380010-005-02	Belt-Fan K21-K25
295675700	380010-005-02	Belt-Fan K21-K25
440050757	380010-002-02	Belt-Fan H20
440053117	380010-005-02	Belt-Fan K21-K25
440065120	794109-004	Bearing Assm
449058030	380050-004	Inner Bearing
449058034	380050-003	Outer Bearing
449089003	380010-010-02	Belt-Fan 4Y 5-6 Series
449089051	380010-005-02	Belt-Fan K21-K25
502029902	380050-006	Bearing Cone
502029903	380050-005	Bearing Cup
502029910	794109-004	Bearing Assm
502070916	380010-002-02	Belt-Fan H20
502105904	380010-002-02	Belt-Fan H20
502276300	380050-035	Bearing Mast
502276301	380050-035	Bearing Mast
502276302	380050-035	Bearing Mast

OE Number	Crown Part No.	Description
502276303	380050-035	Bearing Mast
502277301	380050-035	Bearing Mast
502277302	380050-035	Bearing Mast
503536215	380050-006	Bearing Cone
503536216	380050-005	Bearing Cup
503536245	380050-004	Inner Bearing
503536246	380050-003	Outer Bearing
503536248	380050-035	Bearing Mast
504117200	380050-035	Bearing Mast
504224218	380050-007	Oil Seal
504224242	380050-011	Oil Seal
504240838	380050-040	Ignition Switch
504240854	380050-040	Ignition Switch
505136027	380050-039	Lift Cylinder O/H Kit
505136031	380050-038	Lift Cylinder O/H Kit
5059595-61	380020-003-02	Brake Shoe Kit (2)
505959551	380001-003-01	Converter Cobra
5059605-35	380013-005-02	Spark Plug W9EXR-U
5059605-79	380006-004-02	Pump Water FE
505960556	380012-006-02	Distributor Cap DC-11 F2-FE
505960560	380011-005-01	Alternator D5-F2-FE
505960565	380015-004-02	Rotor RT-03 F2-FE
505960583	380012-006-02	Distributor Cap DC-11 F2-FE
5059635-91	380020-006-02	Brake Shoe Set (2)
505963537	380021-003-02	Brake Cylinder
505966505	064423	Female LP Tank Fitting
505966558	380001-001-01	Lockoff VFF-30-2-IMP
5059725-63	380009-102	Radiator Cap
505976593	380014-005-02	Plug Wire Set FE
506149006	380050-041	Packing Cylinder Kit
507033500	380050-035	Bearing Mast
508801800	380050-035	Bearing Mast
509295802	380013-012-02	Spark Plug L14-U
510764800	380013-012-02	Spark Plug L14-U
513375800	380050-035	Bearing Mast
516149005	380050-037	Packing Cylinder Kit
516149006	380050-041	Packing Cylinder Kit
516484800	380013-008-02	Spark Plug T16PR-U
5170798-00	380001-002-01	Converter JB2
517080800I	380001-005-01	Repair Kit JB2
517451800	380013-012-02	Spark Plug L14-U
518807650	380001-006-01	Repair Kit Cobra
519244814	794109-004	Bearing Assm
520002399	380001-003-01	Converter Cobra
520035885	380001-010-01	Connector LPG Male 7141M
520037830	380001-003-01	Converter Cobra
520045369	380050-016	Roller
522375008	380050-038	Lift Cylinder O/H Kit
524248308	380020-008-02-L	Shoe, Left Hand
524248309	380020-008-02-R	Shoe, Right Hand
54966300	064423	Female LP Tank Fitting
54966400	380001-010-01	Connector LPG Male 7141M
580000049	380005-005-02	Starter GM 3.0L
580000384	380015-009-02	Rotor RT-01 GM 6Cyl
580000628	380013-016-02	Spark Plug T14PR-U
580000728	380010-002-02	Belt-Fan H20
580000737	380010-004-02	Belt-Fan GM 3.0L
5800009-90	380011-005-01	Alternator D5-F2-FE
580002210	380005-005-02	Starter GM 3.0L
580002388	380001-003-01	Converter Cobra
580002399	380001-003-01	Converter Cobra
580002467	380010-004-02	Belt-Fan GM 3.0L
580005036	380013-008-02	Spark Plug T16PR-U
580007732	380001-006-01	Repair Kit Cobra
580007799	380050-040	Ignition Switch
580008972	380013-008-02	Spark Plug T16PR-U
580010475	380050-006	Bearing Cone

Yale Continued ▶

(IC) Truck Components Cross Reference by Manufacturer

Yale Continued

OE Number	Crown Part No.	Description
580010479	380050-006	Bearing Cone
580013445	380013-008-02	Spark Plug T16PR-U
580014183	380010-005-02	Belt-Fan K21-K25
580015831	380010-005-02	Belt-Fan K21-K25
580019725	380005-005-02	Starter GM 3.0L
580021375	380050-040	Ignition Switch
580022227	380050-040	Ignition Switch
580026829	380011-005-01	Alternator D5-F2-FE
5800326-88	380020-006-02	Brake Shoe Set (2)
580035882	380010-004-02	Belt-Fan GM 3.0L
580035883	380010-002-02	Belt-Fan H20
580036620	794109-004	Bearing Assm
5800442-22	380009-101	Upper Hose
5800442-23	380009-100	Lower Hose
5800448-85	380005-009-02	Starter
580047018	380012-007-02	Distributor Cap DC-23 FE-F2
580047019	380015-005-02	Rotor RT-17 FE-FE2
5800513-32	380020-008-02-L	Shoe, Left Hand
5800513-33	380020-008-02-R	Shoe, Right Hand
5800569-45	380009-103	Thermostat
64926500	380001-011-02	Seal Ring Rubber 7141M3
900005266	380015-009-02	Rotor RT-01 GM 6Cyl
900015293	380013-014-02	Spark Plug PT16EPR-L13
900534806	380010-005-02	Belt-Fan K21-K25
900537827	380013-007-02	Spark Plug W9EP
900539818	380010-006-02	Belt-Fan 4G52-4G63
900890817	380010-006-02	Belt-Fan 4G52-4G63
900969823I	380001-005-01	Repair Kit JB2
901283805	380014-005-02	Plug Wire Set F2-FE
901284807	380012-011-02	Distributor Cap DC-20 4G32-52-54
901284808	380015-007-02	Rotor RT-10 4G32-52-54
901285801	380011-004-02	Alternator H20-P40-TB42
9012948-29	380010-008-02	Belt-Timing FE
901294816	380010-008-02	Belt-Timing FE
901302802	380006-004-02	Pump Water FE
901303803	380014-005-02	Plug Wire Set F2-FE

OE Number	Crown Part No.	Description
901304806	380012-011-02	Distributor Cap DC-20 4G32-52-54
901356802	380012-008-02	Distributor DC-5 D5
901356803	380015-004-02	Rotor RT-03 F2-FE
901356814	380015-004-02	Rotor RT-03 F2-FE
901357802	380012-006-02	Distributor Cap DC-11 F2-FE
901357803	380015-004-02	Rotor RT-03 F2-FE
901580802	380012-006-02	Distributor Cap DC-11 F2-FE
901580812	380012-006-02	Distributor Cap DC-11 F2-FE
901948801	380011-005-01	Alternator D5-F2-FE
901953805	380015-004-02	Rotor RT-03 F2-FE
902057822	380001-006-01	Repair Kit Cobra
902057825	380001-006-01	Repair Kit Cobra
902057827	380001-006-01	Repair Kit Cobra
904515101	380050-035	Bearing Mast
904515102	380050-035	Bearing Mast
904990600	380001-001-01	Lockoff VFF-30-2-IMP
905148300	380050-003	Outer Bearing
906197100	380050-003	Outer Bearing
907595300	380050-034	Bearing Mast
907595301	380050-034	Bearing Mast
909932403	380050-004	Inner Bearing
909932404	380050-003	Outer Bearing
911086300	380050-002	Inner Seal
912514300	064423	Female LP Tank Fitting
913987301	380050-034	Bearing Mast
913987302	380050-034	Bearing Mast
918139600	380005-003-01	Starter VA-F2-FE
9182593-00	380020-006-02	Brake Shoe Set (2)
920803300	380050-002	Inner Seal
924088300	380001-006-01	Repair Kit Cobra
9301324-00	380020-006-02	Brake Shoe Set (2)
950517913	380050-004	Inner Bearing
Yamaha (YM)		
25132-004600	380010-005-02	Belt-Fan K21-K25
YA901303803	380014-005-02	Plug Wire Set F2-FE

(IC) Truck Components

Propane Tanks



Steel Tanks

Part Number	Weight kg/lb	LPG Capacity l/gal	Cylinder Diameter mm/in	Cylinder Height mm/in
340012-005	9.0/20.0	17.8/4.7	310/12.2	486/19.2
340012-008	15.2/33.5	29.9/7.9	310/12.2	692/27.3
340012-010	19.7/43.5	38.6/10.2	310/12.2	845/33.3

Tanks include: Quick fill valve, sight gauge, quick coupler, safety relief and fixed liquid level splitter.

Note: Dimensions and capacities are approximate and may vary slightly.



Aluminum Tanks

Part Number	Weight kg/lb	LPG Capacity l/gal	Cylinder Diameter mm/in	Cylinder Height mm/in
340013-005	9.0/20.0	17.8/4.7	312/12.3	486/19.2
340013-008	15.2/33.5	29.9/7.9	312/12.3	692/27.3
340013-010	19.7/43.5	38.6/10.2	312/12.3	845/33.3

Tanks include: Quick fill valve, sight gauge, quick coupler, safety relief and fixed liquid level splitter.

Note: Dimensions and capacities are approximate and may vary slightly.

Tank Replacement Parts

Part Number	Description
340065-001	Sight Gauge with Dial Chamber
340065-002	Dial Chamber for 340065-001
340065-003	Male Quick Coupler
340065-004	Liquid Service Valve
340065-005	1-3/4" Acme Fill Valve



Toggle Clamp

Part Number - 137811



Part Number - 380001-001-01
Converter VFF-30-2-IMP

▼ OEM Reference

AC 4870598	HY 258321	TC 53320-50401
AC 74870598	HY 287647	TY 00591-08206-81
AC 8641341	HY 3052453	TY 00591-31700-81
BK 105627	IMP VFF30-2	TY 00591-44714-81
CL 3675433	KO 34B-04-46310	TY 00591-51137-81
CL 6015-10340	MB 7N314	TY 23640-U2000-71
CL 923048	MB 91865-03100	YT 505966558
CT 7N314	MB C0053321	YT 904990600
CT 91865-03100	ME CHI70269-001	
CT 9326500070	NI 16245-VFF30	
HY 0258321	NI 16400-90H71	
HY 0287647	NI NF91865-13100	



Part Number - 380001-004-01
Repair Kit VFF30-2

▼ OEM Reference
KO RK-VFF30-2



Part Number - 380001-005-01
Repair Kit JB2

▼ OEM Reference

BK 1055931	MB MIC-0053100I	TY 00591-64562-81
HY 3004958I	MB MIC-0053110I	TY 04255-U201171
IMP RKJ	MB MDI-700210I	YT 517080800I
MB 93165-03110I	TY 00591-14708-81	YT 900969823I
MB MDI-700210I	TY 00591-44723-81	



Part Number - 380001-002-01
Converter JB-2

▼ OEM Reference

AC 74830760	CT 93465-10010	IMP JB
AC 74884393	HY 195193	IMP JB-2
AC AC4830760	HY 196193	KO JB
CL 932437	HY 213549	NI NI16010-JBREG
CL 2360140	HY 3004951	TC 53320-50501
CT 93165-03100	HY 3052059	TY 23530-2280071
CT 93165-13100	IMP 1015871	YT 5170798-00
CT 93165-13110	IMP 1015887	
CT 93265-10060	IMP 1015971	
CT 93265-10080	IMP 1040397	
CT 93265-20800	IMP 1085401	
CT 93265-30800	IMP 1085402	



Part Number - 380001-006-01
Repair Kit Cobra

▼ OEM Reference

CL 920165	HY 2026721	TY 00591-14711-81
CL 923292	IMP RK-COBRA	YT 518807650
CL 932698	IMP RK-K	YT 580007732
CT 93165-13110	IMP RK-K-2	YT 902057822
DW A213955	IMP N00-6314A	YT 902057825
HY 1375031	JU 14518910	YT 902057827
HY 1459717	MB 93165-13110	YT 924088300
HY 2023646	NI NF93165-13110	
HY 2023647	TY 00591-14608-81	
HY 2026467		



Part Number - 380001-003-01
Converter Cobra

▼ OEM Reference

CL 923049	HY 1458025	YT 520002399
CL 932435	HY 2023640	YT 520037830
CT 91465-0020	HY 2026468	YT 580002388
CT 93165-23100	IMP COBRA	YT 580002399
DOS A218012	NI 6016-10330	
DW A218012	YT 505959551	



Part Number - 380001-008-01
Regulator LPG

▼ OEM Reference
TY 23530-U1100-71
TY 23530-U1101-71
TY 23530-U1102-71
TY 23530-U1103-71
TY 23530-U1104-71

Propane Parts



Part Number - 380001-007-01
Repair Kit CA100/CA125

▼ OEM Reference

AC 4906962	JU 141150106	TY 00591-05456-81
BK 3155729000	JU 14348300	TY 00591-14729-81
CL 4339780	JU 14348310	TY 00591-31729-81
CL 448383	JU 14348320	TY 00591-31741-81
CL 998838	LI 9810306	TY 00591-51156-81
CT 91865-06400	LI D3155729000	YT 220079907
DW 7W5191	MB 7W5191	YT 505963504
DW D700725	MB A0000-00355	YT 505963589
HY 204782	MB LM4AHN9223	YT 516987805
HY 1358246	NI CK998838	YT 520045894
HY 1358247	PG AV1-14-1	YT 900971806
HY 3052003	PG AV1-14-4	YT 900971809
HY 3069660	PG N00-7426A	YT 900971837
IMP AV1-14-4	TC 52050-59871	YT 902249814
JU 14115000	TC DET000997	
JU 14115010	TY 00591-04117-81	



Part Number - 380001-011-02
Seal Ring Rubber for RE7141M

▼ OEM Reference

AG 7141M3	PG 7141M3	TY 00591-31740-81
IN LPG-1066	RE 7141M-3R	TY 00591-51127-81
IN LPG-1073	TY 00591-31734-81	YT 064926500



Part Number - 380001-012-01
Vaporizer Assembly K21-K25

▼ OEM Reference
KO 16310-FT860



Part Number - 064423
Connector LPG Female

▼ OEM Reference

KO 7141-F	HM 7141F	PG REGO7141F
AC 4738548	HY 0097999	RE 7141F
BK 101411	HY 97999	TY 00591-07632-81
BK 9Y11863	JL 2180387	TY 00591-11157-81
CL 655335	KO 7141F	TY 00591-31692-81
CL 715976	LP 225-6267	TY 00591-51083-81
CL 866176	MB 1015874	TY 23560-U2100-71
CL 926119	MB 93165-03600	TY 23560-U2101-71
CT 0045019	MB 93165-03800	WM 35A9482
CT 1015874	MB LM40AQ5019	WM 35P519
CT 45019	MB LM40AQ5019	YT 054966300
CT 9316503600	MB MDI700050	YT 136350102
CT 93165-03800	MB MIC0053011	YT 220014644
CT LM40AQ5019	MR E7141F	YT 220050482
CT MIC-0053011	NI 78001-7141F	YT 251102100
DW 045019	NI NF93165-03600	YT 505966505
DW D700178	PG 7141F	YT 912514300
GA 557-04	PG C-971-3	



Part Number - 137811
Clamp Toggle LP Tank

▼ OEM Reference
KO TB260



Part Number - 380001-010-01
Connector LPG Male

▼ OEM Reference

KO 7141M	CT 9316503500	PG 7141M
AC 4737405	CT 9316503500	PG C-971-4
BK 9Y11864	CT MIC0053089	PG REGO7141M
CL 6016-10470	GA 557-03	RE 7141M
CL 715977	HY 0124010	TC 7141M
CL 926118	HY 3051152	TY 00591-07633-81
CT 0049099	MB 9136103501	TY 00591-31696-81
CT 1085332	MB 9136113500	TY 00591-51085-81
CT 1085392	MB 9300201300	WM 35A9481
CT 49099	MB 9316503500	WM 35P517
CT 9136103500	MB MIC0053089	YT 054966400
CT 9136103501	NI 78001-7141M	YT 136350101
CT 9136113500	NI 7B001-7141N	YT 220050483
CT 9300201300	NI CK715977	YT 520035885

Starters



Part Number - 380005-001-01
Starter H20-H20II-H25
 Teeth (9)

▼ OEM Reference

AC 4948522	KO 23300-K9160	NI 91H20-03330
AC 4967525	NI 23300-K9160	TC 23300-K9160



Part Number - 380005-005-02
Starter GM 3.0L
 Teeth (11)

▼ OEM Reference

CL 2817056	DR 9000822	JU 50018782
CL 925874	DR 9000850	JU 50137926
CL 930707	HY 1374621	SB 8156144
CL 933605	HY 1391321	YT 220044332
CT A0000-05846	HY 1457047	YT 580000049
DR 10455012	HY 1486530	YT 580002210
DR 9000820	HY 1650426	YT 580019725



Part Number - 380005-002-01
Starter 4P-4Y-5R-5P
 Teeth (9)

▼ OEM Reference

TC 212T1-07201
 TY 28100-20553-71
 TY 28100-20553
 TY 28300-22003
 TY 90928-29006-71



Part Number - 380005-006-01
Starter H20
 Teeth (8)

▼ OEM Reference

AC 4942421	NI 23300-00H10	NI 23300-L2912
KO 23300-00H10	NI 23300-00H11	TC 23300-00H10
KO 23300-00H11	NI 23300-L2910	
MB M3T21882D	NI 23300-L2911	



Part Number - 380005-003-01
Starter VA-F2-FE
 Teeth (8)

▼ OEM Reference

HY 1362069
 HY 2314322
 YT 918139600



Part Number - 380005-004-01
Starter 4G63-4G64
 Teeth (10)

▼ OEM Reference

AC 4920209	CT MD320618	MB MD171228
CL 911410	DW A218315	MB MD320618
CL 918306	KM 4920209	MD 320618
CL 920971	MB M002T-58681	NI MD171228
CT M002T-58681	MB M2T58581	NI MD320618
CT MD171228		



Part Number - 380005-008-02
Starter K21-K25
 Teeth (9)

▼ OEM Reference

KO 23300-GS20A	MB 91H2003330	SY SN0143
CT 91H2003330	NI 23300-FU410	TC N-23300-FU410
KO 23300-FU410		



Part Number - 380005-009-02
Starter GM 2.4L
 Teeth (9)

▼ OEM Reference

HY 1548620	HY 80-1406	HY 9000890
HY 300-1555	HY 800136352	YT 5800448-85

Alternators



Part Number - 380011-001-01
Alternator K21-K25

▼ OEM Reference

AC 8762055	CT 91H20-03270	NI 23100-FU410
AC 8772271A	MB 91H20-03270	TC N-23100-FU410



Part Number - 380011-002-01
Alternator 4Y - GN81-41

▼ OEM Reference

KO TJ27060-78003-71	TC 212T1-06941	TY 27060-78003-71
KO TJ270607800371	TY 00591-10795-81	YT 220042179
ND 100211-4540	TY 00591-50056-81	



Part Number - 380011-003-02
Alternator 4Y

▼ OEM Reference

TY 27060-78153-71
TY 27060-78156-71
TY 27060-78158-71



Part Number - 380011-005-01
Alternator D5-F2-FE

▼ OEM Reference

HY 1361853	YT 505960560	YT 580026829
HY 1450928	YT 5800009-90	YT 901948801
JU 14485060		



Part Number - 380011-006-02
Alternator 4G52-4G54

▼ OEM Reference

AC 4789142	CL 907739	JU 14705000
CL 2363677	CL 908106	PL 110-460
CL 2383064	CL 908221	PL 8AR2200L
CL 2399509	CT 2I3346	SG 2383064
CL 2399511	HY 3029189	TY 00591-21035-81
CL 2807382	HY 3046654	TY 00591-27362-81
CL 6513962	HY 385656	TY 00591-33616-81
CL 6599739	JU 1470500	YT 220005010
CL 905949		



Part Number - 380011-004-02
Alternator H20-P40-TB42

▼ OEM Reference

AC 4949046	HY 3020078	NI 23100-M0401
BO 986032431	KO 23100-B9810	NI 23100-M0402
BO 986033481	MB A1T20271	NI 23100-M0410
CL 7000289	MB A1T21171	NI 23100-U0111
CT A0000-02071	MB A1T22581	NI 23100A4602
FL 2475677210	MB A1T24371	NI 23100A4800
HA LT125-04	MB AG2025A	NI 23100A4810
HA LT125-06B	MB AG2030A	NI 23100A5500
HA LT130-41K	MB AG2035A	NI 23100A5501
HA LT130-65	MB AG2035A2	NI 23100A5502
HA LT130-72	MB AG2035N1	NI 23100B8001
HA LT130-72B	MB AH2035N1	NI 23100B8002
HA LT130-75	MZ GE01-18-300	NI 23100E5200
HA LT135-13	NI 23100-06000	NI 23100H0100
HA LT135-13B	NI 23100-A4602	NI 23100H0110
HA LT135-17B	NI 23100-A4800	NI 23100H0300
HA LT135-19B	NI 23100-A4810	NI 23100H0310
HA LT135-19C	NI 23100-A5500	NI 23100M0400
HA LT135-19E	NI 23100-A5501	NI 23100M0401
HA LT135-20	NI 23100-A5502	NI 23100M0402
HA LT135-24	NI 23100-B8001	NI 23100M0410
HA LT135-35	NI 23100-B8002	NI 23100M0410
HA LT135-35B	NI 23100-B9802	NI 23100U0101
HA LT135-35C	NI 23100-B9810	NI 23100U0111
HA LT135-54	NI 23100-B9810-B	TC 53032-72601
HA LT135-68	NI 23100-E5200	TC N-23100-B9810
HA LT135-69	NI 23100-H0100	TC N-23300-B9810
HA LT150-25	NI 23100-H0110	TY 00591-33739-81
HA LT150-25B	NI 23100-H0300	TY 00591-55972-81
HC LT135-68	NI 23100-H0310	YT 150014500
HY 1310962	NI 23100-M0400	YT 150022504
		YT 901285801



Part Number - 380011-007-02
Alternator H20

▼ OEM Reference

AC 4942402	NI 23100-H7703	NI 23100-U0114
AC 4947935	NI 23100-M0413	NI 23100-U4601
CT 971562	NI 23100-M0414	TC 23100-M0413
KO 23100-C6000	NI 23100-M6601	TC 23100-U0103
KO 23100-M0413	NI 23100-U0100	TC N-23100-C6000
KO 23100-M0414	NI 23100-U0102	TC N-23100-M0413
KO 23100-U0105	NI 23100-U0103	TC N-23100-M0414
NI 23100-A4600	NI 23100-U0104	TC N-23100-U0100
NI 23100-A4601	NI 23100-U0105	TC N-23100-U0102
NI 23100-A4611	NI 23100-U0110	TC N-23100-U0103
NI 23100-C6000	NI 23100-U0112	TY 00591-08089-81
NI 23100-H6215	NI 23100-U0113	

Water Pumps



Part Number - 380006-001-02
Water Pump H20 New Style

▼ OEM Reference

AC 4942349	KO 21010-L1125	NI 21010-L1128
AC 4969885	KO 21010-L1126	TC N-21010-L1100
CL 7000507	KO 21010-L1128	TC N-21010-L1125
CT 0971264	KO 64-101	TC N-21010-L1126
CT 971264	NI 21010-L1100	TY 00591-07978-81
HY 3041677	NI 21010-L1101	TY 00591-32887-81
HY 3045360	NI 21010-L1125	TY 00591-50484-81
KO 21010-L1100	NI 21010-L1126	YT 220007606
KO 21010-L1101		



Part Number - 380006-005-02
Water Pump 4G63-4G64

▼ OEM Reference

CT 1041579	CT MD970338	MB MD970338
DW A218276	CT MD972457	MB MD972457



Part Number - 380006-006-02
Water Pump GM 3.0L

▼ OEM Reference

CL 924942
DW A218653
HY 388365
TY 16100-U2120-71



Part Number - 380006-002-02
Water Pump K21-K25

▼ OEM Reference

AC 8761949	DW D490720	NI 21010-50K02
CT 91H20-02580	NI 21010-50K01	NI 21010-P7526



Part Number - 380006-003-02
Water Pump HER2.7-1404

▼ OEM Reference

AC 4948821	DW 2W8554	KO HE40-2035079
CT 1W0404	DW 4W1583	MB 9Y5969
CT 1W404	DW 9Y5969	MB D700615
CT 4W1583	DW D700615	MB MCF00036
CT 9Y5969	HY 402035079	NI D700615
CT D700615	KO HE40-2035063	TY 00591-05705-81
CT MCF00036	KO HE40-2035078	YT 220007160



Part Number - 380006-007-02
Water Pump 4Y 5-6 Series

▼ OEM Reference

CL 446097	TY 00591-32889-81	TY 16120-96151-71
HY 3046758	TY 00591-53193-81	YT 220010746
TY 00591-10723-81	TY 16120-78151-71	



Part Number - 380006-009-02
Water Pump VA

▼ OEM Reference

CT 219273	HY 326774	YT 220007409
HY 1339931	HY 326779	YT 220070181
HY 1376005	TY 00591-34296-81	
HY 3002535	TY 00591-54109-81	



Part Number - 380006-004-02
Water Pump FE

▼ OEM Reference

CL 7000511	JU 14520447	YT 220079608
HY 1361811	MZ FE7915010C	YT 5059605-79
HY 2022312	TY 00591-22426-81	YT 901302802
JU 14365400	TY 00591-32891-81	
JU 14365450	TY 00591-61180-81	



Part Number - 380006-010-02
Water Pump 4Y 7 Series

▼ OEM Reference

TC 212T1-09451
TY 16110-78156-71



Part Number - 380006-011-02
Water Pump H20II-H25

▼ OEM Reference

CT A0000-00429	KO 21010-50K29	TC N-21010-50K28
KO 21010-50K26	KO 21010-FF225	TY 00591-21011-81
KO 21010-50K28	KO 64-102	TY 00591-34284-81
	TC N-21010-50K26	TY 00591-54104-81

Note: All water pumps include gasket

Radiators and Accessories



Part Number - 380009-001-02

Radiator

▼ OEM Reference
AC 8761212
KO 3EB-04-A5111



Part Number - 380009-007-02

Radiator K21-K25

▼ OEM Reference
KO 3EB-04-A6110



Part Number - 380009-002-02

Radiator

▼ OEM Reference
TY 16410-F1100-71
TY 16410-U2200-71
TY 16410-U2201-71



Part Number - 380009-100

Lower Hose

▼ OEM Reference
HY 2064054
YT 5800442-23



Part Number - 380009-003-02

Radiator

▼ OEM Reference
NI 21460-90H15
NI 21460-90H15-D



Part Number - 380009-101

Upper Hose

▼ OEM Reference
HY 2064053
YT 5800442-22



Part Number - 380009-004-02

Radiator

▼ OEM Reference
NI 21460-6G000
NI 21460-6G100
NI 21460-6G101
NI 21460-G6000



Part Number - 380009-102

Radiator Cap

▼ OEM Reference
HY 1352140
YT 5059725-63



Part Number - 380009-005-02

Radiator

▼ OEM Reference
CT A0000-12933
TY 16410-23010-71
TY 16410-23070-71
TY 16410-U2000-71



Part Number - 380009-103

Thermostat

▼ OEM Reference
HY 1584121
YT 5800569-45



Part Number - 380009-006-02

Radiator

▼ OEM Reference
NI 21460-24H10
NI 21460-90H10

Brake Shoes and Accessories



Part Number - 380020-001-02

Brake Shoe Kit (4)

▼ OEM Reference
 AC 8762610
 KO 3EB-30-A31180
 NI 44999-22H00



Part Number - 380020-005-02

Brake Pad (1)

▼ OEM Reference
 TY 47117-1224071
 AC 4943897
 CT 97046-21800
 TC C51M001507405
 KO 3BA-30-31731



Part Number - 380020-002-02

Brake Shoe (2)

A pin is included in this kit to make it adaptable for RH or LH use. Kit includes 2 shoes to do one side of the truck. Need to order 2 kits if doing both sides.

▼ OEM Reference

TC 20803-71151	KO 3EA-30-1144C	TY 47510-U113071
TC 20803-71161	KO 3EA-30-1145C	TY 47520-U113071



Part Number - 380020-006-02

Brake Shoe (2)

▼ OEM Reference

HY 1334640	YT 5059635-91	TC CK21122083000
HY 1358223	YT 5800326-88	KO 3EB-30-2300K
HY 1515374	YT 9182593-00	KO 3EB-30-23450
TC 22433-79901	YT 9301324-00	



Part Number - 380020-003-02

Brake Shoe (2)

▼ OEM Reference

HY 1334620
 YT 1500132-07
 YT 5059595-61
 HY 1363007



Part Number - 380020-008-02-R

Shoe - Right Hand (2)

▼ OEM Reference

HY 1565314
 KO 3EB-K3-0204C
 YT 5800513-33
 YT 524248309



Part Number - 380020-004-02

Brake Shoe (1)

▼ OEM Reference

AC 8761527	KO 3EB-30-31150	TY 47503-3386071
AC 8761528	KO 3EB-30-31160	TY 47504-3386071
AC 8761529	KO 3EB-30-31170	TY 47505-3386071
CT 91446-17100	NI 44060-22H60	TY 47512-3306071
CT 91546-12500	NI 44070-22H60	TY 47513-3306071
CT 91546-12600	NI 44070-22H70	TY 47514-3306071



Part Number - 380020-008-02-L

Shoe - Left Hand (2)

▼ OEM Reference

HY 1565313
 KO 3EB-K3-0203C
 YT 5800513-32
 YT 524248308



Part Number - 380020-007-02

Brake Shoe Kit (4)

▼ OEM Reference

AC 4940527	KO 3EA-30-31170	NI 44070-FJ500
AC 4940532	MB 91246-16800	NI 44070-FJ510
AC 4940535	MB 91246-16900	TY 47403-12810-71
CT 91B46-10313	MB 91246-17100	TY 47403-16600-71
CT 91B46-10314	NI 44060-00H60	TY 47404-12620-71
CT 91B46-10412	NI 44060-11H03	TY 47404-12810-71
DW A273363	NI 44060-11H06	TY 47404-13300-71
DW A273364	NI 44060-FJ500	TY 47405-12620-71
DW A273365	NI 44060-L0105	TY 47405-12810-71
KO 32532-21500	NI 44070-00H60	TY 47405-13000-71
KO 32532-21600	NI 44070-00H70	TY 47405-13300-71
KO 3EA-30-11410	NI 44070-0K301	TY 47405-1660071
KO 3EA-30-11420	NI 44070-0K311	TY 47406-13000-71
KO 3EA-30-11430	NI 44070-11H06	TY 47505-1300071
KO 3EA-30-31150	NI 44070-11H16	TY 47506-1300071
KO 3EA-30-31160		

Brake Cylinders



Part Number - 380021-001-02

Brake Cylinder

▼ OEM Reference

AC 8761597
 AC 8766117
 KO 3EB-36-31280
 KO 3EB-36-31281
 KO MY022-8098-00
 TY 00591-27394-81



Part Number - 380021-004-02

Brake Cylinder

▼ OEM Reference

CL 7001049	MB 1015776	RA 750
CT 1015776	MB 91484-17100	RA 990-253
CT 1015777	MB 91484-27100	TY 00591-35379-81
CT 91484-17100	MB 91484-27101	TY 00591-58010-81
CT 91484-27100	MB 91484-37100	TY 47530-42100-71
CT 91484-27101	RA 1-164-912	
CT 91484-37100	RA 1-164-915	



Part Number - 380021-002-02

Brake Cylinder

▼ OEM Reference

CT 91346-40300
 CT 93146-02500
 CT 93146-12500
 MB 93146-02500
 MB 93146-12500



Part Number - 380023-001-02

Brake Pedal Cover

▼ OEM Reference

AC 8761606	KO 3EB-36-31130	TY 31319-22000-71
CL 446183	TY 00591-10808-81	TY 31319-23000-71
CL 7000977	TY 00591-35270-81	YT 220004289
CT 0971315	TY 00591-53231-81	
HY 3045352	TY 31319-20540-71	



Part Number - 380021-003-02

Brake Cylinder

▼ OEM Reference

CL 7001081	JU 14495460	TY 00591-58023-81
HY 1347048	MA M45110	YT 220037522
HY 3057522	TY 00591-35435-81	YT 505963537

Muffler



Part Number - 380007-001-02

Muffler

▼ OEM Reference

AC 4949214
 KO 3EB-03-22110
 TY 00591-06324-81



Part Number - 380012-001-02
Distributor Cap - H20II
 Style - DC-10
 ▼ OEM Reference
 AC 8762078 NI 22162-55K10
 DW D490743 TC 22162-55K10
 KO 22162-55K10 TC 22162-55K11
 KO 25-011 TY 00591-23165-81



Part Number - 380012-006-02
Distributor Cap - F2-FE
 Style - DC-11
 ▼ OEM Reference
 HY 1326394 TY 00591-33666-81
 HY 1339151 TY 00591-56299-81
 HY 1370740 TY 00591-56303-81
 HY 3054982 YT 150022511
 JU 14415530 YT 220020015
 JU 14491840 YT 505960556
 JU 14501360 YT 505960583
 MB T45327 YT 901357802
 TC T-FEEN-18-V00 YT 901580802
 TY 00591-06004-81 YT 901580812
 TY 00591-31680-81



Part Number - 380012-002-02
Distributor - H20II
 Style - G
 ▼ OEM Reference
 AC 8762077 NI 22100-50K15
 AC 8762122 NI 22100-55K10
 DW D490742 TC N-22100-50K10
 KO 20-203 TY 00591-27353-81
 KO 22100-50K10 TY 00591-42798-81
 KO 22100-50K15
 KO 22100-55K10
 NI 22100-50K10



Part Number - 380012-007-02
Distributor Cap - 4G63-4G64, FE-F2
 ▼ OEM Reference
 CL 4335221 MB MD618364
 CL 923626 MB T232T-48372
 CT MD618364 NI CK923626
 CT T232T-48372 NI MD618364
 DW A218353 NP EP-335
 HN MD618364 SG MD618364
 HY 1554033 TY 00591-75236-81
 HY 3127916 YT 220022013
 HY 3143902 YT 220043902
 YT 580047018



Part Number - 380012-003-02
Distributor - 4Y
 Style - I
 ▼ OEM Reference
 CT A0000-14798 TY 19030-78151-71
 ND 290000621 TY 19030-78154-71
 TC 212T1-06101 TY 19030-96150
 TY 19030-78150-71



Part Number - 380012-008-02
Distributor Cap - D5
 Style - DC-05
 ▼ OEM Reference
 HY 1371206 TY 00591-11106-81
 HY 3020958 YT 901356802
 NP FA-164



Part Number - 380012-004-02
Distributor Cap - 4Y
 Style - DC-6
 ▼ OEM Reference
 CL 7000255 TY 00591-53200-81
 CT 215154 TY 19101-71010-71
 HY 3048471 TY 19101-76007-71
 TC 212T1-06111 TY 19101-76013-71
 TY 00591-10752-81 YT 220004547
 TY 00591-32688-81



Part Number - 380012-009-02
Distributor - 4G63-4G64
 Style - B
 ▼ OEM Reference
 CL 918313 MB MD169418
 CT 1041457 MB T3T65675
 CT MD169418 NI MD169418
 MB 1041457 TY 00591-42783-81



Part Number - 380012-005-02
Distributor - H20
 Style - C
 ▼ OEM Reference
 AC 4942371 NI 22100-71317
 CL 445285 NI 22100-74011
 CL 7000308 NI 22100-K7201
 CT 0971564 TC N-22100-49207
 HY 3123249 TC N-22100-71306
 KO 20-200 TC N-22100-71317
 KO 22100-K7201 TC N-22100-K7201
 NI 22100-49206 TY 00591-07207-81
 NI 22100-49207 TY 00591-32718-81
 NI 22100-49210 TY 00591-51220-81
 NI 22100-71305 YT 220024204
 NI 22100-71306 YT 220025194
 NI 22100-71315

Distributors/Caps



Part Number - 380012-011-02
Distributor Cap - 4G32-52-54
 Style - DC-20

▼ OEM Reference

AC 4920234	KO 22162-R9006	SG MD611686
AC 4921224	KO 22162-R9007	TC N-22162-25G10
AC 4949023	MB 1017046	TC N-22162-25G11
CL 3779914	MB MD602756	TC N-22162-R9006
CL 7000312	MB MD602949	TC N-22162-R9007
CL 909351	MB MD607597	TY 00591-03628-81
CL 916005	MB MD611686	TY 00591-31074-81
CT 0971276	MB T232T-46772	TY 00591-32686-81
CT 0971771	NI 22162-11E07	TY 00591-33765-81
CT 1017046	NI 22162-17M01	TY 00591-33766-81
CT 971276	NI 22162-17M03	TY 00591-51412-81
CT 971771	NI 22162-25G10	TY 00591-51418-81
CT MD602756	NI 22162-25G11	TY 00591-51420-81
CT MD602949	NI 22162-A3514	TY 00591-56301-81
CT MD607597	NI 22162-R9006	YT 220000727
CT MD611686	NI 22162-R9007	YT 220012921
CT T232T-46772	NI 2216217M01	YT 220016273
HY 3000542	NI 2216217M03	YT 220054038
HY 3020828	NI CK3779914	YT 220054193
HY 3021276	NI MD611686	YT 901284807
HY 3043274	SG 3779914	YT 901304806
KO 22162-25G11	SG MD611685	



Part Number - 380012-012-02
Distributor Cap - H20II
 Style - DC-12

▼ OEM Reference

AC 4969894	KO 22162-78A10	NI 22162-78A00
CL 445294	KO 25-003	NI 22162-78A10
CL 7000253	MB T46371	TC N-22162-G5710
CL 872631	MB 216276	TC N-22162-G5711
CT 46371	NI 22162-G5710	TC N-22162-23G15
CT 216276	NI 22162-G5711	TC N-22162-78A10
HY 3046816	NI 22162-17M02	TY 00591-07216-81
HY 3132609	NI 22162-17M04	TY 00591-32687-81
KO 22162-G5710	NI 22162-23G15	TY 00591-51417-81
KO 22162-G5711	NI 22162-40F00	YT 220012748
KO 22162-23G15	NI 22162-40F10	YT 220024209
	NI 22162-75A10	YT 220070292
	NI 22162-78AX0	

Ignition Rotors



Part Number - 380015-001-02

Rotor RT-11 H20II

▼ OEM Reference

AC 8762079	DW A218357	MB MM611850
BR CK923627	DW D490744	MB T880T-18972
CL 4335223	HN MD618262	NI 22157-55K10
CL 923627	HY 3142510	NI 22157-55K15
CT 91H20-04710	KO 22157-55K10	NI CK923627
CT 914658	KO 26-011	RN J5-5610
CT MD611817	MB 91H20-04710	RN J5-5611
CT MD618262	MB 914658	TC N-22157-55K10
CT MM611850	MB MD611817	TY 00591-23164-81
CT T880T-18972	MB MD618262	YT 220025671



Part Number - 380015-006-02

Rotor RT-13 TB42 6 cyl

▼ OEM Reference

AC 4968831	HY 3122011	RN J5-5612
CL 2572769	KO 22157-52H20	TC N-22157-52H20
CL 444901	MB 1038060	TY 00591-20723-81
CT 1038060	MB MM502535	YT 220018323
CT MM502535	MB T880X17571	
CT T880X17571	NI 22157-52H20	



Part Number - 380015-002-02

Rotor RT-07 4Y

▼ OEM Reference

CL 446130	TY 00591-10757-81	TY 19102-73020
CT 215133	TY 00591-63393-81	TY 19102-73021
HY 3046813	TY 19102-16020	TY 19102-73180
HY 3133089	TY 19102-16040	TY 19102-76007-71
HY 3143266	TY 19102-33010-71	TY 19102-76009-71
RN J5-5613	TY 19102-63010-71	TY 19102-76013-71
TC 212T1-06121		



Part Number - 380015-007-02

Rotor RT-10 4G32-52-54

▼ OEM Reference

AC 4920235	CT T880T12273	NI CK916006
AC 4949021	HY 3000626	NI MD611850
BR CK909353	KO 22157-10B10	NP EP-342
BR CK916006	KO 22157-R9006	RN J5-5620
CL 445290	KO 22157-R9007	TC N-22020-10B10
CL 445292	KO 26-002	TC N-22157-10810
CL 909353	MB 1017001	TC N-22157-10B10
CL 916006	MB 1041551	TC N-22157-R9006
CT 0971270	MB MD602758	TC N-22157-R9007
CT 1017001	MB MD611850	TY 00591-03630-81
CT 1041551	MB T880T12273	TY 00591-31814-81
CT 971270	NI 22157-10B10	TY 00591-50368-81
CT MD602758	NI 22157-R9006	YT 220000750
CT MD611850	NI 22157-R9007	YT 901284808
CT T880T-12273	NI CK909353	



Part Number - 380015-004-02

Rotor RT-03 F2-FE

▼ OEM Reference

CL 444460	NP EP-780	TY 00591-33710-81
CL 446399	RN J5-5614	TY 00591-56318-81
CT 218115	RN J5-5615	TY 00591-56319-81
HY 1326395	TC T-F829-18-V05	TY 00591-56321-81
HY 1362035	TC T-FE2S-18-V05	YT 150022510
HY 1367561	TY 00591-06005-81	YT 220070293
HY 2022460	TY 00591-11046-81	YT 505960565
HY 2023725	TY 00591-31681-81	YT 901356803
MZ F829-18-V05	TY 00591-31813-81	YT 901356814
MZ FE25-18-V05	TY 00591-33617-81	YT 901357803
NP EP-339	TY 00591-33686-81	YT 901953805



Part Number - 380015-008-02

Rotor H20

▼ OEM Reference

AC 4942380	KO 22157-D1200	NI 22157-D1200
AC 4942507	KO 22157-H1000	NI 22157-H1000
AC 8761136	KO 22157-H1001	NI 22157-H1001
CL 7000272	KO 22157-R9007L	NI 22157-R9007L
CT 0971246	KO 37Z-02-HR301A	NP EP-312
DR 12309027	KO 37Z-02-HR301L	TC N-22157-05M02
DR 12309037	KO 37Z-02-HR901	TC N-22157-71300
DR 1972404	KO 5-81326-001-0	TC N-22157-76500
DR E-414	KO 8-94243-346-0	TC N-22157-78500
DR E-417	KO 8-94243-346-1	TC N-22157-D1200
DR E-417-X	KO 9-8231-1912-0	TC N-22157-H1000
DR E414	KO 9-8232-1911-0	TC N-22157-H1001
DR E414Z	KO 9-8232-1912-0	TY 00591-07214-81
HY 3000666	NI 22157-05M02	TY 00591-33703-81
KO 22157-05M02	NI 22157-71300	TY 00591-51429-81
KO 22157-71300	NI 22157-78500	YT 220052533
KO 22157-78500		




Part Number - 380015-005-02

Rotor RT-17 FE-FE2

▼ OEM Reference

HY 1554034
YT 580047019




Part Number - 380015-009-02

Rotor RT-01 GM 6 cyl

▼ OEM Reference

CL 1342529	HY 1334403	TY 00591-56322-81
CL 2575926	HY 1342529	TY 19102-31720-71
CL 922220	HY 1374329	TY 19102-U3160-71
CL 922221	MB 90420-01480	YT 580000384
CT 90420-01480	NI NF90420-01480	YT 900005266
DW A232133	TY 00591-33685-81	

FIVE RING DESIGN - The five rib design prevents flashover and reduces voltage loss. It offers 20% more insulation than conventional plugs. This improved performance is especially significant in plugs with a large gap operating under high voltage.



INSULATOR - The insulators are made of a highly purified alumina powder, which gives strength and thermal conductivity at high temperatures, as well as greater physical strength.

SPECIAL COPPER-GLASS SEAL - A special mixture of copper and glass powder bonds the center electrode and insulator together for a gas-tight seal. Proper heat is maintained and hot combustion gases are excluded.

U-GROOVED GROUND ELECTRODE - This U-Groove allows the spark to fill the gap formed by the U. The ball of fire develops, a larger and hotter flash front, so that the combustion is more complete.

COPPER CORED CENTER ELECTRODE - A special center electrode incorporates copper into the core of the nickel chrome binary alloy. This gives superior thermal conductivity, and increases the operating range.

Part Number - 380013-001-02

Spark Plug - W20ES-U

▼ OEM Reference

AC 4905798	PG 43N	PG B6ES-11
KO 22401-58001	PG 43XL	PG C43N
KO 22401-M7714	PG 44N	PG C44N
KO 22401-M7716	PG 44XL	PG N288
KO 37Z-02-SP04A	PG AG3	PG N5C
KO 37Z-02-SP05A	PG AG30C	PG S43XL
NI N-22401-M7716	PG AG3CX	PG S44XL
PG 394	PG AG3X	PG W16ES-U
PG 4056	PG B6ES	

Part Number - 380013-002-02

Spark Plug - Q14R-U11

▼ OEM Reference

CT 91H20-02860	PG BCP4ES11	PG DCP4ES11
KO 22401-FU412	PG BCP4EY11	PG DCP4EY11
PG BCP4ES	PG DCP4E7	PG FR9DCX
PG BCP4ES11	PG DCP4ES	

Part Number - 380013-004-02

Spark Plug - W14EXR-U

▼ OEM Reference

AC 4516333	CT 1017268	NI 22401-L1600
AC 4516353	HY 3002290	NI 22401-V1414
AC 4933394	HY 3002347	TC N-22401-L1600
CL 2385639	KO 22401-V1414	TY 00591-02042-81
CL 4338827	MB 1017268	TY 00591-33646-81
CL 913639	MB MB1017268	YT 150112466
CN SP200S00009RNYC	ND W16EXR-U	

Part Number - 380013-005-02

Spark Plug - W9EXR-U

▼ OEM Reference

HY 1361837	PG BPR2ES	YT 5059605-35
PG BPR2E	TY 90919-01954-71	

Part Number - 380013-006-02

Spark Plug - W16EX-U

▼ OEM Reference

AC 4920323	MB MS851101	PG C44NS
CL 909378	PG 4253	PG MS851243
CT 2W9486	PG 44NS	PG N11YC
CT MS851101	PG B2401-89904	PG N12YC
MB 1038083	PG BP5EA-L	PG W16EX-U
MB MS851022	PG BP5EY	TY 90919-01954

Part Number - 380013-007-02

Spark Plug - W9EP

▼ OEM Reference

AC 8762050	PL 14G82	TY 80919-76009-71
BH W10DC	SL 144483	TY 80919-76011-71
CL 444771	TC 20801-0A041	TY 80999-76018-71
CT 0971353	TC N-22401-W8914	TY 90098-09125
HY 0326827	TC W9EP	TY 90098-20395
HY 3002288	TY 00591-06208-81	TY 90919-01021
HY 326827	TY 00591-06209-81	TY 90919-01055-71
KO 22401-W8914	TY 00591-32695-81	TY 90919-01950-71
KO 37Z-02-SP02E	TY 00591-33649-81	TY 90999-09001-71
KO TJ-90098-09125	TY 00591-50973-81	TY 90999-09002-71
KO TJ-90919-01055	TY 00591-50976-81	YT 150038500
KO TJ-90919-01950-71	TY 80098-76006-71	YT 220001599
ND W9EP	TY 80919-76004-71	YT 900537827
NI 22401-W8914	TY 80919-76005-71	
PL 14G22	TY 80919-76008-71	

Part Number - 380013-008-02

Spark Plug - T16PR-U

▼ OEM Reference

BH HR8BC	HY 0388361	TY 00591-10918-81
BH HR8BP	HY 1332675	TY 00591-32692-81
BH HR9BC	HY 1332676	TY 00591-42808-81
CL 446323	HY 1451269	TY 00591-50978-81
CL 925049	HY 1467579	TY 90098-16785
CT 216460	ND T16PRU	YT 150112453
DR R-45-TS	ND T20EPRU	YT 516484800
DW A218756	TN 07764	YT 580005036
DW A219024	TN 39046	YT 580008972
DX 1411740	TY 00591-06165-81	YT 580013445

Part Number - 380013-009-02

Spark Plug - W16EPR-U

▼ OEM Reference

CT 1038083	PG CR43CXLS	PG RN12YCC
DW A218377	PG CR44NS	PG RN14YC
PG 1Y00-18-110	PG ON11Y	
PG 3322	PG ON12Y	
PG BPR5E	PG R44LT	
PG CR425XLS	PG RN11YCC	

Part Number - 380013-013-02

Spark Plug - Q20PR-U

▼ OEM Reference

DW A223103
NG BCP4E6

Part Number - 380013-014-02

Spark Plug - PT16EPR-L13

▼ OEM Reference

BO HR9DPX	MB 90420-01620	TY 19111-90098-71
BO HR9DPY	ND PT16EPR-L13	TY 19111-U3161-71
CL 923702	NI NF90420-01620	TY 90098-66113-71
CT 90420-01620	TY 19111-31720-71	TY 90420-01190-71
HY 1389133	TY 19111-31721-71	YT 900015293

Spark Plugs

Part Number - 380013-012-02

Spark Plug - L14-U

▼ OEM Reference

AC 232560	CT 0041663	PL 18-9
AC 4513315	CT 0631202	TY 00591-07885-81
AC 4613261	CT 0676637	TY 00591-07896-81
AC 4660976	CT 0972385	TY 00591-32691-81
AC 4810105	CT 0973283	TY 00591-50970-81
AC 4905800	CT 2A3643	TY 00591-50971-81
AC 4908597	CT 353706	TY 00591-53307-81
AC 4910105	CT 8N2630	TY 90098-64015
AC 4916015	DR C-86	WK 110532
BK 101359	DR C-87	WK 209316
BK 101527	HY 0028758	WM 10-R-385
BK 115923	HY 0079161	WM 10R1191
BK 116251	HY 0123872	WM 20-7000680
BK 716D1	HY 0138366	WM 20-7000681
BK 716J1	HY 0197885	WM 20-7000949
CL 3739054	HY 1312459	WM 20-7100035
CL 742159	HY 1332693	YT 016254800
CL 784250	HY 3001582	YT 016255000
CL 890215	HY 3001585	YT 016255100
CL 890217	HY 3001586	YT 031314500
CL 890221	HY 3001590	YT 063194200
CL 890222	HY 3002287	YT 150015100
CL 890227	HY 3002348	YT 150112405
CL 890245	HY 3002349	YT 150112406
CL 890246	HY 3002575	YT 150112407
CL 890247	HY 3002577	YT 150112408
CL 890255	HY 3040014	YT 150112409
CL 890256	HY 3050408	YT 150112410
CL 890264	HY 3051151	YT 150112411
CL 890271	HY 3051322	YT 150112413
CL 890272	MB 2A3643	YT 150112420
CL 890273	MB 8N2630	YT 150112427
CL 890274	ME 41073	YT 220007428
CL 890276	ME 41273	YT 220010987
CL 907621	ME 41663	YT 220011080
CL 913628	ND L14-U	YT 220011107
CL 913633	NI CK913628	YT 220011205
CL 913638	NP UD-16	YT 220052206
CL 913831	PL 18-10	YT 509295802
CL 940328	PL 18-4	YT 510764800
CN YD6	PL 18-8	YT 517451800
CT 0007954		

Part Number - 380013-016-02

Spark Plug - T14PR-U

▼ OEM Reference

BH H9BC	JU 14148410	TY 00591-50979-81
BO 242219516	ND T14PR-U	TY 19111-U2120-71
CL 922786	PL 14RF42	TY 90098-14785
DR R-45-RB	PL 14RF52	YT 220013371
HY 0281844	PL 14RF62	YT 580000628
HY 1330468	SB 8155723	

Part Number - 380013-017-02

Spark Plug - W16S-U

▼ OEM Reference

AC 4907334	CT MD997476	ND W16S-U
AC 4948894	CT 851101	PL 14-4
AC 9001652	CT 997476	PL 14-5
BK 716G1	DW 8N2236	PL 14R8
CL 446583	DW D141267	TY 00591-05493-81
CL 890210	DW D700699	TY 00591-10919-81
CL 890219	HY 0360046	TY 00591-20174-81
CL 890220	HY 1312454	TY 00591-33687-81
CL 890225	HY 3001588	TY 00591-55310-81
CL 890236	HY 3002289	TY 80098-76004-71
CL 890252	HY 360046	TY 80098-76005-71
CL 890253	KO HE0052048-00	YT 150112473
CL 890265	KO HE0110256-00	YT 150112490
CL 890267	KO HE0110526-00	YT 150112494
CT 0099476	KO HE40-2502314	
CT 141267	KO HE52892	
CT 8N2236	MB 8N2236	
CT 99476	MB MD997476	
CT MD851101	MB 997476	

Spark Plug Wires



Part Number - 380014-001-02

Plug Wire - Set 4Y

▼ OEM Reference

TC 20801-0K052	TY 80919-76106-71
TC 212T1-08551	TY 90919-22132
TY 80919-76102-71	



Part Number - 380014-002-02

Plug Wire - Set 4G63-4G64

▼ OEM Reference

CL 920989	DW A218378
CL 920990	MB 1085017
CT MD972033	
CT MD972748	



Part Number - 380014-005-02

Plug Wire - Set F2-FE

▼ OEM Reference

CL 7000201	TY 00591-56029-81
CL 7000218	TY 00591-61181-81
HY 1362113	TY 00591-76611-81
HY 1369893	YM YA901303803
JU 14364620	YT 220100562
JU 14495050	YT 505976593
TY 00591-11105-81	YT 901283805
TY 00591-33553-81	YT 901303803
TY 00591-33593-81	



Part Number - 380014-006-02

Plug Wire - Set H20II

▼ OEM Reference

DW D490816	NI 22450-50KA0
KO 22450-50K25	TC 20801-0K041
KO 22450-50K50	TC 20801-0K042
KO 22450-50KA0	TC N-22450-50K50
NI 22450-50K25	TY 00591-33605-81
NI 22450-50K50	TY 00591-56038-81



Part Number - 380014-007-02

Plug Wire - Set GM 3.0L

▼ OEM Reference

DOS A218755	YM YA901303803
HY 1329534	YT 220100562
HY 1337666	YT 901283805
HY 1329534	YT 901303803
TY 00591-61181-81	
TY 19335-U2120-71	



Part Number - 380014-008-02

Plug Wire - Set H20

▼ OEM Reference

AC 4942394	NI 22450-L1051
CL 1810436	NI 22450-L1125
HY 0214998	TC 22450-L1051
HY 3052065	TY 00591-00152-81
KO HE-2500753	TY 00591-01133-81
KO HE-2500754	TY 00591-06286-81
NI 22450-49251	TY 00591-32723-81
NI 22450-L0150B	TY 00591-56004-81

Coils



Part Number - 380016-001-02

Coil

▼ OEM Reference

CL 925969	CT MD326638	MB MD326638
CL 4335230	DW A218371	TY 00591-27426-81
CT MD358504	MB MD358504	
CT 1832A002	MB 1832A002	

Fan Blades



Part Number - 380008-001-02

Fan Blade - K21-K25

▼ OEM Reference
 AC 8779236
 KO 21060-FU40A
 NI 21060-GY360
 TC N21060FU40A



Part Number - 380008-004-02

Fan Blade - H20

▼ OEM Reference

AC 4942359	KO 21060-49003	TC N-21060-48210
CL 445268	KO FN-200	TY 00591-07192-81
CL 7001677	NI 21060-48210	TY 00591-36864-81
HY 3124790	NI 21060-49001	
KO 21060-48210	NI 21060-49003	



Part Number - 380008-002-02

Fan Blade - 4Y 6-7 Series

▼ OEM Reference

AC 8762498	KO YM129900-44700	TY 16361-23860-71
KO YM129900-4470	TC 212T1-05981	YT 220034759



Part Number - 380008-005-02

Fan Blade - 4G63-4G64 K-Series

▼ OEM Reference

CT 91202-07400	MB 91202-07400	TY 00591-27429-81
CT 91202-17400	MB 91202-17400	



Part Number - 380008-003-02

Fan Blade - H20 II

▼ OEM Reference

AC 4901388	KO FN-201	TC N-21060-50K00
DW D491452	NI 21010-50K00	TY 00591-36868-81
KO 21060-50K00	NI 21060-50K00	TY 00591-54141-81
KO 21060-87V00	NI 21060-87V00	

Belts

Continued ▶



Part Number - 380010-001-02

Belt-Fan H20II-H25

▼ OEM Reference

DW D490878	KO 11720-K4080	TC N-11720-K4080
KO 11720-52H01-F1	KO 11720-K4080A	TY 00591-75559-81
KO 11720-87V10	NI 11720-87V10	
KO 11720-87V10A	NI 11720-K4080	

Part Number - 380010-003-02

Belt-Fan 4Y 7 Series

▼ OEM Reference

TY 90916-02975-71

Part Number - 380010-005-02

Belt-Fan K21-K25

▼ OEM Reference

AC 4512419	JU 14050060	VB 12.7X1250
CL 1320218	JU 1408732	VB 17480
CL 3490402	JU 14087320	VB 17481
CL 352780	JU 14105900	VB 17484
CL 4312314	KM DV68923	VB 17491
CL 876983	KO 02117-20021	VB 9.5X1250
CT 6L3408	KO 02117-21521	VB 9490
CT 91H20-02560	KO 02117-23021	VB B-17484-A
CT 91H20-02570	KO 02117-23523	VB JC-483
CT 9L2248	MB 91H20-02560	VB N-9480
CX MH38805	MB 91H20-02570	VB V-5546
FW 3007020	MB 91H2002560	VB 1251212
FW 8101112	MB 91H2002570	YM 25132-004600
HY 0104728	NI 02117-20021	YT 220011118
HY 0809400	NI 02117-21521	YT 220052043
HY 0984977	NI 02117-23021	YT 295675600
HY 104728	SL 40955	YT 295675700
HY 2039256	TC 20801-04081	YT 440053117
HY 3057598	TC Z-8-94144-301-0	YT 449089051
HY 3064467	TY 00591-51028-81	YT 580014183
HY 809400	TY 16372-13010-71	YT 580015831
HY 984977	TY 90916-02976-71	YT 900534806
JU 1405006	VB 12.5X1200	



Part Number - 380050-003
Bearing Outer

▼ OEM Reference

AC 4945286	HY 3056632	NI 40211-49001
CL 4151715	KO 34A-21-13210	TY 43815-31620-71
CT F8143-32212	KO 3BD-22-11280	YT 220019999
CT F814332212	KO 3ED-22-11280	YT 220036635
DW A123042	MB F8143-32212	YT 449058034
DW A123043	MB F814332212	YT 503536246
HY 2027663	NI 08322-1201P	YT 905148300
HY 2039210	NI 38440-61500	YT 906197100
HY 3004980	NI 40211-49000	YT 909932404



Part Number - 380050-006
Bearing Cone

▼ OEM Reference

AC 927269	HY 183615	RA 447-098
BG 104948PK	HY 183615	RA DS223655
BG JLM104948	HY 1461670	SG 1318728
BG NT104948PK	HY 1461673	TM JLM104948
BK 6022	HY 3051808	TY 00590-00909-71
BK 6022	IN IN-1585	TY 00591-00644-81
BR CK1318728	IN IN-234	TY 00591-30316-81
CL 1318728	KY KYJLM104948	TY 00591-50757-81
CL 3799728	LI 6022	YT 132614401
CT 953582	LI 6022	YT 220051134
CT 1075032	MB 1075032	YT 502029902
CT 9S3582	MB 9S3582	YT 503536215
CT A0000-07892	MB A0000-26570	YT 580010475
CT A000007892	MB A000026570	YT 580010479
CT A0000-26570	NI CK1318728	



Part Number - 380050-004
Bearing Inner

▼ OEM Reference

AC 4940236	HY 3132196	NY F814030214
BG 30214JR	IN IN-631	SL 5411744
BG AK30214JR	KO 06000-30214	TC 03071-30214
BK LFM53100008	KO 06000-30214L	TY 00591-06279-81
CL 444881	KO 06002-30214	TY 00591-35745-81
CL 7001266	KO 06002-30214L	TY 00591-61205-81
CT 1032322	LI FM53100008	YT 220015777
CT F8140-30214	MB 41530214	YT 220023796
CT F814030214	MB 0415-30214	YT 220027712
DW A293947	MB F8140-30214	YT 220052160
HY 1375492	MB F814030214	YT 258086900
HY 2027662	NI 38440-86160	YT 449058030
HY 3004979	NI NFF8140-30214	YT 503536245
HY 3027413	NY 30214	YT 909932403
HY 3055603	NY 41530214	YT 950517913
HY 3130754	NY 434035070	



Part Number - 380050-016
Bearing Roller

▼ OEM Reference

BG MG5208VFFQ	IN IN-1294	YT 220072690
CL 1333648	IN IN-1310	YT 520045369
HY 1333648	TY 00591-06008-81	



Part Number - 380050-017
Bearing Roller

▼ OEM Reference

BK KMCC662145	CT A0000-10379	MB A0000-10379
CA 662145	ET ET24756	MB K0000-10379
CA 797469	IN IN-1516	NI 662145
CA C797469	IN INE-7663	SL 141231
CE 662145	KO 662142	
CL 662145	KO CC662145	

Part Number - 380050-005
Bearing Cup

▼ OEM Reference

AC 927272	HY 183614	RA DS223657
BG 104910PK	HY 183614	SG 1318727
BG JLM104910	HY 3040033	TM JLM104910
BG NT104910PK	HY 3040949	TY 00590-00911
BK 6024	HY 3051807	TY 00590-00911-71
BK 6024	IN IN-233	TY 00591-00643-81
BR CK1318727	KY KYJLM104910	TY 00591-35528-81
CL 1318727	LI 6024	TY 00591-54879-81
CL 3799729	LI 6024	YT 132614402
CT 1075034	MB 1075034	YT 220051135
CT 9S3581	MB 9S3581	YT 502029903
CT A0000-07882	NI CK1318727	YT 503536216
CT A000007882	NN 4TJLM104910	
DW A233320	RA 447-562	



Part Number - 380050-018
Bearing Thrust Roller

▼ OEM Reference

BK 683819	CA 683919	CT 683819
CA 683819	CL 683819	HY 683819

Bearings



Part Number - 380050-019

Bearing Roller Lift

▼ OEM Reference

BG 83B089B	IN IN-1023	TY 00591-07487-81
CL 7001125	NI 59117-20H00	YT 220070718
HY 3046919	NI 59117-20H03	



Part Number - 380050-020

Bearing Roller Lift - 94 mm Dia.

▼ OEM Reference

HY 3046489	NI 59117-01H03	YT 220070685
NI 59117-01H00	TY 00591-07485-81	



Part Number - 380050-034

Bearing Mast

▼ OEM Reference

CL 7001320	JU 1438437	YT 220034034
CT 215812	JU 14384370	YT 907595300
HY 2039336	JU 14384440	YT 907595301
HY 2039337	MB 215812	YT 913987301
HY 2303610	TY 00591-30424-81	YT 913987302
HY 3054631	TY 00591-52666-81	
IN IN-769	TY 00591-76827-81	



Part Number - 380050-035

Bearing Mast

▼ OEM Reference

BG 209MZZ1	HY 3003695	YT 220035887
BG FMMG209DD	HY 3021364	YT 253851100
BG HVX559	HY 3035129	YT 502276300
BG MG209DD	HY 3054910	YT 502276301
BG MR209MZZ1	HY 3056654	YT 502276302
BG NTSX09A63	IN IN-282	YT 502276303
BG SX09A63	JU 1409636	YT 502277301
BG X559	JU 1436990	YT 502277302
BR 27494-000	JU 14096360	YT 503536248
BR B-27494	JU 14369900	YT 504117200
BR B27494	JU 143699003	YT 507033500
CT 972433	MB 972433	YT 508801800
CT 972433	TY 00591-06467-81	YT 513375800
CT 973960	TY 00591-30336-81	YT 904515101
CT 973960	TY 00591-50877-81	YT 904515102
HY 2303874	YT 150031100	
HY 2309514	YT 220016206	



Part Number - 794109-004

Bearing Tapered Roller

▼ OEM Reference

AC 4943832	IN IE-103653	NI 40215-10360
AC 4948504	IN IN-1096	NI 43215-76000
BK 9247374	IN IN-1229	NI 43215-T8000
BK L0009246860	IN IN-1302	NI CK1817083
BK L0009247374	IN IN-1303	RA 447-105
BK L9509000865	KO 06000-32011	RA 921-000-195
BK LD0009246860	KO 06000-32021	SL 145542
BR CK1817083	LI 9246860	TY 00590-00414-71
CL 1817083	LI 9247374	TY 00591-76004-81
CR CR794109-004	LI 9509000865	TY 04421-27010
CR CR794109-4	LI D0009246860	TY 04421-27050
CT 801985	LI LD0009246860	TY 04421-30010
CT 801985	MB 801985	TY 04421-30011
CT 1009115	MB 1009115	TY 04421-30012
CT NA040025	MB NA040025	TY 90369-35003
DW A213066	MT 650055	TY 97600-32011-71
ET ET24657	MT 26500550	YT 220011358
HY 368427	MT 410031122	YT 220075153
HY 368427	MT 410031122	YT 277154700
HY 2797577	MT 4207748133	YT 440065120
HY 3044732	MT 4207748133	YT 502029910
HY 3046220	MT 4208848227	YT 519244814
HY 3053301	MT 4208848227	YT 580036620

Seals



Part Number - 380050-001
Seal Outer

▼ OEM Reference
HY 1523530



Part Number - 380050-002
Seal Inner

▼ OEM Reference

CL 7003887	JU 14374480	TY 00591-76873-81
HY 2027701	TY 00591-33124-81	YT 220020044
HY 2027817	TY 00591-54664-81	YT 911086300
JU 1437448	TY 00591-71480-81	YT 920803300

Part Number - 380050-011
Seal Oil

▼ OEM Reference

CT 973851	HY 266733	TY 00591-52483-81
CT 973851	HY 3057503	YT 220037503
HY 153718	TY 00591-20561-81	YT 220075023
HY 153718	TY 00591-32092-81	YT 504224242

Part Number - 380050-033
Seal Oil Drive Axle

▼ OEM Reference

BK 219990	LI 219990	TY 00591-41351-81
BK 241238	LI 241238	TY 00591-54654-81
CL 7003866	NI 43533-L1100	YT 220054163
HY 3042586	TY 00591-07374-81	

Part Number - 380050-007

Seal Oil

▼ OEM Reference

CL 7003807	JU 14458080	
CT 215416	JU 14473480	YT 220029615
HY 44542	SL S200851	YT 220075001
HY 44542	TY 00591-32069-81	YT 504224218
HY 3137615	TY 00591-60402-81	

Cylinder Parts



Part Number - 380050-037
Packing Cylinder Kit

▼ OEM Reference

CL 446444	JU 14462360	YT 220021100
CT 973546	TY 00591-22382-81	YT 516149005
HY 2302265	TY 00591-32404-81	
HY 3054917	TY 00591-60962-81	

Part Number - 380050-039

Lift Cylinder O/H Kit

▼ OEM Reference

CL 7004445	HY 3057756	YT 220037756
HY 2307874	TY 00591-45306-81	YT 505136027

Part Number - 380050-041

Packing Cylinder Kit

▼ OEM Reference

HY 2302714	TY 00591-32407-81	YT 506149006
HY 3054918	TY 00591-60963-81	YT 516149006
JU 1444116	TY 00591-76642-81	
JU 14441160	TY 220021877	

Part Number - 380050-038

Lift Cylinder O/H Kit

▼ OEM Reference

TY 00591-76586-81
YT 505136031
YT 522375008

Switches

Part Number - 380050-040

Ignition Switch

▼ OEM Reference

CL 7004147	JU 14483690	YT 504240854
CT 216444	TY 00591-06240-81	YT 580007799
HY 379902	TY 00591-32300-81	YT 580021375
HY 379902	TY 00591-51265-81	YT 580022227
HY 1492154	YT 220003423	
HY 2035830	YT 504240838	

